

ENERCEPT™ H8035/H8036

Networked Power Transducer (Modbus RTU)



US Patent No. 6,373,238



DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Follow safe electrical work practices. See NFPA 70E in the USA, or applicable local codes.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Read, understand and follow the instructions before installing this product.
- Turn off all power supplying equipment before working on or inside the equipment.
- Use a properly rated voltage sensing device to confirm power is off.
DO NOT DEPEND ON THIS PRODUCT FOR VOLTAGE INDICATION
- Only install this product on insulated conductors.

Failure to follow these instructions will result in death or serious injury.

A qualified person is one who has skills and knowledge related to the construction and operation of this electrical equipment and the installation, and has received safety training to recognize and avoid the hazards involved. NEC2009 Article 100

No responsibility is assumed by Veris Industries for any consequences arising out of the use of this material.

CAUTION

RISK OF EQUIPMENT DAMAGE

- Enercept meters are rated for use at 50-60Hz. Do not connect this product to circuits with high harmonic energy, such as Variable Speed Drives (a.k.a. Variable Frequency Drives, Adjustable Frequency Drives) or similar sources, as these may permanently damage the product.

Failure to follow these instructions can result in overheating and permanent equipment damage.

NOTICE

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations.
- The installer is responsible for conformance to all applicable codes.
- Mount this product inside a suitable fire and electrical enclosure.

FCC PART 15 INFORMATION

NOTE: This equipment has been tested by the manufacturer and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Modifications to this product without the express authorization of Veris Industries nullify this statement.

For use in a Pollution Degree 2 or better environment only. A Pollution Degree 2 environment must control conductive pollution and the possibility of condensation or high humidity. Consider the enclosure, the correct use of ventilation, thermal properties of the equipment, and the relationship with the environment. Installation category: CAT II or CAT III

Installer's Specifications

Measurement Accuracy:

System Accuracy	±1% of reading from 10% to 100% of the rated current*
Type of Measurement	One or three phase AC system

Input Voltage Characteristics:

Measured AC Voltage	208-480 VAC
Frequency Range	50/60 Hz
Fuses	1/2A, 600VAC, 200 kAIC

Input Current Characteristics:

Maximum Primary Current	100, 300, 400, 800, 1600, or 2400 A, continuous per phase**
-------------------------	---

Meter Current Draw:

Maximum	60 mA AC
---------	----------

Output:

Modbus RTU Protocol	RS-485, 2-wire plus common
Baud Rate	9600

Mechanical Conditions:

CT Case Isolation	600 VAC
Internal Isolation	2000 VAC RMS
Terminal Block Screw Torque	0.37 ft-lb (0.5 N-m) min.; 0.44 ft-lb (0.6 N-m) max.

Environmental Conditions:

Operating Temperature Range	2400 A model only: 0° to 50°C (32° to 122°F) all other models: 0° to 60°C (32° to 140°F)
-----------------------------	---

Storage Temperature Range	-40° to 70°C (-40° to 158°F)
---------------------------	------------------------------

Operating Humidity Range	<95% RH non-condensing
--------------------------	------------------------

Agency Approvals:

US and Canada (cULus)	UL508 (open type device)
-----------------------	--------------------------

* Meter accuracy specified with conductors centered in the CT window.

** For amperages greater than 2400A, see App Note VN19, www.veris.com/applicationnotes.aspx

QUICK INSTALL

Disconnect and lock out power before installation.

1. Set the address switches located on the bottom of the CT.
2. Connect the voltage leads to the source to be monitored.
3. Snap the CT onto the conductor (observe color matching).
4. Connect the Modbus wires (observe polarity).

TABLE OF CONTENTS

Quick Install	1
Operation	2
Product Identification	2
Dimensions	2
Product Diagram	2
Installation	3
Wiring	4
Data Outputs	4
Address Setup	5
Modbus Register Addressing	6
Using Integer Data Types	8
Notes	10
Troubleshooting	10

OPERATION

The H8035 and H8036 three-phase power transducers monitor energy parameters from aggregate kW (real power) and kWh (consumption) to power factor per phase. Integration of electronics lowers hardware and installation costs. The sensors automatically detect phase reversal, so CT load orientation is not a concern. The CTs and electronics are calibrated as a set, so it is necessary to color-match the CTs and voltage leads when installing. These devices monitor up to 63 loads at a time on a single RS-485 drop.

With two platforms to choose from (H8035 Basic/Energy Only or H8036 Enhanced Data Stream), the applications for these devices are diverse, including aggregate billing, tenant monitoring, energy management, performance contracting, demand limiting and cooling plant optimization.

PRODUCT IDENTIFICATION

*Modbus Enhanced Data Stream Power Transducers**

MODEL	MAX. AMPS	CT SIZE
H8036-0100-2	100	SMALL
H8036-0300-2	300	SMALL
H8036-0400-3	400	MEDIUM
H8036-0800-3	800	MEDIUM
H8036-0800-4	800	LARGE
H8036-1600-4	1600	LARGE
H8036-2400-4	2400	LARGE

**H8036 models work with H8920-1 LON nodes*

*Modbus Basic Power Transducers**

MODEL	MAX. AMPS	CT SIZE
H8035-0100-2	100	SMALL
H8035-0300-2	300	SMALL
H8035-0400-3	400	MEDIUM
H8035-0800-3	800	MEDIUM
H8035-0800-4	800	LARGE
H8035-1600-4	1600	LARGE
H8035-2400-4	2400	LARGE

**H8035 models work with H8920-5 LON nodes*

DIMENSIONS

SMALL
100/300 Amp

A = 3.8" (96 mm)
B = 1.2" (30 mm)
C = 1.3" (31 mm)
D = 1.2" (30 mm)
E = 4.0" (100 mm)
F = 4.8" (121 mm)

MEDIUM
400/800 Amp

A = 4.9" (125 mm)
B = 2.9" (73 mm)
C = 2.5" (62 mm)
D = 1.2" (30 mm)
E = 5.2" (132 mm)
F = 6.0" (151 mm)

LARGE
800/1600/2400 Amp

A = 4.9" (125 mm)
B = 5.5" (139 mm)
C = 2.5" (62 mm)
D = 1.2" (30 mm)
E = 7.9" (201 mm)
F = 6.0" (151 mm)

PRODUCT DIAGRAM

1. Voltage leads
2. Fuses
3. Modbus connector
4. Status LED: Blink codes: slow green for normal operation; slow red for incorrect wiring or low power factor (less than 0.5); fast red for maximum current exceeded.
5. Modbus address switches
6. External CTs: Permanently attached; do not disconnect or use with other power transducers.



Color match CTs and voltage leads! Example: clamp the red labeled CT around the power conductor connected to the red voltage wire.

INSTALLATION


⚠ Disconnect and lock out power before installation.

The Enercept meter, including the current transformers (CTs), voltage connection fuses, and fuse pack, is permitted within electrical distribution equipment including but not limited to panelboards, switchboards, motor control centers, and transformers. Carefully review the equipment in which the Enercept meter will be installed. Consider the following installation conditions during the installation process:


- Review the equipment enclosure for ventilation openings. Wires will cross many of these openings in a normal installation, however, do not install the Enercept where it will substantially block ventilation openings in the enclosure.
- The Enercept meter and the wiring installed within a wiring space or gutter should not exceed 75 percent cross sectional fill at the Enercept meter parts as addressed in the NEC. Improper installation of Enercept meter in the wire gutter of equipment may affect the thermal performance of the equipment.
- Consider the arrangement of CTs within the equipment to ensure the correct bending radius of conductors.
- Review the arrangement and location of the CTs within the equipment. Use appropriate support for the CT to prevent undue strain on the conductor.

1. Choose a unique address and set the switches for that address as shown in the Address Selection Switches section. Only addresses 1 to 63 can be used.
2. Connect the voltage leads to the phase conductors at a location that is not normally turned off. Connect voltage leads on the Line side of the conductor to ensure constant power to the Enercept. For a 3-phase system, connect the red lead to phase A, black to phase B, and yellow to phase C. See the Wiring section on the following page.


ADDRESS



3. Snap the CT onto the conductor. Connect CTs to the correspondingly colored voltage leads. If the application can exceed 20 times the rated CT current, use wire ties to secure the I-bar to the CT housing. This CT automatically detects phase reversal, so CT load orientation is not important.



4. Remove the terminal block and attach the RS-485 wires. Observe (+), (-), and Shield polarity. Insulate any exposed wiring.



5. For information regarding software setup, see the Modbus protocol specifications available at www.veris.com/Modbus/.
6. Check power reading (these calculations are approximations only).


Expected power:

$$kW = \text{Volts} \times \text{Amps} \times 1.732 \times \text{PF} / 1000$$


$$kW = \text{Horsepower} \times 0.746$$

WIRING


Typical 208/480 VAC 3Ø, 3- or 4- Wire Installation



Typical 240/120 VAC 1Ø, 3-Wire Installation



Typical 277 VAC 1Ø, 2-Wire Installation



DATA OUTPUTS

H8035

kWh, consumption
Reset kWh
kW, demand

H8036

kWh, consumption
kW, real power
kVAR, reactive power
kVA, apparent power
Power factor
Average real power
Minimum real power
Maximum real power
Voltage, line-to-line
Voltage, line-to-neutral
Amps, average current
kW, real power ØA
kW, real power ØB
kW, real power ØC
Power factor ØA
Power factor ØB
Power factor ØC
Voltage, ØA to ØB
Voltage, ØB to ØC
Voltage, ØA to ØC
Voltage, ØA to Neutral
Voltage, ØB to Neutral
Voltage, ØC to Neutral
Amps, Current ØA
Amps, Current ØB
Amps, Current ØC

Note: The Enercept cannot communicate on the network bus without power. Therefore, it is best to connect the voltage leads ahead of switching devices.

ADDRESS SETUP

Set these switches to assign a unique address before connecting the device to the Modbus RS-485 line. Each Modbus device must have a unique address. If two devices are given the same address, neither device will be able to communicate.



**DO NOT
USE ZERO!**

1	2	3	4	5	6	7	8	9	10	
11	12	13	14	15	16	17	18	19	20	21
22	23	24	25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40	41	42	43
44	45	46	47	48	49	50	51	52	53	54
55	56	57	58	59	60	61	62	63		

MODBUS REGISTER ADDRESSING

This table lists the addresses assigned to each data point. Registers are read Most Significant Byte (MSB) first. 32 bit floating point values are encoded per IEEE Standard 754. For floating point format variables, each data point appears twice because two 16-bit addresses are required to hold a 32-bit float value. The 16 bit Most Significant Word (MSW) is in the lower address of the register pair, while the least Significant Word (LSW) is in the upper address.

Modbus RTU function codes supported: 3=read holding registers; 6=preset single register; 17=report Slave I.D.

Quick Reference of the Most Common Data Points

Address	Typical Offset	Units	Description	Integer: multiplier required	Float: upper 16 bits	Float: lower 16 bits
40001	0	kWh	Energy Consumption, LSW	X		
40002	1	kWh	Energy Consumption, MSW	X		
40003	2	kW	Real Power	X		
40257	---	kWh	Energy Consumption		X	
40258		kWh	Energy Consumption			X
40259	0	kWh	Energy Consumption (same 40257)		X	
40260		kWh	Energy Consumption (same 40258)			X
40261	2	kW	Real Power		X	
40262		kW	Real Power			X

Complete Listing of Data Points

Address	Typical Offset	Units	Description	Integer: multiplier required	Float: upper 16 bits	Float: lower 16 bits
40001	0	kWh	Energy Consumption, LSW	X		
40002	1	kWh	Energy Consumption, MSW	X		
40003	2	kW	Real Power	X		
40004	3	kVAR	Reactive Power	X		
40005	4	kVA	Apparent Power	X		
40006	5	---	Power Factor	X		
40007	6	Volts	Voltage, line to line	X		
40008	7	Volts	Voltage, line to neutral	X		
40009	8	Amps	Current	X		
40010	9	kW	Real Power, Phase A	X		
40011	10	kW	Real Power, Phase B	X		
40012	11	kW	Real Power, Phase C	X		
40013	12	---	Power Factor, phase A	X		
40014	13	---	Power Factor, phase B	X		
40015	14	---	Power Factor, phase C	X		
40016	15	Volts	Voltage, phase A-B	X		
40017	16	Volts	Voltage, phase B-C	X		
40018	17	Volts	Voltage, phase A-C	X		
40019	18	Volts	Voltage, phase A-N	X		
40020	19	Volts	Voltage, phase B-N	X		
40021	20	Volts	Voltage, phase C-N	X		
40022	21	Amps	Current, phase A	X		
40023	22	Amps	Current, phase B	X		
40024	23	Amps	Current, phase C	X		
40025	24	kW	Average Real Power	X		
40026	25	kW	Minimum Real Power	X		
40027	26	kW	Maximum Real Power	X		
40257	---	kWh	Energy Consumption		X	
40258		kWh	Energy Consumption			X
40259	0	kWh	Energy Consumption (same 40257)		X	
40260		kWh	Energy Consumption (same 40258)			X
40261	2	kW	Real Power		X	
40262		kW	Real Power			X

Address	Typical Offset	Units	Description	Integer: multiplier required	Float: upper 16 bits	Float: lower 16 bits
40263	4	kVAR	Reactive Power		X	
40264		kVAR	Reactive Power			X
40265	6	kVA	Apparent Power		X	
40266		kVA	Apparent Power			X
40267	8	---	Power Factor		X	
40268		---	Power Factor			X
40269	10	Volts	Voltage, line to line		X	
40270		Volts	Voltage, line to line			X
40271	12	Volts	Voltage, line to neutral		X	
40272		Volts	Voltage, line to neutral			X
40273	14	Amps	Current		X	
40274		Amps	Current			X
40275	16	kW	Real Power, phase A		X	
40276		kW	Real Power, phase A			X
40277	18	kW	Real Power, phase B		X	
40278		kW	Real Power, phase B			X
40279	20	kW	Real Power, phase C		X	
40280		kW	Real Power, phase C			X
40281	22	---	Power Factor, phase A		X	
40282		---	Power Factor, phase A			X
40283	24	---	Power Factor, phase B		X	
40284		---	Power Factor, phase B			X
40285	26	---	Power Factor, phase C		X	
40286		---	Power Factor, phase C			X
40287	28	Volts	Voltage, phase A-B		X	
40288		Volts	Voltage, phase A-B			X
40289	30	Volts	Voltage, phase B-C		X	
40290		Volts	Voltage, phase B-C			X
40291	32	Volts	Voltage, phase A-C		X	
40292		Volts	Voltage, phase A-C			X
40293	34	Volts	Voltage, phase A-N		X	
40294		Volts	Voltage, phase A-N			X
40295	36	Volts	Voltage, phase B-N		X	
40296		Volts	Voltage, phase B-N			X
40297	38	Volts	Voltage, phase C-N		X	
40298		Volts	Voltage, phase C-N			X
40299	40	Amps	Current, phase A		X	
40300		Amps	Current, phase A			X
40301	42	Amps	Current, phase B		X	
40302		Amps	Current, phase B			X
40303	44	Amps	Current, phase C		X	
40304		Amps	Current, phase C			X
40305	46	kW	Average Real Power		X	
40306		kW	Average Real Power			X
40307	48	kW	Minimum Real Power		X	
40308		kW	Minimum Real Power			X
40309	50	kW	Maximum Real Power		X	
40310		kW	Maximum Real Power			X

Modbus addresses in the 4xxxx format follow the Modicon protocol specification for point addressing. The actual address sent is the value shown, minus 40001. In other words, the leading "4" is omitted, and the remaining 4-digit number is decremented so that point 40001 is requested with a value of zero in the actual Modbus communication. Some Modbus implementations require point addresses to be specified beginning at zero or 40000, instead of 40001. Programming code may also require addresses that correspond to actual values transmitted, so a value of zero is used to request data beginning at Modbus address 40001.

Many applications use a single Modbus command to read all of the data available from the Enercept. For integers, the beginning address is 40001 (or zero in the actual Modbus command), and for floating points the first address used is typically 40259 (or 258 in the actual Modbus command). Although the first floating point appears at address 40257, it is not necessary to read this value because it is a duplicate copy of the kWh value (required by the product firmware). When reading a block of data, the "typical offset" values index to the data within the block.

USING INTEGER DATA TYPES

Unlike the floating-point data type, the integer data type can only represent whole numbers between zero and 65535. To convert a data point value into the number it represents, multiply the value by a constant, as indicated in the table below.

Some data points require different multipliers for each amperage range, while others (e.g. volts and power factor) use the same multiplier regardless of the amperage range of the product. The latter are indicated by single row values.

Addr	Units	100A	300/400A	800A	1600A	2400A
40001	kWh	7.81E-03	0.03125	0.0625	0.125	0.25
40002	kWh	512	2048	4096	8192	16384
40003	kW	0.004	0.016	0.032	0.064	0.128
40004	kVAR	0.004	0.016	0.032	0.064	0.128
40005	kVAR	0.004	0.016	0.032	0.064	0.128
40006	---	3.0518E-5				
40007	Volts	0.03125				
40008	Volts	0.015625				
40009	Amps	3.906E-03	0.015625	0.03125	0.0625	0.1250
40010	kW	0.001	0.004	0.008	0.016	0.032
40011	kW	0.001	0.004	0.008	0.016	0.032
40012	kW	0.001	0.004	0.008	0.016	0.032
40013	---	3.0518E-5				
40014	---	3.0518E-5				
40015	---	3.0518E-5				
40016	Volts	0.03125				
40017	Volts	0.03125				
40018	Volts	0.03125				
40019	Volts	0.015625				
40020	Volts	0.015625				
40021	Volts	0.015625				
40022	Amps	3.906E-03	0.015625	0.03125	0.0625	0.1250
40023	Amps	3.906E-03	0.015625	0.03125	0.0625	0.1250
40024	Amps	3.906E-03	0.015625	0.03125	0.0625	0.1250
40025	kW	0.004	0.016	0.032	0.064	0.128
40026	kW	0.004	0.016	0.032	0.064	0.128
40027	kW	0.004	0.016	0.032	0.064	0.128

As an alternative to the table on the previous page, invert the values for use as divisors, in which the integer value returned by the Enercept is divided by a number from the table below. In most cases, the divisors are a more compact number.

Addr	Units	100A	300/400A	800A	1600A	2400A
40001	kWh	128	32	16	8	4
40002	kWh	1.9531E-3	4.8828E-4	2.4414E-4	1.2207E-4	6.1035E-5
40003	kW	250	62.5	31.25	15.625	7.8125
40004	kVAR	250	62.5	31.25	15.625	7.8125
40005	kVA	250	62.5	31.25	15.625	7.8125
40006	---	32768				
40007	Volts	32				
40008	Volts	64				
40009	Amps	256	64	32	16	8
40010	kW	1000	250	125	62.5	31.25
40011	kW	1000	250	125	62.5	31.25
40012	kW	1000	250	125	62.5	31.25
40013	---	32768				
40014	---	32768				
40015	---	32768				
40016	Volts	32				
40017	Volts	32				
40018	Volts	32				
40019	Volts	64				
40020	Volts	64				
40021	Volts	64				
40022	Amps	256	64	32	16	8
40023	Amps	256	64	32	16	8
40024	Amps	256	64	32	16	8
40025	kW	250	62.5	31.25	15.625	7.8125
40026	kW	250	62.5	31.25	15.625	7.8125
40027	kW	250	62.5	31.25	15.625	7.8125

NOTES

1. DO NOT GROUND THE SHIELD INSIDE THE ELECTRICAL PANEL. Insulate all Modbus wires, including the shield, to prevent accidental contact with high voltage conductors.
2. Mechanically secure the Modbus cable where it enters the electrical panel.
3. Connect all Modbus devices in a daisy-chain fashion. Use a 120 Ω terminating resistor between (+) and (-) on the first and last devices in the chain.
4. Use shielded twisted pair wire BELDEN 1120A or similar for the Modbus cable.



WARNING: After wiring, remove all scraps of wire or foil shield from the electrical panel. This could be DANGEROUS if wire scraps come into contact with high voltage wires!

TROUBLESHOOTING

Problem	Solution
Status LED does not blink	Check fuses and voltage connections. Status LED should blink regardless of CTs, Modbus connections, and DIP switch setting.
Enercept interferes with another device on the Modbus network	Set DIP switches to a different Modbus address not in use.
Readings seem highly inaccurate.	<ul style="list-style-type: none"> • Check that each CT is installed on the conductor with the corresponding color voltage input lead attached. In most cases, incorrect wiring will cause the Status LED to blink red (slowly). However, a power factor lower than 0.5 could cause the LED to blink this way, even if the unit is installed properly. • It does not matter which side of the CT faces towards the load. • If current is below 7% of full scale maximum for the CT, use a smaller CT or wrap each wire through the CT multiple times • Check current with an amp-clamp. <p>Expected power: $kW = Volts \times Amps \times 1.732 \times PF / 1000$ $kW = Horsepower \times 0.746$ PF is usually 0.7 to 0.95, depending on the load.</p>
Enercept goes offline when load is switched off.	Connect voltage leads on the Line side of the conductor. The Enercept cannot communicate on the Modbus network without voltage.
Status LED blinks red.	<ul style="list-style-type: none"> • If the LED blinks quickly (i.e., about 5 blinks in two seconds), then use a CT with a higher amp rating. • If the LED blinks slowly (i.e., about 1 blink per second), then the CTs are not installed on the correct conductors or the power factor is less than 0.5. The Enercept can accurately measure these low PFs, but few loads operate normally at such a low power factor. • If the LED blinks slowly (i.e., about 1 blink per second), the monitored load might be less than 10% of the CT maximum ratings.