# HIOKI

Instruction Manual

LR8400-20 LR8401-20 LR8402-20 MEMORY HILOGGER

HIOKI E.E. CORPORATION


July 2014 Revised edition 7 LR8400B980-07 14-07H



## **HiLogger Firmware Version Information and Upgrades**

LAN communication is available with HiLogger firmware version 1.20 and later. (The release date for version 1.20 is June, 2010.)

The HiLogger firmware version is displayed at the upper right on the System screen.



The latest version can be downloaded from Hioki's website.

Please visit our company's website or contact your dealer or Hioki representative for the version upgrade procedure.

# **Contents**

	iction	
	ming Package Contents	
Safety	Information	3
Operat	ing Precautions	6
Ch a a	ton 1	
Chap		10
overv	/iew	
1.1	Product Overview and Features	13
1.2	Measurement Flow	14
1.3	Names and Functions of Parts, Screen	
	Configurations	16
1.4	Basic Operation	22
•	Colocil operations (changing columing), coloiming travel	
	and displaying values)	
	Starting and Stopping Measurement	
	Disabling Key Operations (Key-Lock Function)	
	Performing Zero Adjustment	
	Saving Data	
	Confirming Inputs (Monitor)	26
Chap <sup>*</sup>	ter 2	
	urement Preparations	27
	•	
2.1	Attaching Expansion Input Units (as needed)	
2.2	, , , , , , , , , , , , , , , , , , ,	
	Install the Battery Pack	
	Charge the Battery Pack	
2.3	Connecting the AC Adapter	
2.4	Making Connections	
	Pre-Connection Inspection	
-	Voltage and Thermocouple Temperature Measuremer	
-	Temperature measurement mine a receivance remper	
_	Detector (RTD)	
	Humidity Measurement  Resistance Measurement	
_	Resistance MeasurementPulse Measurement	
-	Fuise ivicasultilitiil	40

	Connecting Alarm Outputs	41
	+12 V Output Connection (for external sensors)	42
	External Control (using TRIG OUT and EXT TRIG)	43
2.5	Turning the Power On and Off	44
2.6	Inserting a CF Card or USB Flash Drive	
	(when saving data)	45
	CF Card Insertion & Removal	46
	USB flash drive Insertion & Removal	46
	Formatting a CF Card/USB flash drive	47
2.7	Compensating for Input Circuit Offset	
	(Zero Adjustment)	48
Chap	ter 3	
	ngs	49
3.1	Setting Flow Overview	49
3.2	Configuring Measurement Settings	
	Time Setting by Key Operations	
3.3	Input Channel Settings	
	Key Setting Procedure	
	Voltage Measurement Settings	
	Temperature Measurement Settings (using thermocoup)	
		•
	Pulse or Logic Measurement Settings	61
	Integration (Count) Measurement Settings	62
	Revolution Measurement Settings	63
3.4	Data Saving Settings	64
3.5	Waveform Display Settings (as needed)	65
	Key Setting Procedure	65
	Coloding Wavelerin Biopiay Color imminimum	
	Specifying Vertical Display Range by Magnification ar	
	Zero Position (vertical axis expansion/compression)	66
	Specifying the Vertical Display Range by Upper and	67
	Lower Limits (expansion/compression)  Setting the Display Time Base	b/
_	(horizontal axis magnification)	68
3.6	Scaling Settings (as needed)	
0.0	Joanny Johnnyo (45 Hooded) IIIIIIIIIIIIIIIIIII	00

3.7 3.8 3.9	Entering Titles and Comments (as needed)71 Suppressing Noise (Enable Digital Filtering)73 Viewing and Editing with the All-Channel Settings List
•	Batch Copying Channel Settings
	Setting CH1 of UNIT1 Value as a Scaling Value (Inter-Channel Compensation function)79
Chapt Obser	ter 4 rving Measurements and Data83
4.1	Confirming Measured Values, and Starting Measurement83
•	
:	Verifying Waveform Display Position
4.3	
Chapt Speci	ter 5 fying Criteria for Measurements99
-	About Triggering99  Triggering Measurement Start and Stop100

101
102
105
106
ig)108
109
109
111
ttings 114
115
tions 117
119
121
121
123
123
124
125
aving . 127
S,
128
131
132
132
134
135
135
135
135 136
135 136 137
135 136

	Transferring Data to a PC (USB Drive Mode)140 Select the USB Drive Mode	
Chap <sup>†</sup> Nume	ter 7 erical Calculations/Waveform Calculations 143	
:	Calculate Average, Maximum, Minimum, and Etc143  Key Setting Procedure	5
7.2	Numerical Value Calculation Expressions148	
7.3 ■	Waveform Calculations    149      Key Setting Procedure    149	6
Chapt	ter 8	
	em Environment Settings 151	7
_	Key Setting Procedure152	
8.1	Operation Settings152 Using the Auto-Resume Function	8
	(Resume After Power Restoration)152	
	File Protection Level Setting153	
8.2	gg	
	Enabling and Disabling the Backlight Saver153	
	Adjust Backlight Brightness	
	Selecting Black or White Screen Background	
	Enabling or Disabling the Beeper	
	Selecting the Honzontal (Time) Axis Display155  Selecting the Display Language155	
	Display of Start/Stop Confirmation Messages	
8.3	CSV File Saving Settings156	
	CSV File Data Decimal and Separator Characters156	
	Select the sort order for numerical calculation results156	
	Setting How to Handle Date Data Stored in CSV Files157	
8.4		
•		

	Set Alarm Event Marking	157
8.5		
	Setting the Date and Time	158
	Initializing the HiLogger (System Reset)	159
	Self-Test	160
Chap	ter 9	
Exter	nal Control	161
9.1	External Trigger Input	. 161
9.2	External Signal Output (Trigger Output)	. 162
9.3	Alarm Signal Output (Alarm Output)	. 163
9.4	Synchronous Measurements with	
	Multiple HiLoggers	. 164
Chan	ter 10	
	ection to a PC(Communication)	165
	Communication Features	165
10.1	USB Settings and Connections	. 166
	1. HiLogger Setting	166
	2. Installing the USB Driver	
	3. Connecting the HiLogger to a PC	
	Features Available After USB Setting and Connection	
	4. Installing the Logger Utility Program	
	Uninstalling the Logger Utility	1//
10.2	LAN Settings and Connections (Before connecting to the network)	172
	Things to Check Before Making Settings	
	1. PC Network Setup	
	2. HiLogger Settings	
	3. Connecting the HiLogger to a PC	
	Features Available After LAN Setting and Connection	
	When LAN Communication Fails	186
10.3	Using the Logger Utility	. 187
	Starting and Ending Logger Utility	187
10.4		
	Function	
	Displaying the Main Page	188

		١
v	ı	ı

nte	

_		
	Remote Operating189	
	Start/Stop Measurement190	
	Viewing Current Measurement Values190	
	Acquiring Data from Internal Memory191	
	Setting Comments192	
10.5	Transferring Data to a PC with the FTP Server	
	Function193	
-	Restricting FTP Server Connections (FTP Authentication) 195	
10.6	Auto Sending Data using the FTP Client Function 196	
-	Setting Up an FTP Server on a PC197	
	HiLogger Auto-Send Settings211	
	Testing File Transfer214	
	Checking Communication Status215	
	Sending E-Mail216	
	HiLogger E-Mail Settings217	
	Testing E-Mailing220	
	Checking Mail Communication Status221	
	E-Mail Sending Authentication	
	About Communications Commands223	
-	Configuring Communications Command Operation223	
Chan <sup>-</sup>	ter 11	8
	fications 225	
-		
11.1	LR8400-20, LR8401-20, LR8402-20 Memory	9
	HiLogger Specifications225	
11.2	LR8500 Voltage/Temp Unit Specifications240	
11.3	LR8501 Universal Unit Specifications241	10
	ter 12	
√laint	enance and Service 243	11
12 1	Inspection, Repair, and Cleaning243	
	Troubleshooting244	12
	Disposing of the HiLogger246	12
	Removing the Lithium Battery246	<b>&gt;</b>
		ppe
		Appendix
		Inde
		<u> </u>

# viii

## Contents

Appendix	A1
Appendix 1 Scan Timing	A <sup>2</sup>
Appendix 2 Error Messages and Remedial Actions	
Appendix 3 File Naming	
Appendix 4 Text File Internal Format	
Appendix 5 Binary File Size Calculation	
Appendix 6 List of Default Settings	
Appendix 7 Maximum Recordable Time	
Appendix 8 Concerning Noise Countermeasures	
Appendix 9 Frequently Asked Questions	
■ Installation and Settings	
■ Triggering	
■ Measuring	
■ Data Saving	
■ Logger Utility	A2
<b>Appendix 10Introduction to Measurement Application</b>	ons A26
■ Measuring Electrical Energy by Pulse Count	A26
■ Connect a 4-20 mA output device and record the avalue every minute	
Appendix 11Input Circuit Diagram	A30
IndexIn	dex 1

## Introduction

Thank you for purchasing the Hioki Model LR8400-20, LR8401-20, LR8402-20 Memory HiLogger. To obtain maximum performance from the HiLogger, please read this manual first, and keep it handy for future reference.

The following documents are provided with this HiLogger. Refer to them as appropriate for your application. The following documents are provided with this HiLogger. Refer to them as appropriate for your application.

Document		ument	Description
	1	Measurement Guide	<b>Read first.</b> Offers an introduction to the HiLogger's basic measuring method for first time users.
	2	Instruction Manual (This document)	Contains explanation and instructions regarding the HiLogger's operating method and functions.

## **Registered Trademarks**

- Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries.
- CompactFlash is a registered trademark of Sandisk Corporation (USA).
- Sun, Sun Microsystems, Java, and any logos containing Sun or Java are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

# **Confirming Package Contents**

When you receive the HiLogger, inspect it carefully to ensure that no damage occurred during shipping. In particular, check the accessories, panel switches, and connectors. If damage is evident, or if it fails to operate according to the specifications, contact your dealer or Hioki representative.

Confirm that these contents are provided.		
□ LR8400-20, LR8401-20, LR8402-20 Memory HiLogger*1	☐ Instruction manual (This document)1	
	☐ Measurement guide1	
	□ USB Cable1	
☐ 9418-15 AC Adapter 1 with supplied power cord	(p. 141)	
	☐ Logger Utility(Data acquisition application program CD)1	
(p. 32)	The latest version can be downloaded from our web site.	
*: LR8400 (with two Model LR8500 Voltage/Temp Unit) LR8401 (with two Model LR8501 Universal Unit) LR8402 (with combined units, and UNIT1 is an LR8501 Universal Unit)		

_	26		
	ш		nc
v		w	

Contact your dealer or Hioki repres	sentative for details.
☐ LR8500 Voltage/Temp Unit	☐ 9727 PC Card (256MB)
☐ LR8501 Universal Unit	☐ 9728 PC Card (512MB)
☐ Z1000 Battery Pack	☐ 9729 PC Card (1GB)
☐ 9418-15 AC Adapter	☐ 9830 PC Card (2GB)
□ 9642 LAN Cable	☐ C1000 Carrying Case
☐ Z2000 Humidity Sensor	☐ Z5000 Fixed Stand


# **Safety Information**

## **▲** Danger

This HiLogger is designed to comply with IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, mishandling during use could result in injury or death, as well as damage to the HiLogger. Using the HiLogger in a way not described in this manual may negate the provided safety features. Be certain that you understand the instructions and precautions in the manual before use. We disclaim any responsibility for accidents or injuries not resulting directly from HiLogger defects.

This manual contains information and warnings essential for safe operation of the HiLogger and for maintaining it in safe operating condition. Before using it, be sure to carefully read the following safety precautions.

## **Safety Symbols**



The following symbols in this manual indicate the relative importance of cautions and warnings.

<b>A</b> DANGER	Indicates that incorrect operation presents an extreme hazard that could result in serious injury or death to the user.	
<u> </u>	Indicates that incorrect operation presents a significant hazard that could result in serious injury or death to the user.	
<b>△</b> CAUTION	Indicates that incorrect operation presents a possibility of injury to the user or damage to the HiLogger.	
NOTE	Indicates advisory items related to performance or correct operation of the HiLogger.	

#### Symbols for Various Standards



This symbol indicates that the product conforms to regulations set out by the EC Directive.



This is a recycle mark established under the Resource Recycling Promotion Law (only for Japan).



WEEE marking:

This symbol indicates that the electrical and electronic appliance is put on the EU market after August 13, 2005, and producers of the Member States are required to display it on the appliance under Article 11.2 of Directive 2002/96/EC (WEEE).

## Other Symbols



Indicates the prohibited action.

(p.) Indicates the location of reference information.

Indicates that descriptive information is provided below.



The names of setting objects and buttons on the screen are indicated by square brackets [].

#### SET

(Bold charac-

Bold characters within the text indicate operating key labels.

- Unless otherwise specified, "Windows" represents Windows 2000, Windows XP, Windows Vista, or Windows 7.
- Dialog box represents a Windows dialog box.
- · Click: Press and quickly release the left button of the mouse.
- Double click: Quickly click the left button of the mouse twice.

#### Accuracy

(resolution)

We define measurement tolerances in terms of f.s. (full scale), rdg. (reading) and dgt. (digit) values, with the following meanings:

The maximum displayable value or scale length. This is usually the (maximum display value or name of the currently selected range. Example: For the 1 V range, scale length) f.s. = 1 VThe value currently being measured and indicated on the measur-(reading or displayed value) ing instrument. The smallest displayable unit on a digital measuring instrument, dgt. i.e., the input value that causes the digital display to show a "1" as

the least-significant digit.

#### Measurement categories


This HiLogger complies with CAT II (300 VAC, DC) safety requirements.

To ensure safe operation of measurement instruments, IEC 61010 establishes safety standards for various electrical environments, categorized as CAT II to CAT IV, and called measurement categories.

CAT II:	Primary electrical circuits in equipment connected to an AC electrical outlet by a power cord (portable tools, household appliances, etc.) CAT II covers directly measuring electrical outlet receptacles.
CAT III:	Primary electrical circuits of heavy equipment (fixed installations) connected directly to the distribution panel, and feeders from the distribution panel to outlets.
CAT IV:	The circuit from the service drop to the service entrance, and to the power meter and primary overcurrent protection device (distribution panel).

Using a measurement instrument in an environment designated with a higher-numbered category than that for which the instrument is rated could result in a severe accident, and must be carefully avoided.

Use of a measurement instrument that is not CAT-rated in CAT II to CAT IV measurement applications could result in a severe accident, and must be carefully avoided.



#### Difference between "Measurement" and "Recording"

The measurement and recording processes are distinguished as follows for the purposes of these instructions.

Measurement:	The acquisition of input values into internal HiLogger memory or to a PC via communications.
Recording:	Storing measurement data on a CF card, USB flash drive or on a PC via data communication.

Measured data (data acquired in internal memory) is erased whenever a new measurement starts. To retain data, always record (save) it.

# **Operating Precautions**



Follow these precautions to ensure safe operation and to obtain the full benefits of the various functions.


#### **Before Use**

- Before using the HiLogger the first time, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your dealer or Hioki representative.
- Before using the HiLogger, make sure that the insulation on the cables is undamaged and that no bare conductors are improperly exposed.
   Using the HiLogger in such conditions could cause an electric shock, so contact your dealer or Hioki representative for replacements.

#### **Instrument Installation**

Operating temperature and humidity: 0 to 40°C at 80% RH or less (non-condensating)

Temperature and humidity range for guaranteed accuracy: 23±5°C, 80%RH or less





Exposed to direct sunlight Exposed to high tempera-



In the presence of corrosive or explosive gases



Exposed to water, oil, other chemicals, or solvents Exposed to high humidity or condensation



Exposed to strong electromagnetic fields Near electromagnetic radiators



Exposed to high levels of particulate dust



Subject to vibration



Near induction heating systems (e.g., high-frequency induction heating systems and IH cooking utensils)

### **Installation Precautions**



- Avoid temperature changes around the terminal block. Especially avoid directed airflow such as from an electric fan or air conditioner vent. Thermocouple inputs are prone to measurement errors.
- When the HiLogger is moved to a location with significantly different ambient temperature, allow at least 60 minutes for thermal equalization before measuring.

## **Handling the Instrument**

## 🕰 DANGER

To avoid electric shock, do not remove the HiLogger's case. The internal components of the HiLogger carry high voltages and may become very hot during operation.

# **<b><u>M</u>WARNING**

Touching any of the high-voltage points inside the HiLogger is very dangerous.

Do not attempt to modify, disassemble or repair the HiLogger; as fire, electric shock and injury could result.

# **△ CAUTION**

To avoid damage to the HiLogger, protect it from physical shock when transporting and handling. Be especially careful to avoid physical shock from dropping.



This instrument may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts..

## **Handling the Cords and Cables**

# 

- Avoid stepping on or pinching cables, which could damage the cable insulation
- To avoid breaking the cables, do not bend or pull them.
- To avoid damaging the power cord, grasp the plug, not the cord, when unplugging it from the power outlet.

#### **Before Turning Power On**



Before turning the HiLogger on, make sure the supply voltage matches that indicated on the AC adapter. Connection to an improper supply voltage may damage the HiLogger or AC adapter and present an electrical hazard.



When the power is turned off, do not apply voltage or current to the HiLogger. Doing so may damage the HiLogger.

## NOTE

- After use, always turn OFF the power.
- Brief power interruptions of 40 ms or less will not cause this HiLogger to malfunction. However, Longer interruptions may cause the HiLogger to shut itself off, so consider local power conditions before installing, as appropriate.
- To ensure that recording is not interrupted by power outages, you can use the 9418-15 AC Adapter and Z1000 Battery Pack together.

## **Using the Battery Pack**

# **<b>∆**WARNING

Be sure to observe the following precautions. Incorrect handling may result in liquid leaks, heat generation, ignition, bursting and other hazards.

 Use only the Hioki Model Z1000 Battery Pack. We cannot accept responsibility for accidents or damage related to the use of any other batteries.

See: "2.2 Using the Battery Pack (Option)" (p. 30)

- To avoid the possibility of explosion, do not short circuit, disassemble or incinerate battery pack. When storing the HiLogger, make sure no objects that could short-circuit the connectors are placed near them.
- The battery pack contains lye, which can cause blindness if comes into contact with the eyes. Should battery liquid get into your eyes, do not rub your eyes but rinse them in plenty of water and seek the immediate attention of a physician.
- To avoid electric shock, turn off the power switch and disconnect the cables before replacing the battery pack.
- After installing or replacing the battery pack, replace the battery compartment cover and screw.
- Handle and dispose of batteries in accordance with local regulations.

# **ACAUTION**

Observe the following to avoid damage to the HiLogger.

- Use the battery pack in an ambient temperature range of 0 to 40°C and charge it in an ambient temperature range of 10 - 40°C.
- If the battery packs fails to complete charging within the stipulated time, disconnect the AC adapter from the pack to stop charging.
- Consult your dealer or nearest service station should liquid leaks, strange odor, heat, discoloration, deformation and other abnormal conditions occur during use, charging or storage. Should these conditions occur during use or charging, turn off and disconnect the HiLogger immediately.
- Do not expose the HiLogger to water and do not use it in excessively humid locations or locations exposed to rain.
- Do not expose the HiLogger to strong impacts and do not throw it around.



- The battery pack is subject to self-discharge. Be sure to charge the battery pack before initial use.
- The battery pack is a consumable. If the battery capacity remains very low after correct recharging, the useful battery life is at an end.
- Battery pack lifetime (to at least 60% initial full-charge capacity) is about 300 charge/discharge cycles.
- To prevent battery pack deterioration when the battery will not be used for 1 month or longer, remove it and store it in a dry location with an ambient temperature range of between -20 to 30°C. Be sure to discharge and charge it every two months. Long-term storage at low battery capacity will reduce performance.
- During battery operation, the HiLogger automatically turns off when battery charge is depleted. Leaving the HiLogger in this state for a long time may cause over-discharge, so be sure to turn the HiLogger's power switch off.
- When the HiLogger has turned off automatically due to low battery charge, turn the power switch off and connect the AC adapter (or install new batteries), then allow about 30 seconds before switching back on. If the HiLogger is turned on too soon, it may turn off again automatically.

## **Using the AC Adapter**



- Use only the supplied Model 9418-15 AC Adapter. AC adapter input voltage range is 100 to 240 VAC (with ±10% stability) at 50/60 Hz. To avoid electrical hazards and damage to the HiLogger, do not apply voltage outside of this range.
- Turn the HiLogger off before connecting the AC adapter to the HiLogger and to AC power.
- To avoid electrical accidents and to maintain the safety specifications of this HiLogger, connect the supplied power cord only to a 3contact (two-conductor + ground) outlet.

#### **Connection Precautions**

#### **Connecting to the Analog Input Terminals**

## **▲** DANGER

Do not leave the HiLogger connected to test objects in environments where a voltage surge might exceed the dielectric withstand voltage. Doing so could result in damage to the HiLogger, bodily injury or fatal accident.

# **∆WARNING**

- This instrument is not drip-proof. To prevent liquid including water from entering the instrument, in particular, drop measurement cables down below the instrument.
- To avoid shock and short circuits, turn off the power to lines to be measured before making connections to terminals to be measured and turning on the HiLogger.
- To avoid shock and short circuits, turn off all power before connecting measurement cables.
- Do not connect a cable to the HiLogger while it is connected to the object to be measured. Otherwise, an electric shock accident may occur.
- To avoid short-circuit accidents, make certain that connections are secure.
- To avoid electric shock and short-circuit accidents, always close the analog input terminal cover and tighten the screws.
- To avoid electric shock, use the recommended wire type to connect to the current input terminals, or otherwise ensure that the wire used has sufficient current handling capacity and insulation.
- Channels are insulated by semiconductor relays. When a voltage beyond the specification is applied between the channels, the semiconductor relay may short circuit. Please ensure that a voltage beyond specification, especially a surge such as a lightning, is never applied. When an abnormal measurement value is observed, please contact your dealer or Hioki representative for inspection.

# NOTE

- Measurements may be affected by noise or other electromagnetic ingress if input leads are longer than about three meters.
- Route measurement leads and cables as far away as possible from power and earth lines.
- Measurement values may be scattered if the leads are routed in parallel with other devices. If they must be parallel, check operation before taking measurements.

#### Connecting to the Pulse Input, Alarm Output, and Other External Control Terminals



- The External Control Terminals is not isolated from the HiLogger's chassis ground. Make certain that there will be no potential difference between the External Control Terminals and the ground of any connected device. Otherwise, the HiLogger or device could be damaged.
- To avoid electric shock or damage to the equipment, always observe the following precautions when connecting to pulse input terminals, alarm output terminals, and External Control Terminals.
- Always turn off the power to the HiLogger and to any devices to be connected before making connections.
- Be careful to avoid exceeding the ratings of External Control Terminals.
- Ensure that devices and systems to be connected to the External Control Terminals are properly isolated.

#### Using a CF Card/USB flash drive



- Inserting a CF card/USB flash drive upside down, backwards or in the wrong direction may damage the CF card, USB flash drive, or HiLogger.
- Never eject a CF card /USB flash drive while measuring or when the HiLogger is or accessing the card. Data on the CF card/USB flash drive may be destroyed. (The CF icon/USB flash drive icon at the lower left is red while the card is being accessed.)
- Do not transport the HiLogger while a USB flash drive is connected. Damage could result.
- As the CF card/USB flash drive is sensitive to static electricity, damage to the CF card/USB flash drive or wrong operations by the HiLogger may occur due to static electricity. Please be careful when handling it.
- With some USB flash drives, the HiLogger may not start up if power is turned on while the USB flash drive is inserted. In such a case, turn power on first, and then insert the USB flash drive. It is recommended to try out operation with a USB flash drive before starting to use it for actual measurements.



- The Flash memory in a CF card/USB flash drive has a limited operating life. After long-term usage, data storage and retrieval become difficult. In this case, replace the CF card/USB flash drive with a new one.
- We cannot provide compensation for data loss in a CF card/USB flash drive, regardless of content or cause of the damage. Data is also cleared from memory if a long time passes after measuring. Always maintain a backup of important data stored on a CF card/USB flash drive.
- Although real-time saving to USB flash drive is supported, a CF card is recommended for data preservation. Performance cannot be guaranteed when using storage media other than a Hioki-specified CF card option.

#### **CD Handling**




- Always hold the disc by the edges, so as not to make fingerprints on the disc or scratch the printing.
- Never touch the recorded side of the disc. Do not place the disc directly on anything hard.
- Do not wet the disc with volatile alcohol or water, as there is a possibility of the label printing disappearing.
- To write on the disc label surface, use a spirit-based felt pen. Do not use a ball-point pen or hard-tipped pen, because there is a danger of scratching the surface and corrupting the data. Do not use adhesive labels.
- Do not expose the disc directly to the sun's rays, or keep it in conditions
  of high temperature or humidity, as there is a danger of warping, with
  consequent loss of data.
- To remove dirt, dust, or fingerprints from the disc, wipe with a dry cloth, or use a CD cleaner. Always wipe from the inside to the outside, and do no wipe with circular movements. Never use abrasives or solvent cleaners.
- Hioki shall not be held liable for any problems with a PC system that arises from the use of this CD, or for any problem related to the purchase of a Hioki product.

# **Overview**


# Chapter


#### **Product Overview and Features** 1.1

The portable data logger is expandable from 30 to 60 channels. Data variations can be observed on the high-resolution color LCD screen, and monitored on a PC connected via LAN or USB.





## 1.2 Measurement Flow


















# 1.3 Names and Functions of Parts, Screen Configurations






#### 1.3 Names and Functions of Parts, Screen Configurations







Chapter 1 Overview

### 1.3 Names and Functions of Parts, Screen Configurations







Chapter 1 Overview




# 1.4 Basic Operation

Screen Operations (changing settings, scrolling waveforms, and displaying values)







#### **Starting and Stopping Measurement**

Start measuring (acquiring measurement data) as follows.

When saving is enabled, data is recorded to the specified removable storage (CF card or USB flash drive) as it is being recorded to internal memory.

#### Start Measurement



#### Press START.

(The green LED lights.)

#### **Important**

If [Start/Stop message] is enabled on the System screen, the Start confirmation message appears. Select [Yes] to start mea-

When restarting measurement after stopping, data in the HiLogger's internal memory is overwritten. Be sure to save important data to removable storage before restarting measurement.

### **Finish Measurement**



When [Repeat] (record multiple instances of the specified recording length) or [Cont] (record continuously) is enabled:

Pressing **STOP** stops measuring.

When [Repeat] and [Cont] are disabled (Off):

Measuring stops after the specified recording length.

(If [Start/Stop message] is enabled on the System screen, the Stop confirmation message appears when you press STOP during measurement. Pressing STOP during recording displays a confirmation message. Select [Yes] to stop measuring.)

For details about repeating and continuous recording: See: "Recording Time (Record time)"(p.51), "Repeat Recording (Repeat)"(p .51)


NOTE

To automatically save measurement data, confirm the following before starting:

- Auto saving is properly set (p. 125)
- The removable storage is properly inserted (p. 45)
- There is sufficient free space on the removable storage (p. A12)

### **About Measuring Operation**


See: About Continuous and Repeating Recording: (p. 50)



#### **About Dead time**

When repeating recording is enabled ([Repeat] set to [On])

After a recording length has elapsed, some "dead time" is needed for internal processing before recording can resume. No measurement occurs during the dead time. So to avoid information loss, split data into files at a specified interval by enabling continuous recording ([Repeat]), and selecting [Split Save] for auto saving.



Measurement operation depends on whether the trigger or timing function is used (p. 117).

Keys can be disabled to avoid inadvertent operations.



Press and hold the right and left cursor keys for three seconds to lock the other keys, and repeat to unlock.

## **Performing Zero Adjustment**



With the Waveform/Numerical or [CH] screen displayed, press the up and down cursor keys simultaneously.

See: "2.7 Compensating for Input Circuit Offset (Zero Adjustment)" (p. 48)


## **Saving Data**

Measurement data, settings, screen images and numerical calculation results can be saved.

For details of the saving methods, see "Chapter 6 Saving & Loading Data" (p. 121).

#### (Default settings)


Saving Method: [Select & Save] (Press SAVE to select and save data.)



## **Confirming Inputs (Monitor)**


You can confirm the status of inputs and display ranges with the current settings (data is not acquired to internal memory).

This function is convenient for checking measured values before activating real-time saving.





- The monitor function is not available while measuring.
- To display instantaneous values while the HiLogger is measuring, first press WAVE/DATA to switch to the [Wave+Value] display, then start measurement.
- Depending on the scaling setting, channels requiring more than 14 characters to display the measured value and unit symbols may be displayed in smaller characters.



#### 2.1 **Attaching Expansion Input Units (as needed)**

Attach optional input units to the HiLogger as needed for the objects to be mea-

Each HiLogger supports up to two additional units.

# **Input Unit Types**

Two types of input units are available.

See "11.2 LR8500 Voltage/Temp Unit Specifications" (p. 240), "11.3 LR8501 Universal Unit Specifications" (p. 241) for detailed input unit specifications.

# **Input Unit Models**

LR8500 Voltage/Temp Unit	LR8501 Universal Unit
Measures voltage, temperature, and humidity	Measures voltage, temperature, humidity, and resistance
Measurement Parameter Voltage Temperature (thermocouple) Humidity (using Hioki Z2000 Humidity Sensor)	Measurement Parameter     Voltage     Temperature (thermocouple or resistance temperature sensor)     Humidity (using Hioki Z2000 Humidity Sensor)
M3 screw terminal block Input channels: 15	Resistance  Push-button terminal block Input channels: 15
CH1	CH1 · · · · · · · CH15     CH1 · · · · · · · · · · · · · · · · · · ·

#### **Installation Procedure**


# **<b><u>M</u>WARNING**

- To avoid electric shock accidents or damage, turn off the HiLogger and remove the cables before attaching or detaching.
- To avoid electric shock accidents or damage, ensure that the connectors are secured with the screws.
- To avoid electric shock accidents or damage, always attach the cover over the connectors on the HiLogger side and affix with the screws (unless attaching an extension).

# NOTE

- The HiLogger can be extended with up to two input units.
- If an input unit is attached when the power is on, it will not be properly recognized.

Required items: extension unit (w/supplied screws), phillips screwdriver (M3)



# 2.2 Using the Battery Pack (Option)



If commercial power is not available when the AC adapter is connected, the LR8400-20, LR8401-20, LR8402-20 Memory HiLogger can operate from the Model Z1000 Battery Pack, so


when using commercial power, the battery pack serves as a backup supply during power outages.

Charge the battery pack fully before using it the first time.

Be sure to read "Using the Battery Pack" (p.8) before installing.

# **Install the Battery Pack**

Required items: phillips screwdriver (M3), Hioki Z1000 Battery Pack




**⚠**CAUTION

When installing the battery pack, do not attach the plug to the connector upside down. Doing so will damage the instrument.

# **Charge the Battery Pack**

Regardless of whether the Memory HiLogger is on or off, the battery pack recharges whenever the 9418-15 AC Adapter is plugged in to a power source (p. 32).

Therefore, charging is provided by merely keeping the battery installed in the Memory HiLogger.



# When to charge

When powering the HiLogger from the battery pack without the Model 9418-15 AC Adapter, the low battery indicator ( ) is displayed when the battery charge is depleted, indicating that the battery pack requires charging.

#### Approximate charging time:

Quick charging a "Low" battery pack takes about three hours. The Charge LED turns off an hour of additional charging.

# 2.3 Connecting the AC Adapter





Connect the power cord and the HiLogger to the supplied Model 9418-15 AC Adapter, then plug the power cord into an outlet. When used with the battery pack installed, the battery serves as an operating backup supply in case of power failure, and the AC adapter otherwise has priority.

Before connecting, be sure to read "Using the AC Adapter" (p.9) and "Handling the Cords and Cables" (p.7).



- Connect the output plug to the instrument before plugging the power cord into an outlet. Connecting an energized output plug to the instrument could damage the instrument.
- When connecting an external power supply, connect the output plug to the instrument before activating the external power supply.






#### Turn power off before making connections.

Before connecting, be sure to read "Before Use" (p.6), "Handling the Cords and Cables" (p.7), and "Connection Precautions" (p.10).

### 2.4 Making Connections




If connecting crimped terminals to the analog input terminals, use insulated terminals for M3 screws with the size shown below.



# **Voltage and Thermocouple Temperature Measurement**

# < Voltage/Temp Unit >

Required items: phillips screwdriver (for M3 screws), measurement leads (for voltage measurement), or thermocouple (for temperature measurement)




# <Connecting to the terminals of the Universal Unit>


Required items: phillips screwdriver (for M3 screws), flat-blade screwdriver (tip width 2.6 mm), measurement leads (for voltage measurement), or thermocouple (for temperature measurement)

Recommended wire diameter: Single strand diameter:  $\phi 0.4$  mm -  $\phi 1.2$  mm (AWG26-16) Multi-strand: 0.2 mm<sup>2</sup> - 0.75 mm<sup>2</sup> (AWG24-20) Standard insulation stripping length: 8 mm

With a Phillips screwdriver, loosen the screws in the terminal block cover, and lift the cover.



Push in the button on the connector with a flatblade screwdriver.



- With the button held in, insert the cable into the cable connection hole.
- Release the button. The cable is locked.

- Connect to the measurement object.
- Replace the terminal block cover, and tighten the screws.


Torque screws to no more than 0.6 N•m.

# Temperature Measurement with a Resistance Temperature Detector (RTD)

# <Connecting to the terminals of the Universal Unit>

Required items: phillips screwdriver (for M3 screws), flat-blade screwdriver (tip width 2.6 mm), RTD

Recommended wire diameter:Single strand diameter: φ0.4 mm - φ1.2 mm (AWG26-16) Multi-strand: 0.2 mm<sup>2</sup> - 0.75 mm<sup>2</sup> (AWG24-20) Standard insulation stripping length: 8 mm




# **Humidity Measurement**


# <Connecting to the terminals of the Voltage/Temp Unit>

Required items: phillips screwdriver (for M3 screws), Hioki Z2000 Humidity Sensor

With a Phillips screwdriver, loosen the screws in the terminal block cover of the Voltage/ Temp Unit, and lift the cover.



- Pull up the cover on the external control terminal block.
- Loosen the terminal block screws, insert the bare ends of the leads, and tighten the screws.




Connect to the measurement object.

Replace the terminal block cover on the Voltage/Temp Unit, and tighten the screws.

> Torque screws to no more than 0.6 N•m.

Replace the cover on the external control terminal block.


#### Connect the wires as follows.




# <Connecting to the terminals of the Universal Unit>

Required items: phillips screwdriver (for M3 screws), flat-blade screwdriver (tip width 2.6 mm), Hioki Z2000 Humidity Sensor


With a Phillips screwdriver, loosen the screws in the terminal block cover of the Universal Unit, and lift the cover.



- Pull up the cover on the external control terminal block.
- 3 Loosen the external I/O terminal block screws, insert the bare ends of the leads, and tighten the screws.




Push in the button on the universal unit's connector with a flatblade screwdriver.



- With the button held in, insert the cable into the cable connection hole.
- 6 Release the button. The cable is locked.



### Connect the wires as follows.



- 7 Connect to the measurement object.
- 8 Replace the terminal block cover on the Universal Unit, and tighten the screws.

Torque screws to no more than 0.6 N•m.

Replace the cover on the external control terminal block.

# **Resistance Measurement**

# <Connecting to the terminals of the Universal Unit>


Required items: phillips screwdriver (for M3 screws), flat-blade screwdriver (tip width 2.6 mm), measurement leads

Recommended wire diameter: Single strand diameter:  $\phi$ 0.4 mm -  $\phi$ 1.2 mm (AWG26-16) Multi-strand: 0.2 mm<sup>2</sup> - 0.75 mm<sup>2</sup> (AWG24-20) Standard insulation stripping length: 8 mm


With a Phillips screwdriver, loosen the screws in the termi-

cover.

nal block cover, and lift the




Push in the button on the connector with a flatblade screwdriver.



- With the button held in, insert the cable into the cable connection hole.
- Release the button. The cable is locked.

- Connect to the measurement object.
- Replace the terminal block cover, and tighten the screws.

Torque screws to no more than 0.6 N•m.




Shop for Power Metering products online at: www.PowerMeterStore.ca 1.800.561.8187

# **Pulse Measurement**

< Connecting to the external control terminals >


Required items: phillips screwdriver (for M3 screws), measurement leads



# **Connecting Alarm Outputs**

< Connecting to the external control terminals >


Required items: phillips screwdriver (for M3 screws), measurement leads



# +12 V Output Connection (for external sensors)

< Connecting to the external control terminals >

Required items: phillips screwdriver (for M3 screws), measurement leads





+12 V is present whenever the HiLogger is on. When making connections, be careful to avoid short-circuiting to GND terminals.

NOTE


Maximum supply current is 100 mA.

# External Control (using TRIG OUT and EXT TRIG)


< Connecting to the external control terminals >

Required items: phillips screwdriver (for M3 screws), measurement leads

Lift the external control terminal block cover.




Loosen the terminal block screws, insert the bare ends of the leads, and tighten the screws.



Connect the trigger signal input and output.

Replace the cover on the external control terminal block.


Connect the '+' wire to the TRIG.OUT (or EXT.TRIG) terminal, and the '-' wire to a GND terminal.




- · Connect the TRIG.OUT terminal a trigger input on another device, and connect the EXT.TRIG (input) terminal to the trigger output another device (as needed).
- Five GND terminals are provided. Connections can be made to any GND terminal.

# 2.5 Turning the Power On and Off

Be sure to read "Before Turning Power On" (p .7) before turning power on.





# Inserting a CF Card or USB Flash Drive 2.6 (when saving data)

To save and reload HiLogger measurement data, use an optional CF card (as described below) or an after-market USB flash drive.

Be sure to read "Using a CF Card/USB flash drive" (p.11) before using removable storage media.

#### **Important**

Performance specifications cannot be guaranteed when using storage media other than a Hioki-specified CF card option.

- Hioki options PC cards (includes adapter) Note: The HiLogger does not support card slot adapters. 9727 PC Card 256M, 9728 PC Card 512M, 9729 PC Card 1G, 9830 PC Card 2G
- See "6.4 Data Management" (p. 135) for details about managing data storage in the media.




If the Eject button is in the released position, press it in first before inserting the CF card all the way in. Inserting the CF card when the Eject button is released may damage the instrument.

If the CF card does not go all the way in, do not force it in. Press the Eject button once to release it, then press it again and insert the CF card all the way in.




- Although real-time saving to USB flash drive is possible, a CF card is recommended for optimum real-time data preservation.
- USB flash drive security features such as fingerprint authentication are not supported.

# **CF Card Insertion & Removal**



# Inserting a CF card


- 7 Open the CF card slot cover.
- Press the Eject button in if it is in the released position.
- Face the CF card with the arrow mark on top (▲), and insert it in the direction of the arrow all the way in the slot.



#### Removing a CF card

- Open the CF card slot cover.
- Press the Eject button (to release it).
- 3 Press the Eject button again and pull the card out.

# **USB flash drive Insertion & Removal**



Inserting a USB flash drive

Align the USB flash drive connector with the USB port, and insert it all the way in.

Removing a USB flash drive Pull the USB flash drive out.

See: To replace removable storage during real-time saving: (p. 127)

This procedure describes how to format a CF card or USB flash drive in the HiLogger.

Select the File Screen. 2  $\square$   $\square$   $\square$  Open the Control Dialog box 3 ■ D Select [Format]. □ □ Apply The Format Confirmation dialog appears. **4** ■ □ **■** Select [Yes]. ☐ ☐ ☐ Apply The Format Confirmation dialog appears again. Select [Yes]. ☐ ■ D Apply


NOTE

Formatting irretrievably erases all data on the CF card/USB flash drive. Always backup important data from the CF card/USB flash drive before formatting.

# 2.7 Compensating for Input Circuit Offset (Zero Adjustment)

Zero adjustment corrects for voltage offset at the input terminals, so that Memory HiLogger measurements are relative to zero volts.

Execute zero adjustment whenever input circuit offset is a concern.



NOTE

- Any zero-adjust setting is cleared upon system reset (p. 159).
- Zero adjustment cannot be performed while measuring.

# **Settings**

# Chapter 3

#### **Setting Flow Overview** 3.1

Configure measurement settings before starting to measure. Select the display method and configure auto saving as needed.

After a measurement setting configuration has been saved (p. 131), you can start measuring immediately after loading the setting configuration data.


WAVE/DATA Display the Setting screen For new measurement When setting configuration data has been saved configurations Configure measurement settings Reload stored settings (p. 132) Configure measurement settings (p. 50) Setting Save Set. Waveform(realtime) [Setting] Screen [Setting] Screen Configure input channels (p. 53) СН (as needed) Waveform Display (p. 65) Scaling (p. 69) Titles and Comments (p. 71) Auto Save (p. 64) Noise Suppression (p. 73) View/Edit All Channel Settings List (p. 74) [CH] Screen

Chapter 3 Settings

# 3.2 Configuring Measurement Settings

Configure measurement settings on the [Setting] screen.
The available measurement methods are Normal Recording, Continuous Recording and Repeat Recording.

The Setting screen cannot be displayed while measuring.




 Measuring Method
 Setting Method

 Normal Recording
 Set [Cont] to On.

 Continuous Recording
 Set [Cont] to Off, and set a [Record time] (measurement time span).

 Repeat Recording
 Set [Repeat] to On.

# **Time Setting by Key Operations**



# Recording Interval (Interval)

Select the data acquisition interval.


Setting options:( \* : default setting)

10ms, 20ms\*, 50ms, 100ms, 200ms, 500ms, 1s, 2s, 5s, 10s, 20s, 30s, 1min, 2min, 5min, 10min, 20min, 30min, 1h

- When expansion input units are installed (as UNIT3 and UNIT4), the default setting is 50 ms.
- To select 10-ms intervals, first disable input units 2 to 4 (set to Off).

# Repeat Recording (Repeat)

Select whether to automatically start a new measurement after stopping, or to finish after one measurement.



Setting options:( \* : default setting)

Off*	Measuring stop after one recording length (time span).
On	When stopped by a stop trigger or elapsed recording time,
	measurement automatically restarts.
	Press STOP to stop measuring.

# **Continuous** Recording (Cont)

Select whether to measure for a specified time span, or continuously.

Setting options:( \* : default setting)

0 1 (	3,
Off	Normal recording (specify the recording time, and measure)
On*	Select for continuous measurement.

# Recording **Time** (Record time)

### Set this when [Cont] is disabled (Off).

Specify the duration of one recording length (time span).

The maximum setting is limited by the recording capacity of internal memory. The actual limit depends on the selected recording interval and number of channels used for measurements, so the maximum settable time is displayed as the [Max] value (indicated by the red box).



Setting options:(default setting: 10 seconds)

d (0 to 499), h (0 to 23), min (0 to 59), s (0 to 59)

Chapter 3 Settings

### 3.2 Configuring Measurement Settings



#### **About the Recording Interval**

- Select the data acquisition interval to suit your measurement objectives.
- Note that shorter recording intervals restrict the maximum recording time.
- The minimum recording interval depends on the input unit (channels), and whether burn-out detection is enabled.

#### With burn-out detection (Burn Out) disabled (Off)

When channels 1 to 15 of UNIT1 are selected for measurement: 10 ms When channels 1 to 15 of UNIT2 are selected for measurement: 20 ms When channels 1 to 15 of UNIT3 and UNIT4 are selected for measurement: 50 ms


### With burn-out detection (Burn Out) enabled (On)

When channels 1 to 15 of UNIT1 are selected for measurement: 20 ms When channels 1 to 15 of UNIT2 are selected for measurement: 50 ms When channels 1 to 15 of UNIT3 and UNIT4 are selected for measurement: 100 ms

See: "Chapter 11 Specifications" (p. 225)

 Some waveform peaks may not be displayable with certain interval settings.

For example, when the **[Interval]** is 1 s and the **[Time/DIV]** (time base) is 5 s/DIV.




See: About Horizontal Axis Settings: (p. 68)

- With the 50 or 60 Hz digital filter setting, longer recording intervals produce lower cut-off frequencies and better noise suppression (p. 73).
- The recording interval cannot be changed while measuring. Stop measurement before setting.

# During Normal Recording ([Cont] disabled (Off), and [Repeat] enabled (On))

After a recording length has elapsed, some "dead time" is needed for internal processing before recording can resume. No measurement occurs during the dead time. So to avoid information loss, split data into files at a specified interval by enabling continuous recording ([Repeat]), and selecting [Split Save] for auto saving.



# 3.3 Input Channel Settings

Configure the input channel settings on the [CH] screen.

NOTE The Setting screen cannot be displayed while measuring.


Input channels are as follows. Each channel can provide the following measurements.

- •Voltage/Temp Unit (UNIT1 to UNIT4, each with analog waveform input channels CH1 to CH15)
- •Universal Unit (UNIT1 to UNIT4, each with analog waveform input channels CH1 to CH15)
- •The HiLogger's external control terminals (pulse/logic waveform inputs P1 to P8)

Application	Channels Used	Reference page
Voltage Measurement	01 1 1/15	(p. 55)
Temperature Measurement (using thermocouples)	Channels on a Voltage/Temp Unit or Universal Unit	(p. 56)
Humidity Measurement		(p. 59)
Humidity Measurement (using RTDs)	Channels on an Universal Unit	(p. 58)
Resistance Measurement	Chamileis on an Oniversal Onit	(p. 60)
Pulse or Logic Measurement	Pulse/logic input channels	(p. 61)
Integration (Count) Measurement	(HiLogger external control ter	(p. 62)
Revolution Measurement	minals)	(p. 63)

Other than these, measurements with specific criteria and alarm outputs are available. See "Chapter 5 Specifying Criteria for Measurements" (p. 99) for details.





#### 3.3 Input Channel Settings

#### Unit Switching


(Analog input channel settings) UNIT1 ••• UNIT4  $\rightarrow$  (pulse input and alarm output channel settings) PLS & ALM  $\rightarrow$  (numerical calculation channel settings) CALC1  $\rightarrow$  CALC2  $\rightarrow$  and return to UNIT1

### Channel Switching

(Analog input channel settings) 1-1 ••• 1-15  $\rightarrow$  2-1 ••• 2-15  $\rightarrow$  3-1 ••• 3-15  $\rightarrow$  4-1 ••• 4-15  $\rightarrow$  (pulse input and alarm output channel settings) P1 ••• P8  $\rightarrow$  ALM1 ••• ALM4  $\rightarrow$  (waveform calculation channel settings) W1 ••• W30  $\rightarrow$  and return to 1-1

View input status and the display range while making settings on the [CH] screen.

After setting, press MONIT to confirm input status and display ranges (p. 26).



Except when [Value] is selected, the gauge is displayed for the currently selected channels. The gauge scale is determined by measurement and display range settings.

Monitoring is not available for disabled (Measurement Off) channels, and those with [X] selected for their color.

### Monitor display switching

(Right column)

#### ■ [All Wave]

Displays all channel level monitors.

#### ■ [UnitWave]

Displays level monitors for all channels in the selected input unit.

(Left column)

#### [All Ch]

When [All Wave] is selected, displays all channel level monitors.

When [UnitWave] is selected, displays level monitors for all channels in the selected input unit.

#### ■ [SlctCh]

Displays a channel level monitor for the selected channel.

#### [Value]

Displays numerical values for all channels in the selected input unit.



Level monitor numerical value refresh rate and waveform horizontal axis span depend on the recording interval and horizontal axis (time base) settings. Therefore, long recording intervals can delay numerical value display refresh by as much as 20 seconds. If you need faster value display refresh, select a shorter recording interval.

If the horizontal axis (time span) is too long, one division of the waveform may not be displayed.

# **Voltage Measurement Settings**

Configure these settings for each voltage measurement channel.

See: "Key Setting Procedure" (p .53)

Select the input unit (UNIT1 to 4) and channel (1-1 to 4-15), and check the box to enable the chan-



Select the appropriate measurement amplitude range.

Setting options:( \* : default setting)

10mV\*, 20mV, 100mV, 200mV, 1V, 2V, 10V, 20V, 100V, 1-5V



Chapter 3 Settings

#### When a measured value far exceeds the range limit (range label)

"OVER" or "-OVER" is displayed in place of numerical/cursor values, and the following values are applied to calculations and data storage.

Input type	Input range	+OVER value	-OVER value
	10mv	0.0163835	-0.016384
	20mv	0.032767	-0.032768
	100mv	0.163835	-0.16384
	200mv	0.32767	-0.32768
Voltage	1V	1.6384	-1.6384
voltage	2V	3.2767	-3.2768
	10V	16.3835	-16.384
	20V	32.767	-32.768
	100V	163.835	-163.84
	1-5V	16.3835	-16.384

#### **Instrumentation and Control Device Measurements**

- To measure 4-20 mA current, connect a 250  $\Omega$  shunt resistor between + and analog input terminals (p. 34).
- Select the [1-5V] range to measure 4-20 mA instrumentation control signal outputs.
- The [1-5V] setting automatically selects the [10V] range with an 5-V upper limit and 1-V lower limit. To change the upper and lower limits, select the [10V] range.



Use the scaling function to scale measurements to any arbitrary unit value for display (p. 69).

# Temperature Measurement Settings (using thermocouples)

Follow this procedure to configure thermocouple temperature measurement channels. Make these settings on the **[CH]** screen.

See: "Key Setting Procedure" (p .53)

- Select the input unit (UNIT1 to 4) and channel (1-1 to 4-15), and check the box to enable the channel.
- 2 Select [Tc].

**EXT** 

ON

3 Select the type of thermocouple to be used.

Setting options:( \* : default setting)

K\*, J, E, T, N, R, S, B, W

Select the temperature measurement range.

Setting options:( \* : default setting)

100°C, \*500°C, 2000°C

The type-B thermocouple setting is disabled when the 100°C or 500°C range is selected. To use a type-B thermocouple, first set the range to 2000°C.

5 Select the reference junction compensation (RJC) method.

Setting options:( \* : default setting)

INT\* Use the HiLogger's internal compensation. Select this when connecting the thermocouple (or compensating leads) directly to the HiLogger. Measurement accuracy is the sum of the temperature measurement accuracy and the RJC accuracy.

Use an external RJC method instead of the HiLogger's internal compensation. Select this when using an external cold junction reference (e.g., ice water). HiLogger measurement accuracy is equivalent to the temperature measurement accuracy.


Enable/disable burn-out detection.

Setting options:( \* : default setting)

DFF\* Disable burn-out detection. Normally when the thermocouple is disconnected, the value will fluctuate, etc. and will not be stable.

Detect burn-out during thermocouple measurement. When a burn-out occurs, "BURNOUT" is displayed as the numerical, cursor, or calculation value, and the following values are applied to calculations and data storage: 327.66, 1638.3, and 3276.6°C for the 100, 500, and 2000°Cf.s. ranges, respectively. Note that the recording interval setting is limited.

See: "About the Recording Interval" (p .52)



#### Temperature Measurement Range

(Depends on thermocouple type)

K	-200°C to 1350°C
J	-200°C to 1200°C
Е	-200°C to 1000°C
Т	-200°C to 400°C
N	-200°C to 1300°C
R	0°C to 1700°C
S	0°C to 1700°C
В	400°C to 1800°C
W	0°C to 2000°C

With type B, the display shows 0 to 400°C, but accuracy is not guaranteed.

#### **About Burn-Out Detection**

- When burn-out detection (Burn Out) is enabled (On), a tiny sensing current is applied during each recording interval during thermocouple measurements to detect broken wires.
- Detection current is timed to avoid affecting measured values.
- · For a specific recording interval, the filter cut-off frequency is higher when burn-out detection is enabled, so noise suppression is less effective.
- See: "Chapter 11 Specifications": "Cut-off frequency" (p. 237)
- When measuring the temperature of the range's +f.s., the wire is considered to be broken when the thermocouple resistance exceeds nearly following values. When burn-out detection is enabled with extended thermocouple wires, be sure that the wire diameter is sufficient.


			Range	
		100°Cf.s.	500°Cf.s.	2000°Cf.s.
	K	260	5400	4370
	J	470	4150	1630
	Е	1520	7400	390
	Т	220	5440	5440
Thermocouple	N	520	1470	590
	R	90	40	880
	S	90	80	1300
	В	_	_	2090
	W	220	910	3090


For example, measurement in the 100°C range with a K-type thermocouple and 0.32 mm diameter wire extended beyond about 20 meters is detected as a burn-out.

#### If Thermocouple Measurement Range is Exceeded, or when a measured value far exceeds the range limit (range label)

- Example: Using a type T thermocouple with range -200 to +400°C When a measured value exceeds the measurement range of the thermocouple and far exceeds the range limit (range label), the waveform saturates at the top of the screen, as shown at the right.
- When a measured value far exceeds range limit (range label), "OVER" or "-OVER" is displayed in place of numerical/cursor values, and the following values are applied to calculations and data storage.

Input type	Input range	+OVER value	-OVER value
Thermocouple	100°C	327.67	-327.68
(Tc)	500°C	1638.4	-1638.4
(10)	2000°C	3276.7	-3276.8





# **Temperature Measurement Settings (for RTDs)**

Follow this procedure to configure resistance temperature detector (RTD) measurement channels. Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p .53)

- Select the input unit (UNIT1 to 4) and channel (1-1 to 4-15), and check the box to enable the channel.
- 2 Select [Rtd].
- 3 Select the type of RTD to be used.

Setting options:( \* : default setting)

Pt100\*, JPt100

4 Select the appropriate temperature measurement range.

Setting options:( \* : default setting)

100°C\*, 500°C, 2000°C

5 Select the wiring configuration.

Setting options:( \* : default setting)

3 Wire\* 3-wire RTD connection configuration
4 Wire 4-wire RTD connection configuration



The range setting determines the measurable temperature range

100°C	-100°C to 100°C
500°C	-200°C to 500°C
2000°C	-200°C to 2000°C

Temperature measurement limits are determined by the measurement range selected for each sensor.

Temperature Measurement Ranges


(Temperature measurement range depends on RTD characteristics)

Pt100	-200°C to 800°C
JPt100	-200°C to 500°C

# When the RTD measurement range is exceeded, or when a measured value far exceeds the range limit (range label)

- Example: Using a type Pt100 RTD with range -200 to +800°C When a measured value exceeds the measurement range of the RTD and far exceeds the range limit (range label), the waveform saturates at the top of the screen, as shown at the right.
- When a measured value far exceeds range limit (range label), "OVER" or "-OVER" is displayed in place of numerical/cursor values, and the following values are applied to calculations and data storage.

•	storage.						
I	Input type	Input range	+OVER value	-OVER value			
İ		100°C	327.67	-327.68			
	RTD	500°C	1638.4	-1638.4			
١		2000°C	3276.7	-3276.8			




# **Humidity Measurement Settings**

Enable this channel setting for humidity measurement with the optional Z2000 Humidity Sensor. Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p .53)

Select the input unit (UNIT1 to 4) and channel (1-1 to 4-15), and check the box to enable the channel.

2 Select [Humid].



\* The range is fixed at [100% f.s.].

# When a measured value far exceeds the range limit (range label)

"OVER" or "-OVER" is displayed in place of numerical/cursor values, and the following values are applied to calculations and data storage.

١	Input type	Input range	+OVER value	-OVER value
	Humidity	100%RH	3276.7	-3276.8

3

Chapter 3 Settings

#### **Resistance Measurement Settings**

Make these channel settings for resistance measurement.


Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p .53)

- Select the input unit (UNIT1 to 4) and channel (1-1 to 4-15), and check the box to enable the channel.
- 2 Select [Resist].
- 3 Select the appropriate measurement amplitude range.

Setting options:( \* : default setting)

10Ω\*, 20Ω, 100Ω, 200Ω





For inductive loads such as coil windings, the slow response time may prevent correct resistance measurement. In this case, select a recording time longer than 5 s.

#### When a measured value far exceeds the range limit (range label)

"OVER" or "-OVER" is displayed in place of numerical/cursor values, and the following values are applied to calculations and data storage.

Input type	Input range	+OVER value	-OVER value
Resistance	10Ω	16.3835	-16.384
	20Ω	32.767	-32.768
	100Ω	163.835	-163.84
	200Ω	327.67	-327.68

Chapter 3 Settings


# **Pulse or Logic Measurement Settings**

Make these channel settings for pulse and logic measurements.

(See "Integration (Count) Measurement Settings" (p .62) and "Revolution Measurement Settings" (p .63) for pulse measurements.)

Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p .53)




NOTE


Channels L1 to L8 share the same On/Off state. For example, when L1 and L2 are both enabled, disabling L1 also disables L2. Threshold and filter settings are specific to each channel.

### **Integration (Count) Measurement Settings**

Configure these settings for each pulse channel receiving input from a pulse output device such as a watt-hour or flow meter. Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p.53)








- Use the scaling function to display integrated pulse counts as the corresponding physical units (such as Wh or VA) of the measurement parameter (p. 69).
- The counter saturates at 1,073,741,823 counts. If you expect to exceed this count, we recommend measuring with the Integration Mode (Count Mo) set to Instantaneous (Inst), and summing later with a spreadsheet program.

Configure these settings for each pulse channel on which you will be counting pulses corresponding to revolutions, such as output from a rotary encoder or tachometer. The revolution measurement is obtained by counting the number of pulses input per second. Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p .53)




3

Chapter 3 Settings

#### 3.4 Data Saving Settings

#### **Revolution Measurement Theory**

Pulse count is measured using the HiLogger's internal 10 ms sampling interval.



The revolution rate (r) per second during time t [s] is obtained by dividing the number of pulses from (t-1) to t [s] by the number of pulses per revolution.

Pulse count at t<sub>s</sub> minus pulse count at (t -1) <sub>s</sub>

$$r [r/s] = \frac{}{Pulses \ per \ revolution}$$
(r/s: Revolutions per second)

#### Example: Pulses per revolution = 4

When the number of pulses counted in one second is  $P_{100}$  = 1000 c, and the number of pulses counted in two seconds is  $P_{200}$  = 2000 c, then the revolution rate (r/s) at t=2s ( $r_{t=2}$ ) can be obtained.

$$r_{t=2} = \frac{2000 - 1000}{4} = 250 \text{ [r/s]}$$

## Exception: When time $\boldsymbol{t}_{\boldsymbol{S}}$ is less than one second

The pulse count at  $(t-1)_s$  (whole seconds) cannot measured, so 100 times the pulse count between  $(t-0.01)_s$  and  $t_s$  serves and the pulse count for one second to obtain the revolution rate. As a result, revolution measurements when t is less than one second are scattered.

NOTE

Use the scaling function to display integrated pulse counts as the corresponding physical units (such as Wh or VA) of the measurement parameter (p. 69).

# 3.4 Data Saving Settings

Before measuring, select whether to automatically save data to CF card or USB flash drive while measuring, or to immediately save manually (only when you press SAVE).

See Auto Saving (p. 125) and Immediate Saving (p. 128) for setting procedures.

#### 3.5 **Waveform Display Settings (as needed)**


Set the waveform display settings as needed.

These settings can be changed on the Numerical/Waveform screen after measurement (p. 85).

NOTE The Setting screen cannot be displayed while measuring.

Chapter 3 Settings

# **Key Setting Procedure**



# **Selecting Waveform Display Color**

Different display colors can be selected for each input channel waveform.

Select from the waveform display color setting options.


Setting options:Off (x), 24-color



### 3.5 Waveform Display Settings (as needed)

# Specifying Vertical Display Range by Magnification and Zero Position (vertical axis expansion/compression)

The vertical display range and zero position can be specified for each channel. The magnification setting determines the displayed range. Waveforms are expanded or compressed vertically relative to the center of the screen.



Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p .65)

Display range magnification setting (expansion/compression)



Magnified

Magnified Display (x2)


7	Select [Pos].							Disp		_1		
2	Select	the m	agnifica	ation.				Type  Zoom	Pos X	-2		
			s:( * : def		0 Pos	50 %	- 3					
	x100, x	<b>&lt;50</b> , <b>x2</b>	0, x10, x	_		hange 1's digi	it					
3	Set the		red zere eight.	ntage	T	he expansion rang	n/com-					
	Setting	options	S:					pends on the selected				
	-50 to 1	50% (w	ith x1 mag	gnification	า)			r	nagnification.			
	Zoom		-Position ng range	Zoom		ro-Position tting range						
	x1/2	0 to	100%	x10	-95	0 to 1050%						
	x1		o 150%	x20		60 to 2050%						
	x2 x5		to 250% to 550%	x50 x100		0 to 5050% to 10050%						
)efa	ult Settir	•	Zoom	Zero pos	sition	Input ty	/ne	Zoom	Zero position			
	Voltage		x1	50		Resistance (Resist)		x1	0			
Ter	mperature		x1	0		Logic		_	_			
	nperature	` '	x1	0		Integration (Count)		_	_			
Humidity (Humid) x1			0		Revolution (Revolve)		x1	0				
Measurement range (Zoom: x1) Display range												
100% 50% 0% 100% 50% 0% 100% 50% 0% 100%												

NOTE

Magnification and zero-position settings are ignored when the display range is defined by upper and lower limits.


The vertical display range can be defined by upper and lower limits.

Using this method, the voltage range does not need to be selected because the optimum range is selected automatically for the display.



Make these settings on the [CH] screen.

See: "Key Setting Procedure" (p .65)



#### Numerical Value Entry

1. Select a digit to change with the left/right cursor keys, and increment/decrement the digit with the up/down keys.

(The rightmost character is for an optional measurement unit symbol. Pressing the up/down keys selects from among E - P - T - G - M - k - (blank) - m - u - n - p - f- a. If no unit symbol is needed, it can be left "blank".)


2. When the desired value is selected, press [OK].



- However, upper and lower limit settings are ignored when magnification and zero position are enabled to define the display range.
- The range is not automatically optimized when the upper and lower limits are set on the Waveform/Numerical screen.

#### 3.5 Waveform Display Settings (as needed)

# Setting the Display Time Base (horizontal axis magnification)



Displayed waveforms can be expanded or compressed along the horizontal axis. Shorter setting values correspond to greater magnification. Make these settings on the [Setting] screen.

See: "Time Setting by Key Operations" (p .50)

Settings can be changed during and after measurement on the [Wave+Value] display of the Waveform/Numerical screen(p. 89).

# Select the time per division.

Setting options:( \* : default setting)

100ms\*, 200ms, 500ms, 1s, 2s, 5s, 10s, 20s, 30s, 1min, 2min, 5min, 10min, 20min, 30min, 1h, 2h, 5h, 10h, 12h, 1day [/DIV]



#### When auto save is enabled for waveforms

100, 200 and 500 ms settings are automatically changed to 1 s when measurement starts, and the shorter values cannot be selected while measuring.


#### The [Time/DIV] range depends on the [Interval] setting.

Horizontal axis display options are affected when the recording interval is changed after measuring, because the options for expanding (or compressing) the displayed axis depend on the recording interval used when measuring. When using the Logger Utility program with a LAN connection, recording intervals from 100 ms to 2 s are not available, regardless of auto save settings (5 s is automatically selected).

Selectable, x: Not selectable, △: Not selectable while measuring

Horizon-								F	Recor	ding i	nterv	iterval											
tal axis				าร]			[s]				[min]					[h]							
tai axis	10	20	50	100	200	500	1	2	5	10	20	30	1	2	5	10	20	30	1				
100ms	•	•	•	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×				
200ms	•	•	•	•	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×				
500ms	•	•	•	•	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×				
1s	•	•	•	•	•	•	×	×	×	×	×	×	×	×	×	×	×	×	×				
2s	•	•	•	•	•	•	•	×	×	×	×	×	×	×	×	×	×	×	×				
5s	•	•	•	•	•	•	•	×	×	×	×	×	×	×	×	×	×	×	×				
10s	•	•	•	•	•	•	•	•	•	×	×	×	×	×	×	×	×	×	×				
20s	•	•	•	•	•	•	•	•	•	•	×	×	×	×	×	×	×	×	×				
30s	•	•	•	•	•	•	•	•	•	•	×	×	×	×	×	×	×	×	×				
1min	•	•	•	•	•	•	•	•	•	•	•	•	×	×	×	×	×	×	×				
2min	•	•	•	•	•	•	•	•	•	•	•	•	•	×	×	×	×	×	×				
5min	•	•	•	•	•	•	•	•	•	•	•	•	•	×	×	×	×	×	×				
10min	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	×	×	×	×				
20min	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	×	×	×				
30min	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	×	×	×				
1h	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	×				
2h	Δ	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
5h	Δ	Δ	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
10h	Δ	Δ	Δ	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
12h	Δ	Δ	Δ	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
1day	Δ	Δ	Δ	Δ	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				

#### Scaling Settings (as needed) 3.6




The Setting screen cannot be displayed while measuring.

Use the scaling function to convert input voltage to the physical units of the measurement parameter for display, such to convert voltage input for display as electrical current.


Converted values can be displayed in fixed or floating-point notation.

Make these settings on the [CH] screen. See: "Key Setting Procedure" (p .65)

Scaling Voltage, Temperature, Humidity, Resistance, and Revolution **Measurements** 




#### 3.6 Scaling Settings (as needed)



# Integration Measurement Scaling Setting

Integrated pulse values can be converted for display as physical units of the measurement parameter (such as Wh or VA).

Pulse output devices determine the amplitude per pulse in physical units, or the number of pulses per fundamental unit (for example, per kWh, liter or m<sup>3</sup>).



#### Scaling Setting Example

For integration with a 50,000 pulse/kWh watt-hour meter:

Cond: Dec Units: kWh 1kwh=50000 pulse

For integration with a 10 liter/pulse flow meter:

Cond: Dec Units: L 1 pulse=10L



#### Combining scaling and display positioning (upper/lower limits)

To use both scaling and upper/lower display limits, set the scaling first, then upper/lower limit values.
Saving and loading data with scaling function

When the scaling function is set to enable, scaling information as well as raw data (non-converted data) in binary format are saved. When the data saved in the storage devices is loaded, the converted data will be displayed. The raw data can also be observed by resetting the scaling function to OFF.


#### **Entering Titles and Comments (as needed)** 3.7

Comments of up to 40 characters can be entered as a title for the measurement data, and as a label for each input waveform. Titles and comments are displayed on the waveform/numerical screen (Comments appear only when [Value+Cmnt] display is selected).

Titles can be entered on the [Setting] and [Comment] screens, and comments can be entered on the [CH] and [Comment] screens.

This description enters a comment on the [CH] screen.


NOTE The Setting screen cannot be displayed while measuring.



# 3.7 Entering Titles and Comments (as needed)

# **Operating Panel**

The operating panel depicts the functions of HiLogger's operating keys.



The following characters are converted as follows when saved to a text file.



#### **Suppressing Noise (Enable Digital Filtering)** 3.8

Electrical noise mixed with input signals can be removed by digital filtering.



Noise suppression is most effective for longer recordings, where it can provide higher measurement accuracy and less scattering. Unless the timing difference between channels needs to be minimized, we recommend selecting 50 or 60 Hz to match the local line frequency.

See: "Cut-off frequency" (p .237)

NOTE

The Setting screen cannot be displayed while measuring.

### **Setting Procedure**


Make these settings on the [Setting] screen. See: "Time Setting by Key Operations" (p .50)




- Select 50 or 60 Hz to match the local line frequency.
- When 50 or 60 Hz is selected, longer recording intervals provide lower cut-off frequencies and better noise suppression.
- · A larger number of channels (input units) raises the cut-off frequency for a specific recording interval, and weakens noise suppression. See: "Cut-off frequency" (p.237)
- When 50 or 60 Hz is selected, the measurement timing difference between channels increases relative to the recording interval. Disable filtering (set to Off) to minimize the timing difference between channels (to within 500 us for adjacent channels, and 10 ms for all channels).

Chapter 3 Settings

# Viewing and Editing with the All-Channel 3.9 **Settings List**





NOTE

■ calc2

• The contents of the displayed settings are copied, except for "waveform display color", "input type", and "measurement On/Off settings". However, "input type" and "measurement On/Off settings" can be copied from the [Range] screen.

Copies the settings from waveform calculation channel W16 on the screen to channels W17 to W30.

RTD (Resistance Temperature Detector) and resistance settings (specific to a Universal Unit) cannot be copied to a Voltage/Temperature Unit.

Chapter 3 Settings

[Copy the settings of W16 shown on screen to W17 till W30.]

# 3.9 Viewing and Editing with the All-Channel Settings List


# Batch Setting Waveform Display/Hide and Waveform Color Settings for All Channels

The display of all waveforms can be hidden, and all waveform display colors can be set to defaults. This setting is only available on the **[Range]** screen.



# **Initializing Settings (to factory defaults)**

Certain settings in all input units (or a selected input unit) can be reset to their factory default state.



2

Chapter 3 Settings

# 3.9 Viewing and Editing with the All-Channel Settings List

## Aligning Zero Positions on the Grid

All channels in every unit (CH1-1 to 15, CH2-1 to 15, CH3-1 to 15, CH4-1 to 15 and P1 to ALM4) can be displayed evenly spaced at 5% or 10% intervals on the vertical axis, from top to bottom.

Only those channels set for the same input type and range as the reference channel, and with [Disp span] set to [Pos] (p. 66), are valid.




# Alignment Example (with CH1-1 zero-position aligned at 90% and occupying 5% of vertical screen height)

Channel	Zero-position (%)	,					
CH1-1	90	Interval 200ms	Horz 2s/DIV	Filt 60Hz	Sorn Gauge+Wave	All Wa	ve IINIT1
CH1-2	85	0.10000 V	11012 237019	1111 00112	Jenn dauge mave	nii na	Set Item
CH1-3	80	0.00000 V					Channel
CH1-4	75	-0.10000 V				112	Channe I
CH1-5	70	-0.20000 V				1-3	1- 1 🗸
CH1-6	65	-0.20000 V				115	Input Voltage
CH1-7	60						Range
CH1-8	55	-0.40000 V_				113	1 V
CH1-9	50	-0.50000 V.				<b>451</b>	
CH1-10	45	-0.60000 V				41513 41514	Disp Span
CH1-11	40	-0.70000 V				485	Type Position
CH1-12	35	-0.80000 V.					Zoom
CH1-13	30	-0.90000 V					0 Pos
CH1-14	25	1- 1	0s Meas. Start '	10-03-26 10:	10s :13:42		90 %
CH1-14	20	CEI(4.5MB/ 487MB 1.0%		15.7%)		110-03	EJECT Jump -26 10:14:43

Chapter 3 Settings

A value measured on CH1 of UNIT1 (Analog channel CH1-1) can be set as the scaling value. This function is convenient for thermocouple measurements when errors (such as thermocouple deviations) give different values for the same known temperature.

It applies only to channels with the same input type and range setting as CH1 of UNIT1.



NOTE

When scaling is automatically set by steps 1 to 6 on next page procedure, the measurement units are initially set to [V].


To set all channels to [°C] make the following settings beforehand.

1. Set the [Convert] setting to [Dec] and [unit] to [°C] on the [Conv/Calc] screen.



2. For [Batch Proc], execute [Correct the value to the same as CH1 when input type is same.] (p. 75).

### 3.9 Viewing and Editing with the All-Channel Settings List



# Display Celsius (°C) temperature values as Fahrenheit (°F)

All measured temperature values can be converted at once from Celsius to Fahrenheit

The conversion is simultaneously reflected appropriately on all scaled values.

To revert from Fahrenheit units to Celsius, disable (set to Off) the scaling function (p. 69). This setting is only available on the **[Conv/Calc]** screen.



3

Chapter 3 Settings

# **Observing Measurements and** Chapter 4 **Data**

# **Confirming Measured Values, and Starting** Measurement

Before starting a formal measurement, press MONIT to check measured values as needed (p. 26).

When you have confirmed that the settings are correct, press START to start formal measurement (p. 23).

Pay attention to the following items while measuring.

Measure (as needed)

Chapter 4 Observing Measurements and Data

# **<b><u>M</u>WARNING**

- This table shows the maximum applied voltage ratings for the analog input units and the HiLogger's external control I/O terminals, between grounds, and between channels. To avoid electric shock accidents and damage to the HiLogger, do not exceed these voltages.
- Channels are insulated by semiconductor relays. When a voltage beyond the specification is applied between the channels, the semiconductor relay may short circuit. Please ensure that a voltage beyond specification, especially a surge such as a lightning, is never applied. When an abnormal measurement value is observed, please contact your dealer or Hioki representative for inspection.

Input and Output	Maximum	Maximum rated	Max. Inter-Channel
Terminals	Input Voltage	voltage to earth	Voltage
Analog Input Terminals (both Voltage/ Temp Unit, and Universal Unit)	±100 VDC	300 V AC,DC	Voltage/Temp Unit: 250 VDC Universal Unit: 300 VDC, however, RTDs are not isolated between channels
Pulse Input Terminals	0 to 50 VDC	Non-Isolated (HiLogger/GND Common)	Non-Isolated (HiLog- ger/GND Common)
Alarm Output Terminals	-	Non-Isolated (HiLogger/GND Common)	Non-Isolated (HiLog- ger/GND Common)
External Trigger (EXT.TRIG) Terminal	0 to 10 VDC	Non-Isolated (HiLogger/GND Common)	-
Trigger Output (TRIG.OUT) Terminal	-20 to 30 VDC	Non-Isolated (HiLogger/GND Common)	-


- Never apply voltage to the alarm output terminals. The HiLogger will be damaged.
- The grounds for the EXT TRG and TRIG OUT terminals are common with the HiLogger grounds (GND), and are not isolated. To avoid damaging the HiLogger, connect wiring so as to avoid any potential difference between the grounds of the EXT TRIG and TRIG OUT terminals and connected devices (or system).

#### 4.2 **Observing Waveforms**


View data during and after measuring on the Waveform/Numerical Screen.

# Displaying Waveforms (Display Descriptions)

Press the WAVE/DATA to display the Waveform/Numerical screen. Repeated key presses cycle the screen through seven types (p. 19).




#### 4.2 Observing Waveforms



# **Displaying Gauges**

A gauge corresponding to the measurement range of each channel can be displayed at the left side of the screen, for confirming measurement values. The color of the gauge matches the waveform display color of its input channel. Channel settings can also be changed.






Displayed numerical values are those of the current input signals.

See: To view cursor position values numerically: "Displaying Cursor Values" (p. 91)

To display waveforms and numerical values



# To display numerical values and comments




# To display numerical values only




Chapter 4 Observing Measurements and Data

## **Scrolling Waveforms**

When measuring or displaying an existing waveform, use **SCROLL/CURSOR** to scroll. (While measuring, waveforms can be freely viewed up to the current measurement point.)





## When measuring with [Cont] set to [On]


If internal memory becomes full, recording continues by overwriting the oldest acquired data. Because of that, scrolled waveforms viewed while measuring are limited to the part that has not yet been erased.




# **Verifying Waveform Display Position**

From the scroll bar you can verify the relative position and size of the displayed portion of a waveform within the overall measured waveform.

The width of the currently displayed time span indicator within the scroll bar depends on the time base (time per horizontal division) setting, even when the recording length is unchanged.




Waveforms can be magnified (expanded or compressed) along the time axis by changing the time per horizontal division.



Detailed waveform data is usually best observed with the time axis expanded, while longer-term trends are best observed with it compressed.


Horizontal magnification can be changed while measuring.

However, when measuring with auto saving enabled, the 100, 200 and 500 ms settings are not selectable.




# **Viewing Any Waveform Location (Jump Function)**

When the recording length of a waveform is long, you can specify the portion to be displayed immediately.




This is available only when measurement is stopped. While measuring, [Jump] is changed to [Trace] (p. 88).



Chapter 4 Observing Measurements and Data


# **Specifying a Waveform Time Span**

Specify a waveform time span when saving a partial waveform or applying numerical calculations (Trace cursors or Vertical cursors).



Time difference and potential difference (and when scaling is enabled, scaling values) can be read as numerical values using the A/B cursors.






Cursor values can be displayed for all channels, or for only desired channels (p. 92).

4

Chapter 4 Observing Measurements and Data

### 4.2 Observing Waveforms








Press the outer left and right scrolling keys to scroll in large steps.

#### **About Cursor Types**

Cursor Type	Example	Cursor Value
Trace Cursors	A B B-A	Displays the time and measurement values at the A/B cursors, or the time and measurement differences between the A/B cursors.  Displays the intersections (trace points) of cursors and waveforms.(the intersections of waveform traces of selected channels)
Vertical Cursors	A B B-A	Displays the time and frequency values at the A/B cursors, or the time and frequency differences between the A/B cursors.
Horizontal Cursors	BA B-A	Displays the measurement values at the A and B cursors for the selected channel(s), or the difference between A/B cursor values. A/B cursors can be enabled for any channel.

You can insert up to 100 event marks at any point while measuring, to help find them later.

See: "Searching Event Marks" (p. 97)



Event marks can be applied by the following methods.

- Press START while measuring
- Press the on-screen [Make Mark] button.
- Apply a signal to the EXT TRIG terminal
- When a warning occurs


# **Inserting Event Marks While Viewing Waveforms**

Use this procedure to insert event marks while viewing data on the Waveform/Numerical Value screen during measurement.

Press **START** to apply a mark.

Event marks are numbered in the sequence they are inserted.

Marks can also be applied with the following procedures.




Chapter 4 Observing Measurements and Data

# 4.3 Marking Waveforms and Searching Marks (Search Function)


# **Inserting Event Marks Using External Input Signals**

Event marks can be inserted by applying external input signals. Make this setting before starting measurements.



# **Alarm Event Marks**

Event marks can be inserted by alarm events. Make this setting before starting measurements.



4

Chapter 4 Observing Measurements and Data

# 4.3 Marking Waveforms and Searching Marks (Search Function)

# How are event marks handled in text (CSV) conversion?

The HiLogger's text conversion process includes event numbers along with measured values. This is convenient when you need to later extract only marked data.

# <Example>


File name	WAVE0001	.CSV	
Title comm	nent		
Trigger Tin	########		
Ch	A 1 – 1	A1-2	A 1 = 3
Mode	Voltage	Voltage	Voltage
Range	10mV	10mV	10mV
Comment			
Scaling	OFF	OFF	OFF
Ratio	1.00E+00	1.00E+00	1.00E+00
Offset	0.00000E	+00" 0.0000	0.0E+00" 0.0
Time	1-1[V]	1-2[V]	1-3[V]
0.00E+00	-1.18E-04	-1.23E-04	-1.98E-04
5.00E-01	-1.19E-04	-1.22E-04	-1.97E-04
1.00E+00	-1.20E-04	-1.22E-04	-1.97E-04
1.50E+00	-1.20E-04	-1.21 E-04	-1.97E-04
2.00E+00	-1.21 E-04	-1.20E-04	-1.96E-04
2.50E+00	-1.23E-04	-1.18E-04	-1.96E-04
3.00E+00	-1.23E-04	-1.18E-04	-1.95E-04
3.50E+00	-1.24E-04	-1.16E-04	-1.94E-04
4.00E+00	-1.25E-04	-1.16E-04	-1.93E-04
4.50E+00	-1.27E-04	-1.15E-04	-1.93E-04
5.00E+00	-1.28E-04	-1.14E-04	-1.90E-04
5.50E+00	-1.30E-04	-1.12E-04	-1.89E-04
		-1.12E-04	

NOTE

The Logger Utility program's text conversion process does not include event mark information.

# **Searching Event Marks**

Any event mark can be found by searching.



4

Chapter 4 Observing Measurements and Data

You can set recording to start and stop under specific criteria (start/stop triggers), and to output alarm signals. You can also set specific times to start and stop recording, using the Timer function.

# **About Triggering**

Triggering is the process of controlling the start and stop of recording by specific signals or conditions (criteria). When recording is started or stopped by a specific signal, we say the trigger is "applied" or "triggering occurs".




In this manual, T indicates a "trigger point", as the time at which a trigger is applied.

Criteria can be specified for the following event trigger types.

Trigger Type	Description	Setting Screen	Ref.
Start Trigger	Recording starts when the specified Start Trigger criteria are satisfied.	[CH]/ [Trig & Alm]	(p. 100)
Stop Trigger	Recording stops when the specified Stop Trigger criteria are satisfied. When [Repeat] is enabled (set to [On]), recording restarts automatically.		(p. 100)
Trigger Source	Various trigger criteria can be combined with logical AND/OR operations for each channel.	[Trig & Alm]	(p. 105)
External Trigger	Triggering can be applied by an external signal at the EXT.TRIG input terminal.	[Irig & Aim]	(p. 106)
Pre-trigger	Records data acquired during a specified period prior to each trigger event.	[Trig & Alm]	(p. 108)
Alarm	An alarm signal can be output when any specified criteria are met.	[CH]/ [Trig & Alm]	(p. 109)
Timer	Records at a specified date and time.	[Setting]	(p. 115)

Set trigger criteria for individual channels on the Channel [CH] screen, and set trigger and alarm settings for all channels on the [Trig & Alm] screen (p. 114).




Chapter 5 Specifying Criteria for Measurements

#### **Triggering Measurement Start and Stop** 5.1


There are three ways to set the criteria to start and stop recording according to waveform slope.

Select whether to trigger at the rising or falling edge of the input signal.






Before setting trigger criteria, trigger functions need to be validated.




#### **Key Setting Procedure**



#### 5.1 Triggering Measurement Start and Stop

# **Setting Trigger Criteria**

# **Using Level Triggering**



Enter the signal level threshold at which to start or stop measuring, and whether triggering occurs on the upslope or downslope of the input signal.

Recording starts or stops when the signal crosses the specified threshold. The level value is an instantaneous (not rms) value.

Levels can be confirmed on the level monitor or on the Waveform/Numerical screen. Make trigger settings on the [CH] screen of the displayed channel.

See: "Key Setting Procedure" (p .101)

- Select [Level] as the start/stop trigger type.
- Select the input signal rising (↑) or falling (↓) edge setting option.

Setting options: ( \* : default setting)

- ↑\* Measurement starts (or stops) when the signal crosses the threshold on the upslope (rising edge ↑).
- Set the input signal level at which to start or stop measuring.




When scaling is enabled, the scaled value is also displayed.

Default setting: 0

#### Ranges and Trigger Resolution

Channels	Input type	Range	Resolution	
1-1 to 4-15	Voltage	10 mV f.s	0.01 mV	
		20 mV f.s	0.02 mV	
		100 mV f.s.	0.1 mV	
		200 mV f.s.	0.2 mV	
		1 V f.s.	0.001 V	
		2 V f.s.	0.002 V	
		10 V f.s.	0.01 V	
		20 V f.s.	0.02 V	
		100 V f.s.	0.1 V	
		1-5 V f.s.	0.01 V	
	Temperature	100°Cf.s	0.1°C	
	(thermocouple and RTD)	500°Cf.s.	0.5°C	
		2000°Cf.s.	2°C	
	Humidity	100% rh f.s	0.1% rh	
	Resistance	10 Ω f.s.	0.01 Ω	
		20 Ω f.s.	0.02 Ω	
		100 Ω f.s.	0.1 Ω	
		200 Ω f.s.	0.2 Ω	
P1 to P8	Count	-	1 c	
	Revolve	-	1 r/s	

#### **Using a Window Trigger**



An input signal level "window" within which recording will (or will not) occur can be defined by upper and lower threshold levels. You can select whether measurement starts or stops when the input signal level enters (In) or exits (Out) of this window.

Upper and lower thresholds can be verified in the monitor or on the Waveform screen. When scaling is enabled, the scaled threshold values are displayed.

Make trigger settings on the [CH] screen of the displayed chan-

See: "Key Setting Procedure" (p .101)


- Select [Window] as the start/stop trigger type.
- Select trigger timing (window type).

Setting options: ( \* : default setting)

Trigger when the input signal level enters the window defined by the upper/lower thresholds.

Trigger when the input signal level exits the win-Out dow defined by the upper/lower thresholds.


Enter the upper/lower threshold value.



when scaling is enabled.

#### 5.1 Triggering Measurement Start and Stop

#### **Using Logic Triggering**




Logic triggering is available when Logic is selected for pulse input channels (p. 61).

Triggering is controlled by the signal state and combination of logic input signal channels.

Select a trigger pattern (1, 0, or X) and AND/OR combining logic so that triggering occurs when the combined criteria are satisfied. Make trigger settings on the [CH] screen.

See: "Key Setting Procedure" (p .101)



#### Selecting Triggering Criteria (Trigger Source)


Enable the trigger function (set to On), select recording start/stop timing, and set trigger criteria.

Make these settings on the [Trig & Alm] screen.

See: "Key Setting Procedure" (p .101)




If trigger settings have been made on the [CH] screen, skip steps 1 and 2. (The settings in steps 1 and 2 are interlinked with those on the [CH] screen.)



# Triggering Criteria

teria must first become invalid once.


To apply a trigger when the upslope (↑) of the waveform crosses zero volts:



other crosses on the ups-


#### **Using External Triggering**

To use an external signal as a trigger source, make the following settings.



#### **Trigger Input Signals**

Voltage range	HIGH level: 2.5 to 5.0 V, LOW level: 0 to1 V
Pulse width	HIGH period: 1 ms or greater, LOW period 1 ms or greater
Maximum input voltage	DC0 to 10 V



#### 5.1 Triggering Measurement Start and Stop

#### Setting Criteria for Pre-Trigger Measuring (Pre-Trig)



When trigger timing is set to [Start] or to [Start/Stop], not only the waveform following the trigger can be measured, but a specified span of the waveform before triggering as well.

However, when trigger timing is set to [Stop], pre-trigger settings are disabled.

Make these settings on the [Trig & Alm] screen.

See: "Key Setting Procedure" (p .101)



Set the amount of time to record before each trigger event.

To also measure the waveform after triggering, the recording time must be set longer than the pre-trigger time. (See "Pre-Trigger and Recording Times" below.)



The maximum settable time is displayed.



Increment/decrement by 1

(when the recording interval is longer than 2 seconds, increment/decrement by one recording interval)



Increment/decrement by 10

(when the recording interval is longer than 10 seconds, increment/decrement by one recording interval)




HiLogger pre-trigger time can be set up to 99 days. Logger Utility settings of 100 days or more are reduced to 99 days when transferred to the HiLogger.

#### Difference between [Waiting for pre-trigger] and [Waiting for trigger]

When measurement is started, the specified pre-trigger length is recorded. This period is indicated as the [Waiting for pre-trigger].

After the specified pre-trigger length has been recorded, the period indicated as [Waiting for trigger] continues until a trigger occurs.

During the [Waiting for pre-trigger] interval, trigger criteria are ignored.




#### 5.2 **Alarm Output**

You can enable beep tones and an alarm output signal (for external use) for each input channel by setting its alarm criteria.

External alarm output requires connection to the external control terminals. See "9.3 Alarm Signal Output (Alarm Output)" (p. 163) for details.

# **Checking Alarm Criteria**


Alarm output status is displayed on the [Wave+Value], [Value+Cmnt], and [Value] Waveform/Numerical screens.



# 110

#### 5.2 Alarm Output


■ Some alarm settings are available on the Waveform/Numerical screens. On the [Gauge+Wave] Waveform/Numerical screen, the alarm beeper, alarm hold, and [ALARM CLR] (when alarm hold is enabled) can be set. (Alarm hold can only be set when measurement is stopped.)




#### **Alarm Settings**


Select alarm input channels on the [CH] screen, and specify alarm criteria on the [Trig & Alm] screen.

See: "Key Setting Procedure" (p .101)




#### 5.2 Alarm Output






■ An alarm can be output when thermocouple burn-out is detected.





# 5.3 Confirming All Trigger and Alarm Criteria Settings

You can view and change trigger and alarm criteria settings for all channels on the [Trig & Alm] screen.



Make these settings to record at a specific time. Recording can be set to repeat at specific intervals between the set start and stop times. Before setting, confirm that the HiLogger clock is set to the correct time. If not, reset the clock on the [System] screen (p. 158).






# 116


#### 5.4 Periodic (Timer) Measurements



Measurement operation depends on the trigger, timer, repeat recording (On/Off), and recording time settings.




## 5.5 Measurement with Trigger and Timer Functions



#### **About Dead time**

After a recording length has elapsed, some "dead time" is needed for internal processing before recording can resume. No measurement occurs during the dead time. So to avoid information loss, split data into files at a specified interval by enabling continuous recording ([Repeat]), and selecting [Split Save] for auto saving.



#### 5.6 **Trigger Setting Examples**

Following are examples of typical trigger settings.

Intended Measurement Objective	Ref. No. (next table)
Acquire data from when you press START until you press STOP	No.1
Acquire data for one minute after each time you press START	No.2
Acquire data at one-minute intervals for sixty minutes after you press START	No.3
When the temperature measured on CH1 exceeds 500°C, acquire data until you press STOP.	No.4
Acquire data from when you press <b>START</b> until the temperature measured on CH1 exceeds 500°C.	No.5
Acquire data from when the temperature measured on CH1 exceeds 500°C until it drops below 300°C.	No.6
Acquire data whenever the temperature measured on CH1 exceeds 500°C, until it drops below 300°C.	No.7
Acquire data for only one minute from when the temperature measured on CH1 exceeds $500^{\circ}\text{C}.$	No.8
Acquire data for one minute before and after the time when the temperature measured on CH1 exceeds $500^{\circ}\text{C}$ .	No.9
Acquire data from 9:00 to 17:00 on 6/17/2008.	No.10
Starting at 9:00 on 6/17/2008, acquire data for 24 hours/day, for one month.	No.11
Starting on 6/17/2008, acquire data continuously from 9:00 to 17:00 daily for one month.	No.12
Starting on 6/17/2008, acquire data for one hour at 9:00, 15:00, 21:00, and 3:00 daily for one month.	No.13

120

# 5.6 Trigger Setting Examples

	[Setting] Screen					[Trig & Alm] Screen			[CH] Screen	
No.	Timer	Repeat	Record time	Split Save	Trig Func	Timing	Trig Source	Pre- Trig	Start Trig.	Stop Trig.
1	Off	Off	[Cont.] On	Off	Off	-	-	-	-	-
2	Off	Off	[Cont.] Off 0h: 1min: 0s	Off	Off	-	-	-	-	-
3	Off	Off	[Cont.] Off 1h: 0min: 0s	On [Split Length] 1 min	Off	-	-	-	-	-
4	Off	Off	[Cont.] On	Off	On	[Start]	[Start] OR	-	[Cond] Level↑ [Level] 500°C	-
5	Off	Off	[Cont.] On	Off	On	[Stop]	[Stop] OR	-	-	[Cond] Level↑ [Level] 500°C
6	Off	Off	[Cont.] On	Off	On	[Start/ Stop]	[Start] OR [Stop] OR	-	[Cond] Level↓ [Level] 500°C	[Cond] Level↓ [Level] 300°C
7	Off	On	[Cont.] On	Off	On	[Start/ Stop]	[Start] OR [Stop] OR	-	[Cond] Level↓ [Level] 500°C	[Cond] Level↓ [Level] 300°C
8	Off	Off	[Cont.] Off 0h: 1min: 0s	Off	On	[Start]	[Start] OR	-	[Cond] Level ↑ [Level] 500°C	-
9	Off	Off	[Cont.] Off Oh: 2min: 0s	Off	On	[Start]	[Start] OR	1 m	[Cond] Level ↑ [Level] 500°C	-
10	[Start] On 08-6-17 9:0:0 [Stop] On 08-6-17 17:0:0 [Interval] Off	Off	[Cont.] On	Off	Off	-	-	-	-	-
11	[Start] On 08-6-17 9:0:0 [Stop] On 08-7-17 9:0:0 [Interval] Off	Off	[Cont.] On	On [Split Length] 1 day	Off	-	-	-	-	-
12	[Start] On 08-6-17 9:0:0 [Stop] On 08-7-17 9:0:0 [Interval] On 1 0:0:0	On	[Cont.] Off 8h: 0min: 0s	Off	Off	-	-	-	-	-
13	[Start] On 08-6-17 9:0:0 [Stop] On 08-7-17 9:0:0 [Interval] On 0 6:0:0	On	[Cont.] Off 1h: 0min: 0s	Off	Off	-	-	-	-	-

# Saving & Loading Data Chapter 6


HiLogger data can be saved to removable storage (optional CF card or USB flash drive). The CF card is designated drive "A:" and the USB flash drive is drive "B:".

See: "2.6 Inserting a CF Card or USB Flash Drive (when saving data)" (p. 45)

Data saved (in binary format) to removable storage can be reloaded into the HiLogger.

# 6.1 About Saving and Loading Data

When saving data, a folder named HIOKI\_LR8400 is created, and files are stored in the folder as follows.



6

Chapter 6 Saving & Loading Data

# 6.1 About Saving and Loading Data

O: Available/ x: Not Available

	File		File Name*5	Save		Load	
File Type	Format	Folder Name	(Auto-numbered from 1)	Auto	Man- ual	HiLog ger	PC
Setting Data	Binary	CONFIG	CONF0001.SET	×	0	0	×
Waveform Da-		DATA\(date)*4 (e.g.: 08-07-30)			0	0	0
ta*1	Text *2	DATA\(date)*4 (e.g.: 08-07-30)	WAVE0001.CSV *6	0	0	×	0
Numerical Calculation Results	Text *2	MEASUREMENT	MEAS0001.CSV *7	0	0	×	0
Captured Screen Image	BMP *3	PICTURE	SCR00001.BMP	×	0	0	0

\*1: Save waveform data in binary format if you intend to view it later in the HiLogger or on a PC with the supplied Logger Utility program. Waveform data and some measurement-related settings data are saved.

To save a waveform partially, specify a period by using A/B cursors before saving (p. 90). When the scaling function is set to enable, scaling information as well as raw data (non-converted data) in binary format are saved. When the data saved in the storage devices is loaded, the converted data will be displayed. The raw data can also be observed by resetting the scaling function to OFF.

- \*2: When opening a CSV file in a spreadsheet program, note that the number of rows that can be loaded at one time is limited (p. A8).
- \*3: BMP Format: This is a standard Windows graphics format. These files can be handled by many graphics programs.
- \*4: Date (YY-MM-DD) folders are automatically created inside the DATA folder.
- \*5: When saved manually. See "Appendix 3 File Naming" (p. A8) for file naming details.
- \*6: The TXT file extension is applied except when [Separator:Comma] is selected on the [System]
- \*7: When creating calculation-specific files, an underbar and a serial number ( n) is appended to the file name, e.g., MEAS0001\_1.CSV, MEAS0001\_2.CSV, etc.



Depending on file size and CF card capacity, each folder can store over 1,000 files. However, the file screen display is limited to a maximum of 1,000 files. Also, as more files are created, more time is needed to start and stop recording. We recommend setting measurement criteria so that the number of saved files stays below 1,000 whenever possible.

If power is off for more than 30 minutes, the data is lost.

Also, when Auto-Resume (p. 152) is enabled, measurement resumes automatically when power is restored, so previous measurement data is deleted.

To avoid data loss in such cases during long-term measurement, we recommend the following settings to prepare for power outages.

#### Preparation for power outages during long-term measurements

- •Connect the (optional) battery pack before starting (p. 30) Measurement can continue on battery power when mains power is lost.
- •Configure Auto Save beforehand (save [Waveform(realtime)], P.125) Data is periodically saved to removable storage. The HiLogger includes a large-value capacitor to provide power to save the most recent data and close the files when power fails.



If power is lost within about three minutes after power-on, files on the removable storage may be corrupted, and the device could be damaged. If a damaged storage device is used, files may fail to close within the allotted time, and data may be lost.

When [File Protection:High] is selected on the System screen, storage media is not recognized for three minutes after power-on, during which files may be inaccessible and could become corrupted.

See: "File Protection Level Setting" (p .153)

Although [CSV(realtime)] saving is possible, data is saved only as text, so waveforms cannot be displayed later by reloading into the HiLogger or by application programs. Note that the recording interval setting is limited (p. 125).

#### **Saving Data** 6.2

Basically, three methods are available for saving.

To save automatically while measuring

To save immediately upon pressing the **SAVE** 

To save selected contents

#### Auto Save

Measurement data is simultaneously saved during measurement. Calculation results are saved only after measurement is finished.

Make this setting before starting measurements.

Insert a removable storage

(p. 45)

[Setting] Screen

Set the Auto Save (p. 125)

Select what to save.

The following can be saved simultaneously:

- Waveform Data
- Numerical Calculation Results

Measurement

Saving proceeds automatically

Quick Save

Before saving, select the items to be saved on the [System] screen. These are saved immediately when you press SAVE. This is convenient for saving certain types of data, or when you want to save immediately while monitoring (p. 128).

Insert a removable storage (p. 45)

[System] Screen

Set the function of SAVE to [Quick Save] (p. 128)

Select what to save.\*

- Waveform Data
- Screen Image
- · Setting Data
- Numerical Calculation Results

Press SAVE after measuring.\*

(Saving is not possible while measuring.)

Save

\*: To save a waveform partially, specify a period by using A/B cursors. (Saving a waveform section is not available with Auto Save)(p. 90)

To save a screen image, display the desired screen before saving.

Select & Save

(Default setting)

Press **SAVE** to select and save the selected contents. No settings are needed before saving this way (p. 128).

Insert a removable storage (p. 45)

[System] Screen

Set the function of SAVE to [Select & Save] (p. 128)

Press SAVE after measuring (Saving is not possible while measuring.)

Save Dialog

Select what to save.\*

- Waveform Data
- · Screen Image
- · Setting Data
- Numerical Calculation Results

Press ENTER.

Save

# Automatic Saving (Waveform Data and Numerical Calculation Results)

When auto save is enabled before starting measurement, data can be automatically saved to removable storage during or after measurement.


The following types of measurement data can be auto-saved.


Saved Data	Settings	File Ex- tension	Description
Waveform	Waveform (realtime)	.MEM	During measurement, waveform data is saved in binary format. Conversion to text (CSV) format can be done later, so we suggest selecting Waveform(realtime) for typical operation.
Data Only	CSV (realtime) *2	.CSV*3	During measurement, waveform data is saved in text format. Saved data cannot be reloaded into the HiLogger or by the Logger Utility. However, this format is ideal for loading into spread-sheets like Excel.
Calculation Results Only *1	Calc (post meas.)	.CSV*3	Calculation results are saved after measurement. When [Repeat] recording is enabled (On), each measurement's calculation results are appended to the file. When [Split Calculation] is enabled (On), calculation results are appended at each save interval.
Both Wave- form Data and	Waveform +Calc	.MEM, .CSV*3	Waveform data is saved in binary format during measurement, and calculation results are saved at the end of measurement.
Calculation Results*1	CSV + Calc*2	.CSV*3, .CSV*3	Waveform data is saved in text format during measurement, and calculation results are saved at the end of measurement. Saved data cannot be reloaded into the HiLogger.

- \*1. Calculation must be enabled before starting measurement (p. 143).
- \*2. The recording interval setting is limited for [CSV(realtime)] and [CSV+Calc] according to the number of channels used.

For up to 15 channels (using U1-1 to U1-15), the recording interval must be longer than 50 ms For up to 30 channels (using U2-1 to U2-15), the recording interval must be longer than 100 ms For up to 45 channels (using U3-1 to U3-15), the recording interval must be longer than 200 ms. For up to 60 channels (using U4-1 to U4-15), the recording interval must be longer than 200 ms. To perform waveform calculations, the recording interval must be longer than 500 ms. (Pulse, logic, and alarm channels do not impose such limits.) Also, when opening a CSV file in a spreadsheet program, the number of rows that can be loaded is limited.


\*3. The TXT file extension is applied except when [Separator:Comma] is selected on the [System] screen.





# Replacing Removable Storage During Real-Time Saving

During real-time saving, removable storage can be replaced without interrupting measurement. This procedure describes replacing a USB flash drive.




- If a storage device is not replaced within two minutes after selecting "Yes" in the "Do you want to remove the USB memory/CF card?" confirmation dialog, data may overflow internal memory and be lost.
- If a storage device is replaced during real-time saving, data is saved to a new file.
- If measurement ends while the removable storage is ejected, even if a removal storage is then inserted, the remaining data is lost. In that case, when connected to a LAN, data can be read from the HiLogger via the HTTP function. See "10.4 Remote Measurement with the HTTP Server Function" (p. 188).

# Saving Manually (Waveform Data, Screen Images, Numerical Calculation Results)

Press **SAVE** to save data.



- Internal memory capacity limits saving to the most recent eight million data points. If you need to save more data points, enable real-time autosaving beforehand.
- Saving can only occur when measurement stops. Saving is not possible while measuring (both waveform data and screen images).



First select the saving method.

Choose [Select & Save] or [Quick Save].

# SAVE Key Settings

Setting options: ( \* : default setting)

Select & Pressing SAVE displays a dialog. Select the type of contents to be saved, and save the data.

Quick Save Pressing SAVE saves data according to the settings on the [System] screen.

See p. P.130 when selecting [Select & Save], and P.129 for [Quick Save].

## When you select [Quick Save] (to save data upon pressing SAVE)

Settings are displayed. Select contents to be saved.



Media

Select the priority save destination when [Quick Save] is selected.

Setting options: ( \* : default setting)

Save to the CF card first USB Memory Save to the USB flash drive first

Save Type Select the type of data to save.

Setting options: ( \* : default setting)

Waveform\* Save waveform data. Screen Image Save screen image.

**Setup File** Save setting configuration data. Calc Results Save numerical calculation results.

Calculation must be configured before saving numerical calculation results (p. 143).

**Format** 

(When [Waveform] is selected) Select the data format.

Setting options: ( \* : default setting)

Binary\* Select this format to be able to reload the saved data into the HiLogger, or so that it can be loaded into the Logger Utility **CSV** Select this format to save the data as a text file. This format is ideal for loading into spreadsheet programs like Excel.

Data saved in CSV format cannot be reloaded into the HiLogger or Logger Utility program. Fortunately, data saved in binary format can be later converted to text (CSV) format with the HiLogger or Logger Utility.

Span

(When [Waveform] is selected) Select the time span to be saved.

Setting options: ( \* : default setting)

oouning opnor	or ( radiaan detuing)
All*	Save all measured waveform data.
A-B	Save waveform data between A/B cursors.
Start-A	Save waveform data from the start of measurement to cursor A.
Start-B	Save waveform data from the start of measurement to cursor B.
A-End	Save waveform data from cursor A to the end of measurement.
B-End	Save waveform data from cursor B to the end of measurement.

- Before saving a partial waveform, specify the span to be saved (p. 90).
- When a save span is specified for calculation, the results are saved for the specified span.


#### **Executing a Save**

Press **SAVE** to immediately save data according to current settings.

#### When [Select & Save] is selected (to save after selecting setting contents)


Settings are the same as for Quick Save.

See: For details about the type, format, and span, see P.129, and for setting procedures, see P.131



- · When a save span is specified for calculation results, the results are saved for

Setting configurations can be saved as data files and later reloaded into the HiLogger when you need to make more measurements with the same settings. Up to ten setting configurations can be saved to internal memory, and more can be stored on the removal storage device.




Chapter 6 Saving & Loading Data

# 6.3 Loading Data on the HiLogger

Previously stored binary waveform data, captured screen images and saved setting configurations can be reloaded into the HiLogger (p. 121).

#### **Loading a Setting Configuration**

Setting configurations saved in the HiLogger's memory or on a removable storage can be reloaded.



#### **Automatically Loading Configuration Data (Auto Resume)**

Setting configuration data saved as a file named STARTUP.SET in the [HIOKI\_LR8400] - [CON-FIG] folder can be automatically reloaded at power-on.

When setting configurations are stored on both CF card and USB flash drive, the CF card has priority.


When [File Protection: High] is selected on the System screen, Auto Setup is not available.

6

Chapter 6 Saving & Loading Data


# **Loading Waveform Data and Screen Images**

Saved binary waveform data and screen images can be reloaded in the HiLogger.



#### When loading waveforms)


When the amount of data in a file to be loaded exceeds the internal memory capacity, you can specify a data point (number) at which to start loading ([Top of data num] in fig. below). The loadable data size shows the [Readable data num] (maximum number of data points) that can be loaded. This setting is not needed if the data to be loaded will fit in internal mem-




You can manage data stored on a removable storage in the HiLogger.

- •Format removable storage (p. 47)
- •Load a file (when the file is selected) (p. 132)
- •Move displayed folders (when the folder is selected) (p. 135)
- •Delete data (p. 136)
- •Rename files and folders (p. 137)
- •Copy data (p. 138)
- •Sort files (p. 139)

## Switching removable storage




# Viewing Folder Contents and the Parent Folder



Chapter 6 Saving & Loading Data

# **Deleting Data**


Folder and files on the removable storage can be deleted.





- To protect against inadvertent data loss, the HIOKI\_LR8400 and DATA folders cannot be deleted. If you need to delete one of these folders, rename it first.
- Read-only files can only be deleted with a PC.

Folders and files on a removable storage can be renamed. File names may consist of up to 26 regular characters.




6

Chapter 6 Saving & Loading Data


#### **Copying Data**

Files and folders can be copied between a CF card and USB flash drive.





- Folder copying is supported for up to eight hierarchical levels. Folders more than eight levels deep cannot be copied.
- A file cannot be copied if one with the same name already exists at the destination.




# 6.5 Transferring Data to a PC (USB Drive Mode)

Data saved to a CF card can be transferred to a PC using the supplied USB cable. Before connecting the USB cable to the HiLogger, set the communications interface setting to USB (p. 170), and select "USB Drive Mode" on the HiLogger.



- Refer to the Logger Utility Instruction Manual (on the supplied CD) to observe data using the Logger Utility program on a PC (p. 187).
- Data cannot be read from a USB flash drive in the HiLogger. To load files from a USB flash drive removed from the HiLogger, insert it into a USB slot on the PC.
- USB Drive Mode is not available with Windows 2000.


#### **Select the USB Drive Mode**



# $\triangle$ Caution

- Do not eject the CF card or pull out the USB cable during data transfer. Doing so would prevent proper data transfer.
- The HiLogger and PC should be connected to the same earth ground. If grounded separately, potential difference between the ground points can cause malfunctions or damage when connecting the USB cable.

Before connecting the USB cable to the HiLogger, select the USB Drive Mode on the [System] screen. Otherwise, the HiLogger's CF card cannot be accessed.



#### To exit USB Drive Mode

- 7 Click the Safely Remove Hardware (%) icon in the Windows notification area.
- $oldsymbol{2}$  Click the appropriate line "Safely remove USB Mass Storage Device? Drive(H:)" where H is the drive letter that Windows assigned to the HiLogger.
- $oldsymbol{\mathcal{S}}$  When "Safe to remove hardware" appears, click [X] or [OK].
- 4 Disconnect the USB cable.
- 5 Turn the HiLogger off and back on.



Chapter 6 Saving & Loading Data

# Calculate Average, Maximum, Minimum, and Etc.

Calculations can be applied to measured data. Six types of calculation are available, four of which can be applied at the same time.

Refer to "7.2 Numerical Value Calculation Expressions" (p. 148) for details of the calculation methods. You can specify the measurement time span over which calculations are to be applied (p. 147).

#### Types of calculations

Average value Average value of waveform data Peak value Peak-to-peak value of waveform data Maximum value Maximum value of waveform data Minimum value of waveform data Minimum value

 Time to maximum value Time elapsed from the start of measurement to the maximum value Time to minimum value Time elapsed from the start of measurement to the minimum value

Two methods are available for applying calculations, as follows.

## **Real-Time Calculation While Measuring (Auto Calculation)**

Configure numerical calculations before starting measurement. Performs calculations in real time while measuring (p. 144).

- · The latest calculated values can be viewed on the Wave/Numerical screen ([Wave+Calc] display).
- Calculated values can also be saved at specific intervals to a text (CSV) file.

WAVE/DATA FILE

(Setting Screen) Set Numerical Calculation to [On], and select the calculation types

To save calculation results automatically (Setting Screen) Enable Auto Save (p. 125)



Start and finish measuring

Observation

## Calculation after Measuring (Manual Calculation)

Configure numerical calculations after measurement (p. 146).

#### End of Measurement

WAVE/DATA FILE

(Setting Screen or Wave/Numerical Screen) Set Numerical Calculation to [On], and select the calculation types.

> WAVE/DATA SET FILE


(Wave/Numerical Screen) **Execute Calculations** 

Observation

Chapter 7 Numerical Calculations/Waveform Calculations


## 144


7.1 Calculate Average, Maximum, Minimum, and Etc.




## **Real-Time Calculation While Measuring (Auto Calculation)**

Calculations are automatically performed in real time while measuring.






# Calculation after Measuring (Manual Calculation) After measuring, configure and execute calculations.



After measuring, calculation can be applied to a specified time span. Make any other calculation settings before specifying the calculation time span (P.146, 1



Chapter 7 Numerical Calculations/Waveform Calculations

# 7.2 Numerical Value Calculation Expressions

Average	$AVE = \frac{1}{n} \sum_{i=1}^{n} di$	Obtains the average value of waveform data.  AVE: Average value  n: Data count  di: Data on channel number i		
Peak Value (P-P)	Maximum-value  Minimum-value  Peak value	Obtains the value of the difference (peak-to-peak value) between maximum and minimum values of waveform data.		
Maximum Value	Maximum value	Obtains the maximum value of waveform data.		
Minimum Value	Minimum	Obtains the minimum value of waveform data.		
Time to max- imum value	Start of Measurement Maximum value  Time to maximum value	Acquires the time (s) elapsed from the start of recording to maximum value. When there are two or more maxima, this value is the first to occur.		
Time to mini- mum value	Minimum value  Start of Measurement	Acquires the time (s) elapsed from the start of recording to minimum value. When there are two or more minima, this value is the first to occur.		
Interval Calculation (Auto Calconly, P.144)	When [On]  Start of End of Measurement  Reference Time  [Ref Time]  Start of End of Measurement  Reference Time  Start of End of Measurement	When [Split Save] is enabled ([On] or [Ref Time]), calculation results are saved at the specified interval.  When [On]: Set the [Split Length]. Calculation results for the specified time span are automatically saved.  When [Ref Time]: Set the [Ref Time] and [Split Length]. Calculation results starting from the reference time are automatically saved for the specified time span.		


#### Coefficient a x [CH A] (x, $\div$ , +, or -) coefficient b $\times$ [CH B] + coefficient c

(CH A and CH B may be any input channels' measurement data, selectable from CH1-1 to 4-15, P1 to P8, or waveform calculation result channels W1 to W29 ((reused as inputs, as long as the channel number is smaller than number of the final calculation result channel)). For example, to obtain results on W3, [CHA] and [CHB] can be set to W1 and W2, respectively.)

The above formula is set up beforehand, calculation result waveforms are displayed on the Waveform screen while measuring, and calculated values can be saved. Up to 30 calculation result waveform channels (W1 to W30) are available at once.


Waveform calculations cannot be performed after measurement.

## **Key Setting Procedure**




Chapter 7 Numerical Calculations/Waveform Calculations

#### 7.3 Waveform Calculations




The calculation formula can be entered on the [Conv/Calc] screen. The calculation formula entered for channel W1 can be copied to other channels (p. 74).



# **System Environment** Chapter 8 **Settings**


Settings affecting the clock, SAVE key operation and self testing are made from the [System] screen.



Abre to set the system of this unit.				
1	Operation Related Settings  Specify operating behavior when recovering from powe ages (Auto-Resume) (p. 152) Set the file protection level (p. 153)			
2	Screen and Key Related Settings	<ul> <li>Set backlight power saving (p. 153)</li> <li>Set backlight brightness (p. 154)</li> <li>Select black or white screen background (p. 154)</li> <li>Enable or disable the beeper (p. 154)</li> <li>Set the horizontal axis (time value display) (p. 155)</li> <li>Select display language (p. 155)</li> <li>Set start/stop confirmation message display (p. 155)</li> </ul>		
3	CSV File Saving	<ul> <li>Select CSV file data decimal and separator characters (p. 156)</li> <li>Select the sort order for numerical calculation results (p. 156)</li> <li>Setting How to Handle Date Data Stored in CSV Files (p. 157)</li> </ul>		
4	External Trigger Input	<ul><li>Select the external trigger function (p. 157)</li><li>Set alarm event marking (p. 157)</li></ul>		
5	Saving (SAVE key)	<ul> <li>Select the saving method for SAVE (p. 128)</li> <li>Select the type of data to save* (p. 129)</li> <li>Select save formats* (p. 129)</li> <li>Select the time span to save* (p. 129)</li> <li>*: Set when [Quick Save] is selected.</li> </ul>		
6	System-Related Settings	<ul><li>Set the clock (p. 158)</li><li>Reinitialize the HiLogger(p. 159)</li><li>Transfer data (p. 140)</li></ul>		
7	Self Testing	<ul> <li>KEY/LED test (p. 160)</li> <li>LCD test (p. 160)</li> <li>ROM/RAM test (p. 160)</li> <li>CF card test (p. 160)</li> <li>USB flash drive test (p. 160)</li> <li>Input unit test (p. 160)</li> </ul>		

#### 8.1 Operation Settings

## **Key Setting Procedure**



# 8.1 Operation Settings

# Using the Auto-Resume Function (Resume After Power Restoration)

If a power outage or other power loss causes an interruption in recording (while the LED on the left side of **START** is lit), you can automatically resume recording when the power is restored. If you are using triggers, the triggers are restored to the **[Waiting for trigger]** state.




When Auto-Resume is enabled, measurement data that was in internal memory before the outage is lost when measurement resumes. To retain measurement data from before an outage, disable Auto-Resume (set to Off)

To retain measurement data from before an outage and resume measuring automatically afterwards, enable Auto Save (p. 125).

# Start Backup

(Auto-Resume) Setting options:( \* : default setting)

Off\* Do not use the Auto-Resume Function.
On Use the Auto-Resume Function.



If power is lost within about three minutes after power-on, files on the removable storage may be corrupted, and the device could be damaged. These risks can be avoided by setting the file protection level to [High].

#### **File Protection**

Setting options:( \* : default setting)

Although removable storage is recognized and ready for recording immediately upon power-on, if power is lost within about three minutes after power-on, files on the removable storage may be corrupted, and the device could be dam-



High Removable storage is not recognized for three minutes after power-on (when data could be corrupted or the device damaged).



Auto-Setup is not available when [High] is selected (p. 132).

# **Screen Key Operation Settings**

## **Enabling and Disabling the Backlight Saver**

A backlight saver can be activated after a specified number of minutes during which no operation key is pressed. The backlight saver turns off the backlight of the LCD, prolonging the lifetime of the backlight by turning it off when not needed.

To deactivate the backlight saver, press any key. The operating screen appears again.

#### **Backlight** Saver

Setting options:( \* : default setting)

Disables the backlight saver function. Off\* The operating screen is always displayed. 1 min, 2 The backlight saver is activated if the specmin, 3 min, ified time is exceeded. 4 min, 5 min



- · Be aware that power is still consumed even when the backlight is off, so be sure to turn the HiLogger power switch off when not in use.
- · While the backlight saver is active, the HiLogger's measuring state is still indicated by the LED.

#### 8.2 Screen Key Operation Settings

See: "Key Setting Procedure" (p .152)

## **Adjust Backlight Brightness**

Backlight brightness can be selected from four levels. Lower brightness settings provide longer battery operating time.

Brightness

Backlight When the [Backlight Brightness] setting is selected, pressing **ENTER** repeated cycles through the four brightness levels.

Setting options:( \* : default setting)

100%\*, 70%, 40%, 25% (four-step brightness setting)



## Selecting Black or White Screen Background

The screen background can be set to black or white.






Black Back-

**Display Color** (Background Color)

Setting options:( \* : default setting)

Black\* Make background black. White Make background white.



# **Enabling or Disabling the Beeper**

The beeper can be set to sound when an error occurs.

#### **Beep Sound** (Beeper)

Setting options:( \* : default setting)

On\* Emit a beep sound on error messages (error and warning displays). Off Do not emit beep sound.





When the alarm beeper is enabled, no beep sounds when a warning or error occurs while measuring.

#### Selecting the Horizontal (Time) Axis Display

Select the display method for the horizontal axis at the bottom of the screen. This setting also determines the time display for data saved in CSV format.



#### **Time Disp** (Time Value Display)

Setting options:( \* : default setting)

trigger event.

Displays the time span from the start of measurement. If triggering is enabled, the displayed time span is from the last trigger event. **Date** Displays the date and time every ten divisions. Data Displays the number of data points from the Pts start of measurement. If triggering is enabled,

the displayed data points begin from the last



### Selecting the Display Language

Select the display language.

#### Language

Setting options:( \* : default setting)

English*	Display in English.	lime IIIsh
Japanese	Display in Japanese.	Language
French	Display in French	External Trig I

Chapter 8 System Environment Settings

# **Display of Start/Stop Confirmation Messages**


To help avoid operator errors, confirmation messages can be displayed when measurement is manually started or stopped.

Start/Stop message (Start/Stop Confirmation Messages)

Setting options:( \* : default setting)

Confirmation messages are not displayed. Pressing START and STOP start and stop measurement immediately. Confirmation messages are displayed. To On\* start or stop measurement, move the cursor

to "Yes" and press ENTER.



# 8.3 CSV File Saving Settings

See: "Key Setting Procedure" (p .152)


### **CSV File Data Decimal and Separator Characters**

Select decimal point and separator characters for CSV file data.

#### Decimal Mark (Decimal Point Character)

Setting options:( \* : default setting)


Dot*	Select the period character.
Comma	Select the comma character.



# Separator (Separator Character)

Setting options:( \* : default setting)

Comma*	Select the comma character.
Space	Select the space character.
Tab	Select the tab character.
Semicolon	Select the semicolon character.



# NOTE

The comma character cannot be selected for both decimal point and separator at the same time. By default, comma is the separator character, so it is not available as the decimal character. To select comma as the decimal character, first select a different separator character.

#### Select the sort order for numerical calculation results

Select whether to save numerical calculation results in a single or multiple CSV files

N-Calc. Data Saving (Sort order for numerical calculation results)

Setting options:( \* : default setting)

Single	Saves	numerical	calculation	results	in	а
file*	single f	ile.				
Split save	Saves		calculation	result	S	in
	manapi	J 11100.				



See: "Appendix 3 File Naming" (p. A8)

This section describes how to configure the handling of date data stored in CSV files.

Date set

Setting options:( \* : default setting) format

Date data is output using the following format: ' (apostrophe) YEAR (2 digits) - MONTH (2 digits) - DAY (2 digits) HOURS (2 digits): MINUTES (2 digits): SECONDS (2 digits). MILLISEC-ONDS (2 digits). This information is treated as a comment in Ex-

Split msec. Date data is output using the format, with sub-second time data

(unit: ms) is output separately: " (double quotation) YEAR (4 digits) - MONTH (2 digits) - DAY (2 digits) HOURS (2 digits) : MINUTES (2 digits): SECONDS (2 digits) " (double quotation). In Excel, sub-second time data is displayed in a separate column. This format is convenient when you wish to combine CSV data acquired from different instruments in Excel.

# **External Trigger Input Settings**

"Key Setting Procedure" (p .152)

## **Selecting the External Trigger Function**

Select the function of the EXT.TRIG input terminal.

**External Trig** 

(External Trigger Input) Setting options:( \* : default setting)

Triggering occurs when a signal is applied Trigger\* to the EXT.TRIG terminal.

**Event** An event mark is inserted into measurement data when a signal is applied to the EXT.TRIG terminal.

External Trig In LVEITE IIIATK TUT ATA -SAVE Key Operation

#### **Set Alarm Event Marking**

Selects whether an event mark is inserted when an alarm event occurs.

Event mark for

alarm (Alarm Event Marking)

Setting options:( \* : default setting)

Event marks are not inserted by alarm events.

On Event marks are inserted by alarm events.

Event mark for alarm AVE Kev Uperation


**Chapter 8 System Environment Settings** 

# 8.5 Making System Settings

#### **Setting the Date and Time**


The HiLogger is equipped with an auto-calendar, automatic leap year detection, and a 24-hour clock.

If the clock is not set to the correct time, measurement start time (start trigger time) and file date information will be incorrect. If this occurs, reset the clock.



The system is reset by pressing and holding STOP while turning the HiLogger POWER switch on.

See: About the factory default settings: "Appendix 6 List of Default Settings" (p. A11)




All Reset sets the communications interface to USB.

**Chapter 8 System Environment Settings** 

#### 8.5 Making System Settings

#### **Self-Test**

The following self tests are available. Results are displayed on the screen. If any faults are found, have the HiLogger repaired. Contact your dealer or Hioki representative.



Self-Test	Details
KEY/LED	Tests the keys and LEDs for correct operation.  After every key has been pressed, the KEY/LED check finishes.  Pressing START also tests whether the LED lights.  If you notice a malfunction, press START and STOP simultaneously to abort the test.
LCD	Tests the screen display (character test, gradation test, color test) The screen changes each time you press an operation key.  If the display screen seems abnormal, request repairs.
ROM/RAM	ROM/RAM Tests the HiLogger's internal memory (ROM and RAM)  If "NG" appears, request repairs.
CF card	Use only Hioki optional CF cards. Non-Hioki CF cards may be unable to provide proper read/write performance, in which case HiLogger performance cannot be guaranteed.
USB Memory	Tests whether the inserted USB flash drive is recognized by the HiLogger.
Unit Information	Displays the input unit configuration.


The external control terminals on the HiLogger support trigger signal input and out-

Be sure to read p. 41 to p. 43 for external control terminal connection details.

#### **External Trigger Input** 9.1

Triggering can be controlled by applying a signal from an external trigger source

This allows synchronous operation of multiple HiLoggers by parallel triggering (p. 164).



See "Using External Triggering"(p .106) for setting procedures and trigger signal details.


The external signal input function can be changed to insert event marks.

See: "Inserting Event Marks Using External Input Signals" (p.94)

Chapter 9 External Control

# 9.2 External Signal Output (Trigger Output)

You can output a signal when a trigger event occurs. This allows synchronous operation of multiple HiLoggers by parallel triggering (p. 164).



## **Trigger Output Signals**

Output signal	Open collector output (with voltage output), active LOW
Output voltage range	HIGH level: 4.0 to 5.0 V, LOW level: 0 to 0.5 V
Pulse width	LOW level: 10 ms or greater
Maximum input voltage	-20 to +30 V, 5 mA max, 200 mW max



NOTE

The signal is output even when triggering is not enabled. When triggering is not otherwise used, a trigger signal is output during measurement.

#### **Signal Output Procedure**

Connect the HiLogger's TRIG.OUT external control terminal to the external device to be triggered.


(See the connection procedure on p. 43)

When a trigger event occurs, a pulse wave changing from the HIGH level (4.0 to 5.0 V) to the LOW level (0 to 0.5 V) is output from the TRIG.OUT terminal.

This signal is output when alarm criteria are satisfied. Specify the desired alarm criteria.

See: "5.2 Alarm Output" (p. 109)


9.3




## **About the Alarm Output Signal**

Output signal	Open collector output (with voltage output), active LOW
Output voltage range	HIGH level: 4.0 to 5.0 V, LOW level: 0 to 0.5 V
Output Refresh	Every recording interval
Maximum switch rating	5 to 30 VDC, 200 mA

Below is a diagram showing the structure map of the HiLogger's alarm output circuit, and an example of a connection with the relay.





Example of an alarm output connection

## Signal Output Procedure

Connect the HiLogger's ALM external control terminals to the external devices.

(See the connection procedure on p. 41)

When the alarm criteria are satisfied, a Low level (0 to 0.5 V) signal is output.


# 9.4 Synchronous Measurements with Multiple HiLoggers




Although this function synchronizes the measurement start time of multiple HiLoggers to the external trigger signal, it does not synchronize actual sampling times.

Over long-term measurements, data acquisition times will differ because of sampling block scattering on each HiLogger.

Multiple HiLoggers can be synchronized using the external control terminals. Two synchronization methods are available, as follows.





# **Connection to a PC** (Communication) Chapter 10

Communication is available by connecting a PC to the HiLogger with an Ethernet or USB cable.

#### **Communication Features**

Item	LAN (100BASE-T)	USB	Ref.
Real-time measurements using the Logger Utility program (on the supplied CD)	0	0	10.3 (p. 187)
Remote operation by HTTP server	O*2	Х	10.4 (p. 188)
Manual data acquisition by FTP server	0	Х	10.5 (p. 193)
Auto send data to FTP client	O*1	Х	10.6 (p. 196)
Automatic e-mail sending (notification)	O*1	Х	10.7 (p. 216)
Measuring with a program created with Visual Basic	O*3	0	10.8 (p. 223)

- \*1: Not available while measuring with the Logger Utility.
- \*2 : Not available while measuring with the Logger Utility or a program created with Visual Basic or other languages.
- \*3: Data cannot be transferred in real time with recording intervals shorter than one second. Use the Logger Utility for shorter recording intervals However, data recorded at shorter intervals can still be obtained after measurement has fin-


To create a program, see the Communications Command Instruction Manual on the supplied

# 10.1 USB Settings and Connections

Connect the USB cable to a PC to transfer data from the CF card (p. 140), and to communicate using the Logger Utility (p. 187), or communications commands (p. 223).

## 1. HiLogger Setting

Select the HiLogger's USB interface.



#### 2. Installing the USB Driver

Install the USB driver as described below before connecting to the Memory HiLogger via USB cable.

If you install the USB driver in Windows2000, the USB Drive Mode of the device will be disabled.

#### Install the driver.

Run [SetupDriver32.msi] in the CD-R. If [Logger Utility] is already installed, run the CD from the following location. [c:\Program Files\HIOKI\LoggerUtility\Driver\SetupDriver32.msi]

If you are using the WindowsVista/7 64bit version: Run [SetupDriver64.msi] in the CD-R. If Logger Utility is already installed, run the CD from the following location. [c:\Program Files\HIOKI\LoggerUtility\Driver\SetupDriver64.msi]

Depending on the environment, the dialog box may take some time to appear so please wait till it does so.

Click [Next].



3 Check [Everyone] and Click [Next] to start installing.

When you want to change the installation destination

Click[Browse...] to change the folder to install into. Normally, there is no need to change.



# 168

#### 10.1 USB Settings and Connections

Click [Next] to start installing.



Installing



#### For WindowsXP

During the installation, a message saying that the software has not passed Windows Logo testing will appear a few times, click [Continue Anyway] to continue installing.




#### For WindowsVista/7

When a dialog box requesting your permission to continue the program appears, click [Continue].



5 When installation is completed and the dialog box appears, click [Close] to exit.

This completes the driver installation.





Chapter 10 Connection to a PC (Communication)

10

#### 10.1 USB Settings and Connections

#### 3. Connecting the HiLogger to a PC


Connect the HiLogger to the PC with a USB cable. Install the USB driver before communicating with the HiLogger the first time (p. 167).

# 

To avoid electric shock hazards, turn off all devices before connecting or disconnecting the USB cable.

# 

- Do not pull out the USB cable during data transfer. Doing so would prevent proper data transfer.
- The HiLogger and PC should be connected to the same earth ground. If grounded separately, potential difference between the ground points can cause malfunctions or damage when connecting the USB cable.



The first time the computer is connected to the HiLogger, follow the next steps to recognize the HiLogger.

#### For Windows2000/Vista/7

The HiLogger is automatically recognized, and preparations to use the device are complete.

7 A [Found New Hardware Wizard] dialog box will appear and the new hardware detection wizard will begin.

Check [No, not this time] and click [Next].

Check [Install the software automatically (Recommended)] and click [Next].

Please wait while the driver is being installed.

3 Click [Continue Anyway].

A message saying that the software has not passed Windows Logo testing will appear a few times, click [Continue Anyway] to continue installing.









Chapter 10 Connection to a PC (Communication)

# 172

#### 10.1 USB Settings and Connections

✓ When installation is completed and the dialog box appears, click [Close] to exit.

This completes the driver installation.



## **Features Available After USB Setting and Connection**

#### Transferring Data from a CF Card to a PC (p. 140)

Data saved to a CF card can be transferred to a PC.

#### Controlling by Logger Utility(p. 187)

The supplied Logger Utility program provides PC control over HiLogger settings and measurement data recording and observing.

#### Controlling by Communications Commands (p. 223)

See the Communications Command Instruction Manual on the supplied application CD.

## 4. Installing the Logger Utility Program

The Logger Utility program can be installed from the supplied CD, or you can download the latest version from the Hioki web site.

## **Operating Environment Confirmation and Preparation**

Verify operating environment compatibility before installing.

#### **Operating Environment**

os	Windows 2000 (with SP4 or later) Windows XP (with SP2 or later) Windows Vista Windows 7
CPU	Pentium III (500 MHz) or better
Monitor Resolution	1024 x 768 dots or better
Internet Explorer	6.0 or better
Memory	At least 512 MB
Interface	An available Ethernet or USB receptacle

#### Preparation

Insert the supplied CD in the PC's CD-ROM drive, or unzip the downloaded application program file on the PC.

#### 174

#### 10.1 USB Settings and Connections

#### **Installation Procedure**

Install the Logger Utility with this procedure. This explanation is for installing the software on Windows XP. The messages displayed may differ slightly depending on other operation system or settings you are using.

#### Important

If you are running software such as antivirus software, be sure to end the software before you start the installation. The installation may not be performed properly if antivirus software is running.


#### 1 Start up Windows.

Exit all running applications.

#### ) Insert the included CD into the PC's CD-ROM drive.

The installer run automatically. If the installer do not start, execute [setup.exe] from the CD-ROM drive.

In Vista, Although the dialog which ask for installation permission of application, click [Allow].



Welcome to the HIOKI Logger Utility Setup Wizard will guide you through the steps required to install HIDKI Logger Utility on you Click


The end user license agreement is displayed.

Read the EULA, then select [Agree], and click [Next].


The installation destination folder can be changed on this screen.

If you are not changing the installation destination, click [Next].

To change the installation destination, click [Browse] to select another folder.



Chapter 10 Connection to a PC (Communication)



C:\Program Files\HIDKI\Logger Utility\

# 176

#### 10.1 USB Settings and Connections

∠ Click [Next] to start installing.

Installation starts.

click [Cancel].

lation.



Note: After the Logger Utility has been installed, the CD can be removed from the drive.

# **Uninstalling the Logger Utility**

When the Logger Utility is no longer needed, uninstall it with the following procedure.

7 From the Windows Start menu, select the [Control Panel], and double click [Add or Remove Programs].



2 From the list of installed programs, select [Logger Utility], and remove it. You are returned to the [Add or Remove Programs] screen. Settings files are not deleted during uninstall, so if no longer needed, delete them manually.

# 10.2 LAN Settings and Connections (Before connecting to the network)

The required settings are different, depending on whether the HiLogger is to be connected to an existing network or directly to a PC.



Always make LAN settings before connecting to the network. If you change settings while connected to the network, IP addresses may overlap or invalid address data may flow over the network.

#### Things to Check Before Making Settings

The required settings are different, depending on whether the HiLogger is to be connected to an existing network or whether a new network consisting only of the HiLogger and one PC is to be configured.

#### When Connecting the HiLogger to an Existing Network

The following items must be assigned in advance by your network administrator. Be sure that there is no conflict with other devices.

Whether to use DHCP	Yes/No
The host name and address of the HiLogger	Subnet mask: (When DHCP is used, the IP address and subnet mask are not required)
Gateway	Whether to use a gateway: Yes/No IP Address (when used): (When DHCP is used, the gateway address is obtained from the DHCP server, so it does not need to be specified here)
The TCP/IP port number to use	X (default 880x) (Specify at least the three most significant digits of the four- or five-digit port number. The least significant digit (0 to 9) is reserved for use by the HiLogger. Specify when the default 8800 to 8809 cannot be used.)

#### When Configuring a New Network with a PC and This HiLogger

(Using as Local Network Without External Connections)

If there is not administrator for your network, or if you have been entrusted with settings, the following addresses are recommended.

# (Settings example)

IP Address

PC : 192.168.1.1 First recorder : 192.168.1.2

Second recorder: 192.168.1.3 and so on, in sequence.

1

Host name : Any name (However, must be unique)

Subnet mask : 255.255.255.0
Gateway : Off

Gateway : Off DHCP : Off Port number : 880X

#### **Setting Items**

*: Dynamic Host Configuration Protocol	DHCP is a protocol that allows devices to automatically obtain and set their own IP addresses.  If you enable DHCP and there is a DHCP server operating in the same network, the HiLogger's IP address, subnet mask, and gateway can be obtained and set automatically.
Host Name	This is a name that identifies the HiLogger on the network. Assign a host name that is different from the names of all other devices. This HiLogger does not support dynamic DNS, the name that you set is not registered with a DNS server.
IP Address	This is an address that identifies an individual device on a network. Assign an address that is different from the addresses of all other devices. If DHCP is enabled, the address is assigned automatically by the DHCP server.
Subnet Mask	This is a setting used to divide an IP address shown to the network into a network address and a host address. Use the same subnet mask for all devices in the same network. If DHCP is enabled, the subnet mask is assigned automatically by the DHCP server.
Use Gateway IP Address	For network connections: When your PC (or the communicating device) is on another network than this HiLogger, set this to [On] and specify the gateway device. When the PC is on the same network, this is usually set to the same address as the default gateway in the PC communications settings.

#### **Authorization User Name and Password**

These are used when you login to the HiLogger by FTP, or use a PC browser (with the authorization setting set to on).

When authorization is enabled, login is not possible unless a correct user name and password are entered. This setting is recommended if you wish to restrict the users who can access the HiLogger.

The "Password" item is displayed as "\*\*\*\*\*\*\*\*.

Valid characters: Alphabetic characters and symbols

If you want to allow anyone to access, or you wish to login as "anonymous" with a FTP client, leave the user name and password fields blank.

#### 10.2 LAN Settings and Connections (Before connecting to the network)

#### 1. PC Network Setup


The setup procedure is the same when connecting one HiLogger to the PC as it is when connecting multiple HiLoggers to the PC through a hub.


These instructions presume a network configured as follows.

IP Address 192.168.1.0/24 (network address)
(or, enter 192.168.1.1 as a private IP address\*)

Subnet Mask 255.255.255.0

\*: Although the IP address can be freely set, a private IP address is normally more secure.





#### 10.2 LAN Settings and Connections (Before connecting to the network)

	,		
Setting Item	ıs		
Host Name			
	Setting options		
	Up to 12 characters (e.g., LOGGER)		
DHCP	Enable or disable DHCP function.		
	When enabled, the IP address and subnet mask are obtained automatically.		
	Setting options: ( * : default setting)		
	Off* Disable DHCP. On Enable DHCP.		
	CII Eliable DIICP.		
IP Address	Set the HiLogger's IP address.		
	Setting options		
	(where _ is 0 to 255, e.g., 192.168.1.2)		
Subnet Mask	Set the subnet mask.		
	Setting options		
	(where _ is 0 to 255, e.g., 255.255.255.0)		
Port	Set the TCD/ID part number to be used by the Hill agger		
(Port Number)	Set the TCP/IP port number to be used by the HiLogger. The lowest digit is reserved for use by the HiLogger.		
(1 011 1141111001)	Setting options		
	(where _ is 0 to 9, e.g., 880X)		
	(Wildia _ 18 a 18 a 7, a.g., accord)		
Gateway IP	Set this only when [Gateway] is enabled.		
	Set the IP address of the gateway device.		
	Setting options		
	(where _ is 0 to 255)		
DNS	Salast whather to use DNS		
DNS			
	Setting options: ( * : default setting)		
	OFF* Do not use DNS.		
	ON Use DNS.		
DNS IP	Set this only when [DNS] is enabled.		
	Set the DNS server's IP address.		
	Setting options		
	(where _ is 0 to 255)		

#### **Setting Example**

#### Connecting one HiLogger to one PC

Host Name	LOGGER
DHCP	Off
IP Address	192.168.1.2
Subnet Mask	255.255.255.0
Port	880X
Gateway	Off
DNS	Off

#### When connecting multiple HiLoggers to a PC through a hub

This example is a local area network with no external connection. We recommend using only private IP addresses. As below, make sure that no host names or IP addresses are duplicated.

First HiLogger		
Host Name	LOGGER1	
IP Address	192.168.1.2	
Second HiLogger		
Host Name	LOGGER2	
IP Address	192.168.1.3	
Third HiLogger		
Host Name	LOGGER3	
IP Address	192.168.1.4	
Common Sottings		

DHCP	Off
Subnet Mask	255.255.255.0
Gateway	Off
Port	880X

NOTE

LAN communications with a PC require that the HiLogger is first set correctly.


10.2 LAN Settings and Connections (Before connecting to the network)

#### 3. Connecting the HiLogger to a PC


Connect the HiLogger to the PC with an Ethernet cable.


# **<b><b><u>M</u>WARNING**

Always turn both devices OFF when connecting and disconnecting a LAN cable. Otherwise, an electric shock accident may occur.



If the green LED does not light when connected to the LAN, the HiLogger or connected device may be damaged, or the cable may be faulty.





# Features Available After LAN Setting and Connection

#### Using the Logger Utility (p. 187)

The supplied Logger Utility program provides PC control over HiLogger settings and measurement data recording, and data observation.

#### Remote Operation (p. 188)

A standard web browser such as Internet Explorer (IE) can be used to make HiLogger settings and to control remote data acquisition and on-screen monitoring (HTTP server functions).

#### Downloading Data to a PC (p. 193)

The HiLogger's internal memory data and files on its removable storage can be transferred to a PC running an FTP client.

#### Automatically Sending Data to a PC (p. 196)

Binary files auto saved by the HiLogger to removable storage can be automatically sent to other network clients, or to a remote FTP server. Use the FTP client function.

#### Sending E-Mail (p. 216)

E-Mail notifications can be automatically sent from the HiLogger when start or stop triggering occurs, and when an alarm, power outage recovery, memory-full or removable-storage-full event occurs. It can be sent to a network device, remote PC, or mail-capable cell phone via an SMTP mail server.

#### Controlling by Communications Commands (p. 223)

See the Communications Command Instruction Manual on the supplied application CD.

10

#### 10.2 LAN Settings and Connections (Before connecting to the network)

#### When LAN Communication Fails

#### Confirm cable connections.

When connecting one HiLogger to one PC, use the supplied cross-over adapter with the 9642 LAN Cable.

In case of poor connection, disconnect and reconnect the cable to clean the contacts. When connecting the cable, the green LED on the HiLogger's LAN jack should light.

#### Confirm the PC's IP address.

Click [Run...] on the Windows Start menu (or select [All Programs]-[Accessories]-[Comand Prompt]) and enter "ipconfig /all" to confirm the IP address of the network interface, subnet mask, and gateway address.

#### If settings are incorrect:

Refer to "1. PC Network Setup"(p. 180) to reset the IP address.

#### Confirm communication between the HiLogger and PC.

After confirming that the IP addresses of the HiLogger and PC are correct, use the "ping" utility to test data transfer.

1.From the Start menu, select [All Programs]-[Accessories]-[Comand Prompt].

2.(at the blinking cursor)

Enter "ping XXX.XXX.X.X"(the IP address of the host device to test).

Alternatively, the host name can be entered if its IP address is assigned by DNS.

For example, if the HiLogger's IP address is 192.168.1.2, enter "ping 192.168.1.2" and press Enter.

The following display text indicates normal operation. The "time" is the communication response time.

Pinging 192.168.1.2 with 32 bytes of data:

```
Reply from 192.168.1.2: bytes=32 time<10ms TTL=32 Reply from 192.168.1.2: bytes=32 time<10ms TTL=32 Reply from 192.168.1.2: bytes=32 time<10ms TTL=32 Reply from 192.168.1.2: bytes=32 time=1ms TTL=32
```

The following display text indicates communications failure.


Recheck cable connections.

Pinging 192.168.1.2 with 32 bytes of data:

```
Reply from 192.168.1.2: Host is down.
```

#### **Using the Logger Utility** 10.3

The supplied Logger Utility program provides PC control over HiLogger settings and measurement data recording, and data observation.




For details such as Logger Utility operating instructions, read the instruction manual (PDF file) provided on the CD.

#### Starting and Ending Logger Utility

#### Starting Logger Utility

From the Start Menu of Windows, click [All Programs]-[HIOKI]-[Logger Utility] -[Logger Utility].



#### **Ending Logger Utility**

Click [Exit Application] from the File menu of the main screen. Alternatively, you can click the [x] close button at the top right of the main screen.

# 10.4 Remote Measurement with the HTTP Server Function

The HiLogger includes an HTTP server function for remote data acquisition and onscreen monitoring using a web browser such as Internet Explorer (IE).



- LAN settings and connections must be made before using the HTTP server function for remote measurements (p. 178).
- The HTTP server function is not available while measuring using the Logger Utility program.

#### Displaying the Main Page

- 1 Start IE.
- Enter the HiLogger's address (e.g., http://192.168.1.2) in the [Address] field.

The main page appears.



- 3 Select [SETTING PAGE].
- 4 (When the [FTP/HTTP Authentication] HiLogger setting is enabled)
  Enter the user name and password, and press the [SET].

To avoid unauthorized access to HTTP functions, we recommend securing connections with a user name and password on the Communications Settings display of the HiLogger's [System] screen. FTP/HTTP authentication can be disabled when frequent access to the HiLogger from multiple PCs is necessary.

See: "Enable [FTP/HTTP Authentication]."(p. 212)



- Microsoft InternetExplorer Version 5 or later is recommended as the browser. Set the security level to "Medium" or "Medium-high", and invalidate the pop-up block.
- Remote operation by HTTP is not available while measuring with the Logger Utility or a Visual Basic program.

#### If no HTTP screen is displayed

- 1. Perform this procedure.
  - (1) Click [Tools]-[Internet Options] to display IE settings.
  - (2) On the [Advanced] tab, under HTTP 1.1 settings, enable [Use HTTP1.1] and disable [Use HTTP1.1 through proxy connections].
  - (3) On the [Connections] tab, click [LAN Settings], and disable [Use a proxy server].
- 2. LAN communications may not be possible. See "When LAN Communication Fails" (p. 186).

#### What if the Remote Operating Screen does not appear?


Java may not be installed. To operate the HiLogger from a web browser, depending on the PC's software environment, Java may need to be installed separately. In that case, download and install JRE (Java Runtime Environment) from the Java web page.

Attempting to operate the HiLogger by multiple PCs at the same time may result in unintended actions. Remote control operation should be performed from only one PC at a time. If the security setting blocks the Remote Operating Screen from being displayed, add the address of Model LR8400 (for example, http://192.168.1.2/DISP.HTM) to the exception site list.

For more information, visit "Manage the Exception Site List" of the Java website at http:// docs.oracle.com/javase/7/docs/technotes/quides/jweb/security/exception\_site\_list.html. http://docs.oracle.com/javase/7/docs/technotes/guides/jweb/security/ exception\_site\_list.html

#### **Remote Operating**

Click [REMOTE CONTROL] to view the current HiLogger screen in the web browser.




- The displayed panel emulates the HiLogger's. Click the keys with the mouse to operate.
- Screen refresh time can be selected from Off, or 2, 10, or 60 seconds. Refreshing the screen also refreshes the on/off state of the Start LED.
- The emulated screen can be enlarged or reduced.

#### 10.4 Remote Measurement with the HTTP Server Function

#### Start/Stop Measurement

Click [START/STOP] to display this screen.



Click the buttons to operate.


# **Viewing Current Measurement Values**

Click [CURRENT DATA DISP] to display current measurements.



- While measuring, you can monitor numerical data acquired from each channel at every recording interval. Screen refresh time can be selected from Off, or 5, 10, or 60 seconds.
- When measurement is stopped, instantaneous input data from each channel is displayed.
- · You can select which input unit to display.

Click [MEMORY DATA GET] to display this screen.



NOTE

Data acquired into the HiLogger's internal memory cannot be accessed while measuring. It is possible only after measurement stops.

#### When acquiring optional range data

- 1 Specify the time span of data to acquire, and click the SET button.
- Under [GET PART SET], click [BIN DATA], [TXT DATA], or [TO MS-EXCEL].

#### When acquiring all data


Under [GET ALL IN MEMORY], click [BIN DATA], [TXT DATA], or [DATA TO MS-EXCEL].

Setting options:

BIN DATA	Acquires data in binary format.
TXT DATA	Acquires data in text format.
TO MS-EXCEL, DATA TO MS- EXCEL	Send data to Excel. Useful for creating graphics.

#### **Setting Comments**

Click [COMMENT SET] to display this screen.



- · Comments for each channel can be simply entered from the web browser. Enter a comment, and click the [SET] button.
- · You can select another input unit for setting.




- Comments cannot be changed while measuring.
- Please input 8-bit ASCII characters, the HiLogger can not display other characters.

# 10.5 Transferring Data to a PC with the FTP **Server Function**

FTP (File Transfer Protocol) is used for file transfers within a network. The HiLogger's FTP server function works with an FTP client running on a PC to transfer HiLogger data files from internal memory and removable storage to the PC.


- 1 Start IE to display the Settings screen (p. 188).
- Click [DATA GET BY FTP].

This screen is displayed.



**Click [FTP DATA GET FROM CARD & MEMORY].** 

The HiLogger's CF card, USB flash drive, and internal memory file folders are listed.



[CF] indicates the CF card, [USB] the flash drive, and [MEMORY] indicates internal HiLogger memory.

#### 10.5 Transferring Data to a PC with the FTP Server Function



- Entering just the HiLogger's IP address (e.g., ftp://192.168.1.2) in a browser such as IE displays the CF card, USB flash drive, and internal memory file folders.
- Internal memory data cannot be transferred while measuring. It is accessible when measurement stops. Files containing either current or previously saved data (real-time, CSV, and calculation results) are inaccessible while measuring.
- When [FTP/HTTP Authentication] is enabled, enter the required user name and password, and press the [SET] button.

See: We recommend restricting file access with a user name and password to avoid unauthorized access. "Enable [FTP/HTTP Authentication]."(p. 212)

#### Open a folder.



5 Select a file, and [Copy To Folder].



- The FTP server of the HiLogger allows only one connection at a time. More than one PC cannot access the server simultaneously.
- If no command is sent from a PC for more than one minute after connecting to the FTP server, the FTP may disconnect the PC. Reconnect the FTP.
- The FTP connection may fail after disconnecting and attempting to reconnect. In this case, disconnect again and wait for one minute before reconnecting.
- During real-time, auto, or manual saving, and when deleting files, creating or deleting folders, or renaming, formatting, or loading files on the HiLogger, only file transfers are possible from the FTP client.
- If an FTP transfer is writing to removable storage when auto saving starts or numerical calculations are saved, FTP operation is suspended during data saving.
- When measurement ends during an FTP transfer, the transfer may be suspended during data saving.
- Before inserting or removing a removal storage, terminate the FTP connection.
- Although the HiLogger's removable storage can be externally accessed using FTP, avoid other HiLogger operations such as using telnet at the same time. Otherwise, unintended operations could occur.
- With IE, the refresh date of files may not match those of the main HiLog-
- With IE, previously obtained data can be retained in temporary internet files, and may be reloaded in place of the latest data. If the HiLogger's data has been refreshed, restart IE before using FTP. (A free alternative to IE is FFFTP.)

#### Restricting FTP Server Connections (FTP Authentication)

[FTP/HTTP Authentication] Setting (p. 212).

Anonymous authentication allows unrestricted access to the HiLogger's FTP server by all network devices.

To restrict access to the FTP server, enable FTP/HTTP authentication and set a user name and password.

We recommend restricting file access with a user name and password to avoid unauthorized use.

Files auto saved by the HiLogger to removable storage can be automatically sent to other network clients, or to a remote FTP server.



- Set Auto Save to Waveform (realtime), CSV (realtime), Waveform+Calc, or CSV+Calc.
- · Calculated values are not transferred automatically.
- To save or transfer data periodically, set the Split Save setting to Periodic.
- To continue saving or transferring data even when the CF card becomes full, select Overwrite Oldest Save.

See: "Automatic Saving (Waveform Data and Numerical Calculation Results)"(p. 125)

- For the FTP client to control auto sending of data, the IP address of the FTP server PC must be specified.
- The Windows FTP server function can be used. Enter and register the HiLogger user name and password in the FTP server. For details about the Windows FTP server, see Internet Information Services (IIS) in Windows Help.
- •Free programs such as FileZilla Server can be used in place of Windows FTP server.

#### **General Procedure**

- 1 LAN Settings and Connections (p. 178)
- Set up the FTP server on the PC (p. 197)
- 3 Enable FTP auto sending on the HiLogger (p. 211 to p. 214)
- Configure auto saving (p. 125).
- 5 Start measuring with the HiLogger When auto saving a file on removable storage, the file is also sent automatically to the FTP server PC.
- 6 Check communication status (p. 215)

### Setting Up an FTP Server on a PC

This section describes how to set up an FTP server on a PC using Windows XP and Windows 7 as the examples.



- The necessary settings may differ depending on the environment. Refer to the FTP server's help as necessary or consult with your network administrator.
- You will need Windows administrator privileges in order to make these settings.


(Windows Home Edition does not include an FTP server. Instead use FileZilla Server or another freeware alternative.)

#### Windows7

7 Select [Programs] under [Control Panel].




Select [Turn Windows features on or off].



10

3 On Windows, click the [+] button to the left of [Internet Information Services] to expand the list of functions.
Click the [+] button to the left of [FTP Server] and check [FTP Service]. Click the [+] button to the left of [Web Management Tools] and check [IIS Management Console].
Click [OK].




This completes the installation of the FTP server.


#### Configuring the FTP server

✓ Select the [System and Security] control panel.





6 Select [Internet Information Services (IIS) Manager] .



7 Select [Internet Information Services (IIS) Manager] from [AdministrativeTools].




10

Chapter 10 Connection to a PC (Communication)

NOTE

Communications may be blocked depending on the settings for software (for example, a firewall)
Used to protect the computer.

Enter the site information and click the [Next] button.
Use an FTP site name such as [ftp]. Set the directory into which you wish to save data from the FTP client as the content directory.



O Configure the bind and SSL settings and click the [Next] button.


Configure the settings as follows:

Bind settings IP address: All Unassigned

Port: 21

Start FTP site automatically: Check

SSL: No SSL




Configure the settings as follows:

Authentication: Basic Authorization: All users

Permissions: Check both Read and Write.

This completes the configuration of the FTP server.




Traffic of FTP is validated by a firewall.

# 11 Select [System and Security] from [Control Panel]




12 Select [Windows Firewall]



#### 13 Select [Advanced settings]




# 14 Select [FTP Server (FTP Traffic-In)] from [Inbound Rules] Properties




# 15 On the [FTP Server (FTP Traffic-In)], Select [Enable]






#### Setting the users that will access the server


17 Select [Administrative Tools] from Control Panel



18 Select [Computer Management]




7 Right-click on local users and group users to display the menu and select [New User].



20 Set the user and click the [Create] button.
Set the username and password and select the [Password never expires] check box.




21 Confirm that the set-up logger is registered as the user, and close the dialog.




22 Open C:\inetpub, right-click [ftproot], and then, select [Properties].



23 Select [Edit] of [Users] from [Security].



24 Open [Properties] of ftproot, Select [Edit] of [Users] from [Security].




Above, a setup of FTP of Windows 7 is an end.

You can use the FTP server by using the created username and password.

#### WindowsXP Professional


1 In the [Control Panel], select [Add or Remove Programs].




Select [Add/Remove Windows Components].




3 Select [Internet Information Services (IIS)], and then [Details].






5 Click [Next].
At this point, your Windows XP CD is requested.




6 Click [Finish].




When installation is finished, the [InetPub] folder is created.



7 In the [Control Panel], select [Administrative Tools].



8 Select [Internet Information Services].




O Select [Default FTP Site], and right click to select [Properties].




10 For the IP Address, select [(All Unassigned)].



11 On the [Home Directory] tab, select [Read], [Write], and [Log visits], and click [OK].



12 Back in the [Administrative Tools], select [Computer Management].




13 In [Local Users and Groups], select [Users] then right click in the right pane and select [New User].




#### 10.6 Auto Sending Data using the FTP Client Function

14 Enter a user name, full name, password and confirmation (e.g., "logger"), and click [Create].




The created [logger] user is registered.




This completes FTP setup on the PC.

This example illustrates sending data to an FTP server with address 192.168.1.1.




### **Key Setting Procedure**



Chapter 10 Connection to a PC (Communication)

10

#### 10.6 Auto Sending Data using the FTP Client Function



## **Setting Items**

**FTP Server** Enter the name of the data sending FTP server.

Setting options

Up to 32 characters

**IP Address** Enter the IP address of the data sending FTP server.

This is the IP address of the PC acting as the FTP server.

Setting options

\_.\_.\_ (where \_ is 0 to 255, e.g., 192.168.1.1)

User Name Enter the FTP server logon user name.

This is the user name of the HiLogger registered with the FTP server.

Setting options

Up to 32 characters (e.g., LOGGER)

Password Enter the FTP server logon password.

This is the password of the HiLogger registered with the FTP server.

Setting options

Up to 32 characters (e.g., LOGGER)

The password is displayed as "\*\*\*...\*\*\*" (32 asterisks (\*)).

**Save Directory** Specify the destination folder for saving data on the FTP server.

Setting options

Up to 32 characters(e.g., abc)

Append identifier to file name Select identifiers to be prepended to file names.

Setting options

Host Name Include the host name in the names of files sent to the FTP

server.

IP Address Include the IP address in the names of files sent to the FTP

Date Include a timestamp in the names of files sent to the FTP

server. Examples

Host Name: LOGGER IP Address: 192.168.1.2 Date: '10-04-01 08:30:05

Auto Save file name: AUTO0001.MEM

When the host name, IP address, and time are set as above, the file name is LOGGER\_192-168-1-2\_100401-083005\_AUTO0001.MEM. Identification is


possible when using multiple HiLoggers.

PASV Mode Switch it ON when using PASV mode during communication.

Chapter 10 Connection to a PC (Communication)

# 214

#### 10.6 Auto Sending Data using the FTP Client Function



#### **Data Transfer Timing**

To calculate: transfer time (s) = file size (KB) / transfer speed (KB/s) + transfer preparation time (s).

See "Appendix 5 Binary File Size Calculation" ( $\Rightarrow$  p. A10) for file size information. Typical transfer speed is 300KB/s, and typical transfer preparation time is 3 s.

Example: For a 3MB (3,000KB) file, Transfer time = 3,000KB / 300 (KB/s) + 3 (s) = 10 + 3 (s) = 13 (s) The communication status can be checked as follows.

The status of all FTP file transfers, the number already sent, the number that failed to send, and the number of unsent files are displayed.

Status values are reset to zero by the following:

- When pressing **START** to start measuring
- · When changing LAN-related settings



For example, Total 10, Sent (Finish) 7, Failed (Miss) 1, and Unsent (Not Yet) 2

Here, ten FTP transfers were initiated, seven of which were sent, one of which failed, and two of which are waiting to be sent.

# 10.7 Sending E-Mail

E-mail notifications can be automatically sent from the HiLogger when start or stop triggering occurs during measurement, and when an alarm, power outage recovery, memory-full or removable-storage-full event occurs. Notifications can be sent to a network device, remote PC, or e-mail-supporting cell phone via an SMTP mail server. Register up to three recipient addresses.




Frequent alarm events can generate excessive e-mails. In this case, enable Alarm Hold to limit notifications to the first alarm event on each channel. (See Alarm Hold Settings on p. 111 .)

#### **General Procedure**


- 1 LAN Settings and Connections (p. 178)
- HiLogger E-Mail Settings (p. 217)
- 3 Testing E-Mailing (p. 220)
- 4 Start Measuring with the HiLogger E-mail is sent by the mail server when a trigger or alarm event occurs.
- 5 Confirming E-Mail Sending Status (p. 221)


# **HiLogger E-Mail Settings**

This example illustrates sending mail from HiLogger logger@xyz.xx.xx to a cell phone (or PC) with address abc@xyz.xx.xx via SMTP mail server 192.168.1.100 when a Start trigger occurs.



#### **Key Setting Procedure**





## **Setting Items**

**Mail Server** Enter the mail server name. Specifies the SMTP mail server.

Setting options

Up to 32 characters.

**IP Address** Set the IP address of the mail server. Specifies the SMTP mail server.

Setting options

\_.\_.\_ (where \_ is 0 to 255, e.g., 192.168.1.100)

IP / Port Set the port address of the mail server. Default is port 25.

Setting options

1 to 65535

Sender Enter the sender's e-mail address.

**Address** Setting options

> Up to 32 characters. (e.g., logger@xyz.xx.xx)

Sender Name Enter the sender's name.

Setting options

Up to 32 characters. (e.g., logger)

**Subject** Enter the subject for mail notifications.

Setting options

Up to 32 characters. (e.g., logger\_mail)

Enter the text for mail notifications. Message

Setting options

Up to 32 characters. (e.g., E-mail from logger)

Attach data Enable/disable attachment of measurement data (Data sends only when

Start trigger, Stop trigger, or alarm event occurs).

Setting options: ( \* : default setting)

Do not attach measurement data to e-mail. On Attach measurement data to e-mail.

# **Testing E-Mailing** Start Bup Select [Mail Transfer Test]. Mem Full Card Full 0 / 25 Apply Sends a test e-mail. On Finish If the e-mailing test fails, check your HiLogger e-mailing settings. If the e-mailing test succeeds, you can start measurement.

NOTE

If more than 30 unsent mails accumulate, the oldest is marked as failed, and cannot be sent. Unsent mail is deleted whenever measurement starts.

#### **E-Mail Sending Timing**

Each e-mail should take about one second.


#### **Checking Mail Communication Status**

The mail communication status can be checked as follows.

The status of all mail transfers, the number already sent, the number that failed to send, and the number of unsent files are displayed.

Status values are reset to zero by the following:

- When pressing **START** to start measuring
- · When changing LAN-related settings



For example, Total 10, Sent (Finish) 7, Failed (Miss) 1, and Unsent (Not Yet) 2


Here, ten e-mails were initiated, seven of which were sent, one of which failed, and two of which are waiting to be sent.

10

#### **E-Mail Sending Authentication**

The HiLogger supports "POP before SMTP" and "SMTP" for mail sending authentication. Set as needed.

The SMTP authentication is available in the firmware version 1.27 or later.



# **10.8 About Communications Commands**

Communications commands can be used to control the HiLogger remotely by connecting it to a PC with a USB or Ethernet cable.

This description applies only to HiLogger settings, and does not describe the communications commands themselves. For details about the communications commands, see the supplied Logger Utility CD. Communications command descriptions are provided in HTML format.


These can be viewed by the following procedure.

- Insert the supplied CD in the PC's CD-ROM drive.
- Click index.htm in the LR8400 folder.

See "10.1 USB Settings and Connections" (p. 166) for the USB settings and connection procedures.

See "10.2 LAN Settings and Connections (Before connecting to the network)" (p. 178) for the LAN settings and connection procedures.

# **Configuring Communications Command Operation**



# Specifications Chapter

Models LR8400-20, LR8401-20, and LR8402-20 are distinguished by the input units installed at the factory.

Model	UNIT1	UNIT2
LR8400-20	Voltage/Temp Unit	Voltage/Temp Unit
LR8401-20	Universal Unit	Universal Unit
LR8402-20	Universal Unit	Voltage/Temp Unit

# 11.1 LR8400-20, LR8401-20, LR8402-20 Memory **HiLogger Specifications**

### (1) General Specifications

#### **Basic Specifications**

Period of guaranteed accuracy	1 year
Internal memory	8 MWords volatile RAM (SDRAM)
Clock functions	Auto calendar, auto leap year judgment, 24-hour timer
Clock accuracy	±3 s/day (@23°C)
Timebase accuracy	±0.2 s/day while measuring (@23°C, 73.4°F)
Backup battery life	Approx. five years for clock and settings (@23°C, 73.4°F)
Operating environment	Indoors, Pollution degree 2, up to 2000 m (6562-ft.) ASL
Operating temperature and humidity	0 to 40°C (32 to 104°F), 80% RH or less (non-condensating) (temperature variation range is 10 to 40°C (50 to 104°F))
Conditions of guaranteed accuracy	After 30 minutes warm-up The 50/60 Hz cut-off setting is selected (see the Cut-Off Frequency Table)
Temperature and humidity range for guaranteed accuracy	Temperature 23±5°C (73±9°F), Humidity 80% RH or less (non-condensating)
Storage temperature and humidity	Temperature -10 to 60°C (14 to 140°F), Humidity 80% RH or less (noncondensating)
Dielectric strength	3.0 kVAC for 1 minute (between each input channel and chassis) 350 VAC for 15 seconds (between input channels)
Dimensions	Approx. 272W × 182.4H × 66.5D mm (10.71"W × 7.18"H × 2.62"D) (without projections) Approx. 272W × 234.8H × 66.5D mm (10.71"W × 9.24"H × 2.62"D) (with two input units, without projections)
Mass	Approx. 1.8 kg (63.5 oz.) (LR8400-20, without 370 g battery pack) Approx. 2.6 kg (91.7 oz.) (LR8400 with two LR8500s, without 370 g battery pack)

# 226

### 11.1 LR8400-20, LR8401-20, LR8402-20 Memory HiLogger Specifications

### **Basic Specifications**

Applicable Standards	Safety EN61010 EMC EN61326 Class A, EN61000-3-2, EN61000-3-3	
Vibration endurance	JIS D 1601:1995 5.3(1), Category 1: Vehicle, Condition: Category A equiv. (45 m/s2 oscillating acceleration on X-axis for 4 h, and on Y- and Z-axes for 2 h)	
External control terminals	External trigger input, trigger output, four alarm channel outputs, ground, +12 V output (@100 mA max.)	

### **External Storage**

CF card	
Slot	CompactFlash specification compliant, 1 slot
Card capacities	Hioki 9727 (256MB), 9728 (512MB), 9729 (1GB), 9830 (2GB)
Data formats	FAT, FAT32
USB flash drive	Connector: Series A receptacle
CF card/USB flash drive common functions	Files and folders can be copied between drives.

#### **Communications Functions**

Connector RJ-45  LAN Function • Data acquisition and ity	measurement criteria setting with the Logger Util- ment by communications commands by FTP server (from HiLogger memory or remov-
LAN Function  • Data acquisition and ity	ment by communications commands
ity	ment by communications commands
Setting and measurer	
	by FTP server (from HiLogger memory or remov-
<ul> <li>Manual file transfer b able storage).</li> </ul>	
	FTP client (periodically transfer binary files from uring or after measurement)
	ITTP server (remote control, start/stop measure- it values, data acquisition to memory, FTP file intry)
	upon start/stop triggering, alarm events, power when internal memory or removable storage is
USB Interface	
USB standard USB2.0 compliant High	ı Speed
Connector Series-mini B receptacl	le
• Data acquisition and ity	measurement criteria setting with the Logger Util-
<ul> <li>Setting and measurer</li> </ul>	ment by communications commands
USB Drive Mode (to t	transfer data from CF card to a PC)

#### **Power source**

AC adapter	9418-15 AC Adapter (supplies 12 V DC ±10%)
Rated supply voltage	100 to 240 VAC (Voltage fluctuations of $\pm 10\%$ from the rated supply voltage are taken into account)
Rated supply frequency	50/60 Hz
Battery	Z1000 Battery Pack (The AC Adapter has priority when connected)
External Power	10 to 28 VDC (voltage variation range is 12 to 16 V)
Power consumption	
Typical power consumption	With 9418-15 AC adapter or other 12 V DC external power, without battery pack w/LCD max. brightness: 7 VA (HiLogger only) w/LCD backlight off: 6 VA (HiLogger only)
Maximum rated power	When using the 9418-15 AC adapter: 70 VA (including the AC adapter), 24 VA (HiLogger only) When using an external DC16 V power source: 24 VA (when battery is charged, and w/LCD max. blightness) When using a Z1000 Battery Pack 7 VA (w/LCD max. brightness)
Continuous operating time	When using Model Z1000 Battery Pack, approx. 5 hours (Backlight brightness 25%, @23°C, 73.4°F)
Charging function	With the Z1000 Battery Pack installed and the AC Adapter connected Quick charging time: Approx. 3 hours (@23°C, 73.4°F)

# 228

### 11.1 LR8400-20, LR8401-20, LR8402-20 Memory HiLogger Specifications

### **Trigger Function**

33		
Trigger method	Digital comparison	
Trigger modes	Single or continuous	
Trigger timing	Start, stop, start&stop	
Trigger source		
Analog input	30 channels (U1-1 to U2 additional input units	2-15), or up to 60 channels (U1-1 to U4-15) with
Integrated pulse input	ut 8 channels (P1-P8)	
Digital input	8 channels (L1-L8)	
External trigger	Trigger on external input signal rising or falling edge (selectable).	
	Rising :	triggers upon transition from 0 to 1.0 V (LOW) to 2.5 to 5.0 V (HIGH).
	Falling :	triggers upon transition from 2.5 to 5.0 V (HIGH) to 0 to 1.0 V (LOW), or when the external trigger terminal is shorted to a GND terminal.
	Trigger input voltage: range	0 to 10 VDC
	External trigger filter:	On/Off
	Minimum response : pulse width	H period 2.5 ms or greater, L period 2.5 ms or greater
	Trigger input termi: : nals	M3 screw type terminal
Timer trigger Set year, month, day, hour, minute, and second		our, minute, and second
Trigger criteria	AND or OR of each trigger source	
	<ul> <li>Trigger criteria can be set for each channel.</li> </ul>	
	Free-running when all	are Off
Trigger types analog* and pulse		
Level Trigger	Triggering occurs when	the signal rises (or falls) through a specified value.
Window Trigger	Triggering occurs when window defined by upper	the input signal level enters or exits the amplitude er/lower thresholds.
Trigger types digital		
Pattern Mask Trigger	Trigger when signals m (where X is "ignore")	atch the pattern mask (1, 0, and X)
Trigger level resolution		: 10 divisions) evolution 1/n (where n = pulses/rev)
Pre-trigger	Time span setting (any Settable with real-time s	
Trigger output	Open-collector output (v Pulse Width: at least 10	with 5 V output, Active Low)
	i dioo viidini di lodoi 10	

#### **Alarm Output**

Alarm Output Channels	Four, non-isolated (Common GND with HiLogger)
Output settings	Output occurs when the logical sum (OR) or product (AND) of alarm trigger sources is true.
Alarm source	
Analog input	30 channels (U1-1 to U2-15), or up to 60 channels (U1-1 to U4-15) with additional input units $$
Integrated pulse in- put	8 channels (P1-P8)
Digital input	8 channels (L1-L8)
Thermocouple burn- out	When thermocouple burn-out detection is enabled
Alarm types analog* and pulse	
Level	An alarm is output by input rising above or falling below a preset level
Window	An alarm is output by input crossing into or out of a window defined by preset upper and lower trigger levels
Trigger types digital	
Pattern Mask Alarm	Alarm when signals match the pattern mask (1, 0, and X) (where X is "ignore")
Alarm level resolution	(Analog) 0.1%f.s. (f.s. = 10 divisions) (Pulse) Integration 1c, revolution 1/n (where n = pulses/rev)
Latch setting	Alarm output can be set to be held (latched), or not.
Cancel Hold	Enable Alarm Hold to latch alarm output without stopping measurement.
Beeper	Built-in beeper On/Off
Output form	Open-collector output (with 5 V pull-up, active low)
Maximum switch rating	5 to 30 VDC, 200 mA
Output refresh	At every recording interval

Chapter 11 Specifications

#### (2) Measurement Functions

#### Measurement

Recording interval	10ms*1, 20ms*2, 50ms*3, 100ms, 200ms, 500ms, 1s, 2s, 5s, 10s, 20s, 30s, 1min, 2min, 5min, 10min, 20min, 30min, 1h
Recording length (time span)	Set continuous recording Off or On. When Off, any time can be set.
Repeating Measure- ment Recording	Set Off or On. When On, measurement repeats at the set recording interval.
Recording Data Quantity	Analog recording n channels: 8 M/n data values
Waveform storage	The most recent 8 million data values (one analog channel recording time, or 8 M / n values for n channels) are stored in internal memory (n = number of analog channels + pulse channels $\times$ 2 + digital channels $\times$ 1 + alarm channels $\times$ 5 words) Data retained in memory can be observed by backward scrolling.
Measurement data backup	Data is retained for about 30 minutes after power-off (except when powered off while writing to removable storage, or within five minutes after power-on)

- \*1: Settable for up to 15 channels (U1-1 to -15) when thermocouple burn-out is disabled.
- \*2: Settable for up to 30 channels (up to U2-1 to U2-15) when thermocouple burn-out disabled, or up to 15 channels (U1-1 to U1-15) when enabled.
- \*3: Settable for up to 60 channels (up to U3-1 to -15 and U4-1 to -15) when thermocouple burn-out is disabled, or up to 30 channels (U2-1 to -15) when enabled.

### Display

Display Screen Selec- tion (Hybrid display config- urations)	<ul> <li>Simultaneous waveform, gauge and setting display</li> <li>Waveform display</li> <li>Simultaneous waveform and numerical value display</li> <li>Simultaneous numerical value and comment display</li> <li>Numerical value display</li> <li>Simultaneous waveforms and numerical calculation results display</li> <li>Waveform and A/B cursor values displayed at the same time</li> </ul>
Waveform colors	24 colors
Waveform compres- sion and magnification	
Horizontal axis (time axis)	100ms, 200ms, 500ms, 1s, 2s, 5s, 10s, 20s, 30s, 1min, 2min, 5min, 10min, 20min, 30min, 1h, 2h, 5h, 10h, 12h, 1day /divisions
Vertical axis (voltage axis)	Select by position or upper/lower limits  • When selecting by position, magnification can be x 100, x 50, x 20, x 10, x 5, x 2, x 1, or x 1/2. 0 Position: Set between -50% and 150% (at 1X magnification)  • When selected by upper/lower limits, specify the limit values.
Waveform scrolling	Time-axis scrolling is available by left/right arrow keys while measuring and when measurement stops (waveform drawing period).  These keys make large jumps
Jump function	Selects the displayed span of the waveform.

Monitor function	Confirm instantaneous values and waveforms without recording data.
	(Monitoring is performed while triggering.)
Save	
Save destination	CF card or USB flash drive selectable
Auto save	Waveform data and interval calculation results (real-time saving) Numerical calculation results other than interval calculations (after measurement saving)
Real-time saving	<ul> <li>Saves waveform data in binary or CSV format to selected removable storage about once per minute (for slower recording intervals, saves every interval).</li> <li>Real-time saving to removable storage is possible while communicating with the Logger Utility.</li> </ul>
Split Save	Selectable Off, On or Periodic
On	Saves data split into separate files from measurement start, at the set interval.
Periodic	Saves data split into separate files from a set reference time (within 24 hours), at the set interval.
Overwriting save	Selectable Off or On
On	Deletes the oldest file to save the newest file when removable storage becomes full.
Remove external media	During real-time saving, press a button, confirm the displayed message, and remove the storage media.  When the removable media is re-inserted, data retained in internal memory is saved continuously to a separate file.
Data protection	When a power outage occurs during real-time saving, the file is closed before shutdown.  When battery charge is depleted during battery operation, the file is closed.
Manual saving	Press <b>SAVE</b> to save. Select <b>SAVE</b> operation from selection or immediate saving. For immediate saving, select the save type, format, and time span.
Save types	Setting criteria, waveform data (binary format), waveform data (CSV format), numerical calculation results, screen captures (compressed bitmap format)
Reloading data	Up to 8 million data values can be saved in binary format to a specified location. (one analog channel recording time, or 8 M / n values for n channels)

#### **Calculations**

Numerical calculations		
No. of calculations	Six calculations are available at the same time	
Calculations	Average value, peak value, maximum value, Time to maximum value, minimum value, Time to minimum value	

#### Calculations

Calculation time span Applies calculations to all data in internal memory, or to the time-span (After measuring) specified by A/B cursors. Calculation time span Applies calculations to all data in internal memory, or to the time-span (While measuring) specified by A/B cursors. Interval calculation: Calculates and displays the latest results at the specified interval: 1, 2, 5, 10, 20, or 30 minutes, or 1, 2, 5, 10, or 12 hours, or one day. Auto saving calcula- After measuring, the most recent calculation results are automatically tion results saved in TXT format to removable storage. Saves real-time calculation results in TXT format to removable storage at the specified interval. **Waveform calculations** Calculate sum, difference, product, and quotient between channels, with **Calculation Method** calculated results displayed as channels Z1 to Z30 (valid only while mea-Auto saving calcula- Saved in real time with a channel's waveform data. tion results

#### **Other Functions**

Event mark function	
Search function	Displays the waveform before and after a specified event mark.
Event mark insertion	<ol> <li>When pressing START while measuring</li> <li>When pressing the on-screen [Make Mark] button.</li> <li>When a signal is applied to the external trigger input terminal (External Trigger and Exclusive settings on the System screen)</li> <li>When an alarm event occurs (can be enabled/disabled)</li> </ol>
No. of Marks	Up to 100 per measurement
Cursor measurement functions	
Cursor measure- ment	Time difference between A/B cursors, potential difference, potential at each cursor, time
Cursor display	Select All or Selected channels
Cursor movement	Select A, B, or Both (simultaneous)
Cursor types	Select trace, vertical, or horizontal
Scalling function	Scaling can be set for each channel Selectable from Ratio or 2-Point setting methods
Fahrenheit display	Scaling can be set to display Fahrenheit (F) when English language is selected.
Inter-Channel compensation function	The value measured on UNIT1, CH1 can be applied as the scaling value (only to other channels with the same input type and range).
Comment entry	Titles and comments can be entered for each channel.

#### (3) Inputs

No. of	Input	Channels
--------	-------	----------

Analog

Up to two measurement input units (LR8500 Voltage/Temp Unit or LR8501 Universal Unit) can be added (for up to 60 channels). 8 channels (each channel selectable for pulse or digital input)

#### **Analog input**

Pulse/Digital

Terminal block M3 screw type terminal block (2 terminals per channel) Terminal block

cover mounting\*1

Push-button terminals (4 terminals per channel) Terminal block cover

mounting \*2

Maximum input volt- DC ±100 V \*3

age

250 VDC\*1 Max. inter-channel

voltage

300 VDC\*2(However, RTD and resistance channels are not isolated.)

300 VAC, DC (between each input channel and chassis)\*3 Maximum rated volt-

Measurement category II\*3 age to earth

Anticipated transient overvoltage 2500 V\*3

Measurement object Voltage\*3

Thermocouple (K, J, E, T, N, R, S, B, W)\*3

RTDs (Pt100, JPt100)

(Connection: 3- or 4-wire configuration, Measurement current: 1 mA)\*2 Resistance (Connection: 4-wire configuration, Measurement current: 1 mA)\*2

Humidity (Only with Hioki Z2000 Humidity Sensor)\*3

\*1: LR8500 Voltage/Temp Unit only, \*2: LR8501 Universal Unit only,

\*3: With both LR8500 Voltage/Temp Unit or LR8501 Universal Unit


234

Measurement ranges
/Measurable Range
/Resolution
/Measurement accu-
racy

Measurement			Max. Res-		Measure-
Object	Type	Range	olution	Measurable Range	ment accu-
Object			Olution		racy
		10 mVf.s.	500 nV	-10 mV to 10 mV	± 10 μV
		20 mVf.s.	1 μV	-20 mV to 20 mV	± 20 μV
		100 mVf.s.	5 μV	-100 mV to 100 mV	± 100 μV
		200 mVf.s.	10 μV	-200 mV to 200 mV	± 200 μV
Voltage		1 Vf.s.	50 μV	-1 V to 1 V	± 1 mV
voltage		2 Vf.s.	100 μV	-2 V to 2 V	± 2 mV
		10 Vf.s.	500 μV	-10 V to 10 V	± 10 mV
		20 Vf.s.	1 mV	-20 V to 20 V	± 20 mV
		100 Vf.s.	5 mV	-100 V to 100 V	± 100 mV
		1-5 Vf.s.	500 μV	1 V to 5 V	± 10 mV
		100°Cf.s.	0.01°C	-100 to 0°C or less	±0.8°C
		100 Ci.s.	0.01	0 to 100°C	±0.6°C
				-200 to -100°C or less	±1.5°C
	K*1	500° <b>C</b> f.s.	0.05°C	-100 to 0°C or less	±0.8°C
				0 to 500°C	±0.6°C
		2000°Cf.s.	0.1°C	-200 to -100°C or less	±1.5°C
		2000 01.5.	0.1 C	-100 to 1350°C	±0.8°C
		100°Cf.s.	0.01°C	-100 to 0°C or less	±0.8°C
		100 Ci.s.	0.01 C	0 to 100°C	±0.6°C
				-200 to -100°C or less	±1.0°C
	J *1	500° <b>C</b> f.s.	0.05°C	-100 to 0°C or less	±0.8°C
	J			0 to 500°C	±0.6°C
				-200 to -100°C or less	±1.0°C
		2000°Cf.s.	0.1°C	-100 to 0°C or less	±0.8°C
				0 to 1200°C	±0.6°C
		100°Cf.s.	0.01°C	-100 to 0°C or less	±0.8°C
		100°Cf.s.	0.01 °C	0 to 100°C	±0.6°C
	E*1			-200 to -100°C or less	±1.0°C
		500° <b>C</b> f.s.	0.05°C	-100 to 0°C or less	±0.8°C
				0 to 500°C	±0.6°C
				-200 to -100°C or less	±1.0°C
Thermocouple		2000°Cf.s.	0.1°C	-100 to 0°C or less	±0.8°C
(not including				0 to 1000°C	±0.6°C
RJC accuracy)		100°Cf.s.	0.01°C	-100 to 0°C or less	±0.8°C
*1: JIS C 1602-		100°Cf.s.	0.01 °C	0 to 100°C	±0.6°C
1995, IEC584				-200 to -100°C or less	±1.5°C
	T*1	500° <b>C</b> f.s.	0.05°C	-100 to 0°C or less	±0.8°C
	1 .			0 to 400°C	±0.6°C
				-200 to -100°C or less	±1.5°C
		2000°Cf.s.	0.1°C	-100 to 0°C or less	±0.8°C
				0 to 400°C	±0.6°C
		100°Cf.s.	0.0100	-100 to 0°C or less	±1.2°C
		IUU CT.S.	0.01°C	0 to 100°C	±1.0°C
				-200 to -100°C or less	±2.2°C
	N*1	500°Cf.s.	0.05°C	-100 to 0°C or less	±1.2°C
	N .			0 to 500°C	±1.0°C
				-200 to -100°C or less	±2.2°C
		2000°Cf.s.	0.1°C	-100 to 0°C or less	±1.2°C
				0 to 1300°C	±1.0°C
		100°Cf.s.	0.01°C	0 to 100°C	±4.5°C
				0 to 100°C or less	±4.5°C
		500°Cf.s.	0.05°C	100 to 300°C or less	±3.0°C
	R*1			300 to 500°C	±2.2°C
				0 to 100°C or less	±4.5°C
		2000°Cf.s.	0.1°C	100 to 300°C or less	±3.0°C
				300 to 1700°C	±2.2°C
		1	1	1	1

Measurement ranges
/Measurable Range
/Resolution
/Measurement accu-
racv

Measurement Object	Туре	Range	Max. Res- olution	Measurable Range	Measure- ment accu- racy
		100°Cf.s.	0.01°C	0 to 100°C	±4.5°C
				0 to 100°C or less	±4.5°C
		500°Cf.s.	0.05°C	100 to 300°C or less	±3.0°C
Thermocouple	S*1			300 to 500°C	±2.2°C
(not including				0 to 100°C or less	±4.5°C
RJC accuracy) *1: JIS C 1602- 1995. IEC584		2000°Cf.s.	0.1°C	100 to 300°C or less	±3.0°C
				300 to 1700°C	±2.2°C
		500°Cf.s.	0.05°C	400 to 500°C	±5.5°C
*2: ASTM E-	B*1			400 to 600°C or less	±5.5°C
988-96	Ь	2000°Cf.s.	0.1°C	600 to 1000°C or less	±3.8°C
900-90				1000 to 1800°C	±2.5°C
	W*2	100°Cf.s.	0.01°C	0 to 100°C	±1.8°C
		500°Cf.s.	0.05°C	0 to 500°C	±1.8°C
		2000° <b>C</b> f.s.	0.1° <b>C</b>	0 to 2000°C	±1.8°C
RTD		100°Cf.s.	0.01°C	-100 to 100°C	±0.6°C
*3: JIS C 1604-	Pt100 *3	500°Cf.s.	0.05°C	-200 to 500°C	±0.8°C
1997. IEC751		2000° <b>C</b> f.s.	0.1°C	-200 to 800°C	±1.0°C
	JPt100	100°Cf.s.	0.01°C	-100 to 100°C	±0.6°C
1989	*4	500° <b>C</b> f.s.	0.05°C	-200 to 500°C	±0.8°C
1303		2000°Cf.s.	0.1°C	-200 to 500°C	±1.0°C
		10Ωf.s.	$0.5$ m $\Omega$	0 to 10Ω	± 10 mΩ
Resistance		20Ωf.s.	1mΩ	0 to 20Ω	± 20 mΩ
resistance		100Ωf.s.	$5m\Omega$	0 to 100Ω	± 100 mΩ
		200Ωf.s.	$10 \text{m}\Omega$	0 to 200Ω	± 200 mΩ
Humidity		100%rh f.s.	0.1%rh	5.0 to 95.0%rh	See Humidity Accuracy Ta- ble (includes Z2000 Hu- midity Sen- sor accuracy)



Reference junction

compensation

compensation accu- Reference junction compensation

racy Add to thermocouple measurement accuracy when internal RJC is en-

Temperature charac- Add (Measurement accuracy x 0.1) /°C to measurement accuracy (see teristic

Humidity Accuracy Table for humidity) Reference junction Internal/External selectable (for thermocouple measurements)

**Chapter 11 Specifications** 

Thermocouple burn- out detection	Enable/disable thermocouple burn-out detection at each recording interval. $5~\mu\text{A}\pm20\%$ detection current. No current flow when acquiring measurement data. Burn-out detection is effective for recording intervals longer than 20 ms (for up to 15 channels: U1-1 to U1-15).
Digital filter	Off, 50 Hz, 60 Hz (automatically sets the cut-off frequency according to the recording interval)
Cut-off frequency	See the Cut-Off Frequency Table (p. 237).
Input resistance	1 M $\Omega$ ±5% (voltage and thermocouple measurement) 2 M $\Omega$ ±5% (RTD and resistance measurement)
Normal mode rejec- tion ratio	50dB minimum (with 50 Hz input with 5 s recording interval, and 50 Hz digital filter enabled) (with 60 Hz input with 5 s recording interval, and 60 Hz digital filter enabled) (Using up to 15 channels (U1-1 to -15) with thermocouple burn-out disabled.)
Common mode re- jection ratio	with 100 $\Omega$ maximum signal source impedance 100dB minimum (with 50 or 60 Hz input and digital filter disabled) 140dB minimum (for 50-Hz input with 5 s recording interval, 50-Hz digital filter enabled, 10 mV f.s. range setting) (for 60-Hz input with 5 s recording interval, 60-Hz digital filter enabled, 10 mV f.s. range setting) (Using up to 15 channels (U1-1 to -15) with thermocouple burn-out disabled.)
Conditions of guar- anteed accuracy	After 30 minutes warm-up
Temperature and hu- midity range for guaranteed accuracy	Temperature 23±5°C (73±9°F), Humidity 30 to 80% RH (non-condensating)
Effect of radiated ra- dio- frequency elec- tromagnetic field	±5%f.s. at 3 V
Effect of conducted radio-frequency electromagnetic field	
Pulse/Digital input	
Terminal block	M3 screw type terminal block
Input signal compati- bility	Non-voltage "a" contact (normally open) open collector or voltage input
Maximum input volt- age	0 to 50 VDC
Input resistance	1.1 MΩ±5%
Max. inter-channel voltage	Non-isolated (HiLogger/GND Common)
Maximum rated voltage to earth	Non-isolated (HiLogger/GND Common)

**Detecting level** Measurement pa-

HIGH 1.0 Vmin. LOW 0 to 0.5 V / HIGH 4.0 Vmin. LOW 0 to 1.5 V

rameter

Pulse/digital input independently selectable for each channel

**Pulse input** 

Measurement range/Resolution

Measurement	Donne	Max. Res-	Magazzahla Danga									
Object	Range	olution	Measurable Range									
Pulse Integra-	1,000 Mc pulse f.s.	1pulse	0 to 1,000 Mpulse									
tion	1,000 IVIC pulse 1.s.	ipuise	o to 1,000 ivipuise									
Revolution Vari-	5,000/n [r/s] f.s	1/n [r/s]	0 to 5,000/n [r/s]									
ation	n = pulses/revolution, fro	= pulses/revolution, from 1 to 1,000										

Pulse input period

Without filter (Off), at least 200 µs (both H and L levels at least 100 µs) With filter (On), at least 100 ms (both H and L levels at least 50 ms)

Slope

Either rising or falling edge pulse detection can be set for each channel

Measurement

Integrated count, Revolution variation

mode

Integrated count Additive:

Counts cumulative (integrated) value from measurement start

Instantaneous:

2-level selectable

Counts instantaneous value at every recording interval (the integration

value is reset at each interval)

Revolution variation Counts the input pulses per second to obtain revolutions

Anti-chatter filter Settable On/Off for each channel

Digital Input

Measurement mode Records 1 or 0 at each recording interval

# **Cut-off frequency**

#### 1. With 60-Hz digital filter, and burn-out detection disabled

-: Not settable

							Re	cordin	g inter	val					
		10 ms	20 ms	50 ms	100 ms	200 ms	500 ms	1 s	2 s	5 s	10 s	20 s	30 s	1 m	2 m or more
Cut-off fre- quency char char Up	Up to 15 channels*1	20.0k	13.0k	4.9k	2.4k	1.2k	60	60	60	60	60	10	10	10	10
	Up to 30 channels*2	-	20.0k	13.0k	4.9k	2.4k	1.2k	60	60	60	60	60	60	10	10
	Up to 45 channels*3 Up to 60 channels*4	_	-	20.0k	13.0k	4.9k	2.4k	1.2k	60	60	60	60	60	60	10

[Unit: Hz]

<sup>\*1.</sup> Using U1-1 to -15, \*2. Using U2-1 to -15,

<sup>\*3.</sup> Using U3-1 to -15, \*4. Using U4-1 to -15

#### 2. With 50-Hz digital filter, and burn-out detection disabled

-: Not settable

			Recording interval													
		10 ms	20 ms	50 ms	100 ms	200 ms	500 ms	1 s	2 s	5 s	10 s	20 s	30 s	1 m	2 or more	
	Up to 15 channels*1	20.0k	13.0k	4.9k	2.4k	1.2k	50	50	50	50	50	10	10	10	10	
Cut-on	Up to 30 channels*2	-	20.0k	13.0k	4.9k	2.4k	1.2k	50	50	50	50	50	50	10	10	
quency	Up to 45 channels*3 Up to 60 channels*4	-	-	20.0k	13.0k	4.9k	2.4k	1.2k	50	50	50	50	50	50	10	

[Unit: Hz]

#### 3. With 60-Hz digital filter, and burn-out detection enabled

-: Not settable

			Recording interval													
		10 ms	20 ms	50 ms	100 ms	200 ms	500 ms	1 s	2 s	5 s	10 s	20 s	30 s	1 m	2 m	5 m or more
Cut-off fre- quency Up to o	Up to 15 channels*1	-	20.0k	13.0k	4.9k	2.4k	1.2k	60	60	60	60	60	10	10	10	10
	Up to 30 channels*2	-	_	20.0k	13.0k	4.9k	2.4k	1.2k	60	60	60	60	60	60	10	10
	Up to 45 channels* <sup>3</sup> Up to 60 channels* <sup>4</sup>	_	-	ı	20.0k	13.0k	4.9k	2.4k	1.2k	60	60	60	60	60	60	10

[Unit: Hz]

#### 4. With 50-Hz digital filter, and burn-out detection enabled

-: Not settable

			Recording interval													
		10 ms	20 ms	50 ms	100 ms	200 ms	500 ms	1 s	2 s	5 s	10 s	20 s	30 s	1 m	2 m	5 m or more
0 . "	Up to 15 channels*1	-	20.0k	13.0k	4.9k	2.4k	1.2k	50	50	50	50	50	10	10	10	10
	Up to 30 channels*2	-	-	20.0k	13.0k	4.9k	2.4k	1.2k	50	50	50	50	50	50	10	10
quency	Up to 45 channels*3 Up to 60 channels*4	-	-	-	20.0k	13.0k	4.9k	2.4k	1.2k	50	50	50	50	50	50	10

[Unit: Hz]

<sup>\*1.</sup> Using U1-1 to -15, \*2. Using U2-1 to -15, \*3. Using U3-1 to -15, \*4. Using U4-1 to -15

#### 5. With digital filter, and burn-out detection disabled

-: Not settable

		Recording interval		
		10 ms	20 ms	50 ms or more
Cut-off frequency	Up to 15 channels*1	20.0k	20.0k	20.0k
	Up to 30 channels*2	-	20.0k	20.0k
	Up to 45 channels*3	_	_	20.0k
	Up to 60 channels*4			

[Unit: Hz]

### 6. With digital filter disabled, and burn-out detection enabled

-: Not settable

		Recording interval			
		10 ms	20 ms	50 ms	100 ms or more
Cut-off frequency	Up to 15 channels*1	_	20.0k	20.0k	20.0k
	Up to 30 channels*2		-	20.0k	20.0k
	Up to 45 channels*3		-	-	20.0k
	Up to 60 channels*4				

[Unit: Hz]

- \*1. Using U1-1 to -15, \*2. Using U2-1 to -15,
- \*3. Using U3-1 to -15, \*4. Using U4-1 to -15

### (4) Others

Accessories	<ul> <li>Instruction Manual (This document)</li></ul>
Options (sold separately)	Model LR8500 Voltage/Temp Unit  Model LR8501 Universal Unit  Model Z1000 Battery Pack (NiMH, 7.2 V, 4500 mA)  Model 9418-15 AC Adapter (with supplied power cord)  Model C1000 Carrying Case  Model 9642 LAN Cable  Model Z2000 Humidity Sensor  Model 9727 PC Card (256MB)  Model 9728 PC Card (512MB)  Model 9729 PC Card (1GB)  Model 9830 PC Card (2GB)  Model Z5000 Fixed Stand

Chapter 11 Specifications

# 11.2 LR8500 Voltage/Temp Unit Specifications

Period of guaranteed accuracy	1 year
No. of Input Channels	15 channels (select voltage, thermocouple, or humidity for each channel)
Input terminals	M3 screw type terminal block (2 terminals per channel) Terminal block cover mounting
Measurement objects	<ul> <li>Voltage</li> <li>Thermocouple (K, J, E, T, N, R, S, B, W)</li> <li>Humidity (Only with Hioki Z2000 Humidity Sensor)</li> </ul>
Measurement accuracy	Per connected HiLogger specification
Conditions of guaranteed accuracy	Per connected HiLogger specification
Temperature and hu- midity range for guar- anteed accuracy	Per connected HiLogger specification
Operating environment	Per connected HiLogger specification
Operating temperature and humidity	Per connected HiLogger specification
Storage temperature and humidity	Temperature -10 to 50°C (14 to 122°F), Humidity 80% RH or less (non-condensating)
Dimensions	Approx. 128W $\times$ 52.8H $\times$ 64.5D mm (5.04"W $\times$ 2.08"H $\times$ 2.54"D) (sans protrusions)
Mass	Approx. 380 g (13.4 oz.)
Applicable Standards	Safety : Per connected HiLogger specification EMC : Per connected HiLogger specification

Period of guaranteed accuracy	1 year
No. of Input Channels	15 channels (select voltage, thermocouple, RTD, humidity, or resistance for each channel)
Input terminals	Push-button terminals (4 terminals per channel) Terminal block cover mounting
Measurement objects	<ul> <li>Voltage</li> <li>Thermocouple (K, J, E, T, N, R, S, B, W)</li> <li>RTDs (Pt100, JPt100, 3- or 4-wire configuration, 1 mA measurement current)</li> <li>Resistance (4-wire configuration, 1 mA measurement current)</li> <li>Humidity (Only with Hioki Z2000 Humidity Sensor)</li> </ul>
Measurement accuracy	Per connected HiLogger specification
Conditions of guaranteed accuracy	Per connected HiLogger specification
Temperature and hu- midity range for guar- anteed accuracy	Per connected HiLogger specification
Operating environment	Per connected HiLogger specification
Operating temperature and humidity	Per connected HiLogger specification
Storage temperature and humidity	Temperature -10 to 50°C (14 to 122°F), Humidity 80% RH or less (non-condensating)
Dimensions	Approx. 128W $\times$ 52.8H $\times$ 64.5D mm (5.04"W $\times$ 2.08"H $\times$ 2.54"D) (sans protrusions)
Mass	Approx. 300 g (10.6 oz.)
Applicable Standards	Safety : Per connected HiLogger specification EMC : Per connected HiLogger specification

Chapter 11 Specifications

# **Maintenance and** Chapter 12 **Service**

# 12.1 Inspection, Repair, and Cleaning



Touching any of the high-voltage points inside the HiLogger is very dangerous.

Do not attempt to modify, disassemble or repair the HiLogger; as fire, electric shock and injury could result.

#### Replaceable Parts and Operating Lifetimes

Useful life depends on the operating environment and frequency of use. Operation cannot be guaranteed beyond the following periods.

For replacement parts, contact your dealer or Hioki representative.

Part	Life
LCD (to half brightness)	Approx. 40,000 hours
Z1000 Battery Pack	Battery charge capacity is reduced to about 60% after 300 full charge/discharge cycles.
Battery pack connector	Connect/disconnect 30 times (for stable contacts)
Electrolytic Capacitors	Approx. 10 years
Lithium battery	Approx. 5 years  The HiLogger contains a built-in backup lithium battery. If the date and time deviate substantially when the HiLogger is switched on, it is the time to replace that battery. Contact your dealer or Hioki representative.

#### **Fuse**

The fuse is housed in the power unit of the HiLogger. If the power does not turn on, the fuse may be blown. If this occurs, a replacement or repair cannot be performed by customers. Please contact your dealer or Hioki representative.



#### **Transporting**

- Use the original packing materials when transporting the HiLogger, if pos-
- Pack the HiLogger so that it will not sustain damage during shipping, and include a description of existing damage. We do not take any responsibility for damage incurred during shipping.

#### Cleaning

To clean the HiLogger, wipe it gently with a soft cloth moistened with water or mild detergent. Never use solvents such as benzene, alcohol, acetone, ether, ketones, thinners or gasoline, as they can deform and discolor the case. And, wipe the LCD gently with a soft, dry cloth.

# 12.2 Troubleshooting

If damage is suspected, check the "Before Returning for Repair"(p. 244) section before contacting your dealer or Hioki representative.

#### **Before Returning for Repair**

If abnormal operation occurs, check the following items.

Symptom	Check Items	
The display does not appear when you turn the power on.	<ul><li>Is the power cord disconnected?</li><li>Are connections made correctly?</li><li>Is the battery pack installed correctly?</li></ul>	Verify that the power cord is connected properly (p. 32). Verify that the battery pack is correctly installed (p. 30).
Keys do not work.	Is any key being held down?     Is the key-lock state active?     (A message appears when a key is pressed while key-lock is active.)	Verify key operation.  Cancel key-lock: (Hold the ☐ □ cursor keys for three seconds)
Power does not turn on.	<ul> <li>Check the AC adapter (if 12 V DC is not output, the adapter is faulty).</li> <li>A power protection component may be damaged.</li> </ul>	Contact your dealer or Hioki representative for service.  Customers should not attempt to perform parts replacement and repair.  Contact your dealer or Hioki representative for service.
A waveform does not appear when you press START.	Is the "Waiting for pre-trigger" message displayed?     Is the "Waiting for trigger" message displayed?     Is the waveform display color selection box selected ( ⋈ )?	When pre-triggering is enabled, triggering is ignored until the pre-trigger portion of the waveform has been acquired. Recording starts when a trigger occurs.
No changes occur in the displayed waveform.	Is the measurement cable connected correctly?     Is the measurement range set properly?	Verify that the clamp sensor or connection cable is connected correctly (p. 33).
Data cannot be saved to the removal storage.	<ul> <li>Is the removal storage inserted properly?</li> <li>Is the removal storage formatted?</li> <li>Is the remaining capacity of the removal storage too low?</li> </ul>	"Using a CF Card/USB flash drive" (p. 45)

### 12.2 Troubleshooting

Z1000 battery pack cannot be charged (Charging LED is not lit).	<ul> <li>Please confirm that the surrounding tem- perature is within 10 to 40°C range.</li> </ul>	The temperature allowed for charging on the HiLogger is surrounding temperature of 10 to 40°C.
	Is the HiLogger stored for a long time in a plugged condition?	The battery pack may have deteriorated and the battery life may be expiring soon. Please purchase a new battery pack. Please contact your dealer or the nearest HIOKI representative. If the HiLogger is not used for more than a month, please remove the battery pack for storage.
Time that can be used with the battery pack has become shorter.	Possibility of capacity decrease due to the deterioration of the battery pack.	The battery pack may have deteriorated and the battery life may be expiring soon. Please purchase a new battery pack. Please contact your dealer or the nearest HIOKI representative.
If the cause is un- known	<ul><li>Try performing a system reset (p. 159).</li><li>All settings are returned to their factory defaults (p. A11).</li></ul>	

Chapter 12 Maintenance and Service

# 12.3 Disposing of the HiLogger

The HiLogger contains a lithium battery for memory backup. When disposing of this HiLogger, remove the lithium battery and dispose of battery and HiLogger in accordance with local regulations.


#### **Removing the Lithium Battery**

# **∆WARNING**


To avoid electric shock, turn off the power switch and disconnect the power cord and measurement cables before removing the lithium battery.

Required tools: One Phillips screwdriver (No.1), tweezers


- Verify that the power is off, and remove the measurement cables and power cord.
- Turn the HiLogger over and remove the five screws affixing the lower case.




Remove the two screws in the battery compartment cover.




4 Remove the battery pack.




Remove the screw in the battery compartment, and remove the bottom of the case.



6 Remove the two screws in the circuit board, and remove the board.



7 Turn the board over, and insert the tweezers between the battery holder and battery while lifting the battery to remove it.



See www.dtsc.ca.gov/hazardouswaste/perchlorate

Chapter 12 Maintenance and Service


1)


# **Appendix**

## **Appendix 1 Scan Timing**

For sampling of the LR8500 Voltage/Temp Unit and LR8501 Universal Unit, there is a scan system for each channel.

In the following figures, the digital filter is Off, recording interval is 20 ms (with 2 input units), or 50 ms (with 4 input units).





When the digital filter is off, the scan widths and dead times between channels are fixed to the values shown in the figure above regardless of the recording intervals. When the digital filter is on, the scan widths and dead times between channels vary in accordance with the recording intervals.

## **Appendix 2 Error Messages and Remedial Actions**

Error messages consist of either "Error" or "Warning" displays.

A screen message appears whenever an error occurs. In either case, take the remedial action indicated.

## **Error Messages**





To clear an error message, press ENTER or ESC.

Messa	ssage Remedial Action			
001	Failed to back up the waveform.	Data in internal memory will be lost in about 30 min. after power outage. For long-term measure ments, Auto Save to CF card or etc. is recommended to prepare for power outages.  See: "What happens to data in a power outage?" (p.123)		
004	Battery low. Cannot access to the waveform backup and Media.	Low battery charge: recharge or replace with a fresh battery pack.		
005	FPGA error.	Incompatible FPGA firmware version. Try updating the firmware, and if the error persists, submit the HiLogger for repair.		
008	FPGA PLL error. Turn off and on the power.	Measurement stopped due to FPGA internal PLL fault. Turn power off and on, check ambient conditions (temperature and noise), and try measuring again.		
009	Turn off and connect UNIT in numerical order.	If input unit 4 is used while unit 3 is not, move connections to unit 3 so there is no gap between input units.		
010	UNIT recognize error.	An input UNIT could not be properly recognized. Contact your dealer or Hioki representative, as it may be damaged.		
011	The time of the clock was initialized.	Reset the clock. If the problem remains, have the HiLogger repaired.		
012	Internal Memory recognize error.	Internal memory could not be properly recognized. Contact your dealer or Hioki representative, as it may be damaged.		

## **Warning Messages**

Appears just once when an error occurs. Disappears within a few seconds. Also disappears when any key is pressed.

Messa	Message Remedial Action			
101	Invalid key.	The pressed key is disabled due to measuring or other operation. Press the key again after the current operation finishes.		
102	Cannot start measurement.	The <b>START</b> key is disabled when the current screen is displayed. Switch to the Waveform/Numerical screen before starting measurement.		
103	Cannot change while measuring.	Press <b>STOP</b> to stop measuring before changing the setting.		
201	Exceeding the setting range.	The entered numerical value is out of the valid range. Enter a valid value.		
204	Measurement range changed.	When <b>[Type]-[Up/Lwr]</b> is selected, the measurement range is automatically changed to match the upper and lower limits.		
230	Recording time has been changed due to memory limit.	Increasing the number of measurement channels has decreased Internal memory waveform data capacity.		
231	Pre-Trigger span changed.	Increasing the recording interval or length requires reducing pre-trigger recording time.		
232	Recording and Pre-Trigger spans changed due to waveform memo- ry limit.	Increasing the recording interval requires reducing recording length and pre-trigger recording time.		
233	Trigger or alarm changed.	The setting ranges for count integration and revolutions have been changed.		
234	Burn Out (broken-wir) detection changed.	Burn-out detection is not available with the current settings. To enable burn-out detection, select a longer recording interval or reduce the number of channels used.  See: "About the Recording Interval" (p .52)		
235	Cannot change Burn Out (brokenwire) detection.	The setting is not available due to the combination of the number of channels used and the recording interval. To enable burn-out detection, select a longer recording interval, or reduce the number of channels used.  See: "About the Recording Interval" (p.52)		
236	File partition period was changed.	The segment time span has been changed in response to changing the recording interval.		
237	File partition time was changed.	The segment time span has been changed in response to changing the recording interval.		
238	CSV auto save has been set.Unable to set the specified record interval.	The recording intervals available for CSV auto saving are limited. Select a longer recording interval.  See: "Automatic Saving (Waveform Data and Numerical Calculation Results)" (p.125) *2		

Appendia

Α**4** Appendix 2 Error Messages and Remedial Actions

Messa	age	Remedial Action	
239	CSV auto save has been set.Unable to set the specified record interval.	Select non-CSV auto saving to measure with the specified recording interval.	
240	The timer stop time has been passed.	Change the timer stop time or cancel the timer.	
241	10ms recording interval cannot be set due to too many channels.	Measurement with 10 ms recording interval is available when using UNIT1-1 to -15. Disable (set to Off) channels on other input units (2 to 4).	
242	20ms recording interval cannot be set due to too many channels.	Measurement with 20 ms recording interval is available when using UNIT1-1 to UNIT2-15. Disable (set to Off) channels on other input units (3 and 4).	
243	Recording interval has been changed.	The recording interval has changed due to expanded channel usage.	
244	Auto-save has been changed from CSV to waveform.	The saving method was changed to Waveform (binary) because the selected recording interval is too short for CSV saving. To enable CSV saving, select a longer recording interval or reduce the number of channels used.  See: "Automatic Saving (Waveform Data and Numerical Calculation Results)" (p .125) *2	
301	No waveform data.	No waveform data is preset, so data saving and cal- culations cannot be performed. Press <b>START</b> to start acquiring measurement data.	
302	Confirm the A-B cursor position.	The A/B cursor positions are invalid (out of waveform range). Check the cursor positions.	
303	No numerical calculation data. Execute numerical calculation (p. 143)		
304	Invalid event mark.	Try moving to an event mark that is not in memory.	
401	File processing error.	An unexpected fault occurred while processing a file on the removal storage. Turn the HiLogger off and back on.	
402	Cannot load this file.	The format of the file is incompatible with the HiLogger, or the file is corrupt.  Refer to "6.1 About Saving and Loading Data" (p. 121) for loadable file formats.	
403	Insert a Media.	A CF card or USB flash drive is not present. Insert storage media.	
404	Directory full.	No more files can be created because the directory is full. Check or perform the following:  1. System reset (p. 159)  2. Verify that the removal storage is specified by Hioki (p. 45)  3. Reformat the removal storage (p. 47) If the message persists after performing the above, either the removal storage or HiLogger may be damaged. Contact your dealer or Hioki representative.	
405	Not enough capacity.	The removal storage as insufficient space to save the file. Delete files to increase free space, or replace the removal storage.	

Message		Remedial Action	
407	Insert CF card or USB memory.	A CF card or USB flash drive is not present. Insert storage media.	
408	Preparing to protect files.	Allow about three minutes for the capacitor to charge.	
430	Unsaved data present.	The removal storage is not inserted, or does not have enough free space.  Insert a removal storage and manually save needed data.	
431	Insert media to save waveform data.	Insert a removal storage.	
432	Change media.	Removable storage cannot be accessed. Replace the CF card or USB flash drive.	
434	Media is full or cannot delete oldest wave file.	This may appear while measuring using waveform auto save. A file could not be saved: Not enough space on the removable storage.	
435	Media is nearly full.	Not enough space on the removal storage. Replace with a new removal storage.	
436	Saving interrupted (Low battery).	Battery charge is too low to save. Recharge, or connect the AC adapter.	
437	Saving wave data.Wait for a moment.	Some key operations are disabled because of the increased load during real-time saving.  Minimize key operations as much as possible during real-time saving.	
438	This folder is protected. Rename for deleting.	This message is displayed to prevent accidental deletion of data folders. To delete a folder, first rename it.	
441	Insert the recording media. Unsaved data will be lost soon.	Real-time saving was attempted without removable storage, and with less than 50% internal memory available. Insert removable storage.	
442	File name is too long to change.	The HiLogger cannot rename files with names longer than 26 characters. Use a PC to rename the file.	
501	File system error (I/O error).	An I/O error occurred while accessing the removal storage. Reformat the removal storage. If the error persists, try a different removal storage. If this error occurs while using a good removal storage, the HiLogger may be damaged, in which case contact your dealer or Hioki representative.	
502	File system error (Incorrect file handle).		
503	File system error (system configuration).	Turn the HiLogger off and back on. If the fault persists, perform system reset (p. 159).	
504	File system error (not enough memory).		
505	File system error (incompleted information).	The removable storage could not be recognized. Reformat the removable storage on a PC. If the error persists, try a different removable storage. If this error occurs while using a good removable storage, the HiLogger may be damaged, in which case contact your dealer or Hioki representative.	

А6 Appendix 2 Error Messages and Remedial Actions

N4	15 514 5			
Messa	age	Remedial Action		
506	File system error (incorrect device).	Turn the HiLogger off and back on. If the fault persists, perform system reset (p. 159).		
507	File system error (file protected).	The requested write process (including deletion) could not be performed because the file attribute is read-only. Use a PC to cancel the read-only setting.		
508	File system error (failed to recognize the format).	The removable storage could not be recognized. Reformat the removable storage on a PC. If the error persists, try a different removable storage. If this error occurs while using a good removable storage, the HiLogger may be damaged, in which case contact your dealer or Hioki representative.		
509	File system error (limit of the number of files).	The number of files to be processed exceeds the limit, so processing cannot be performed. Delete files to increase free space, or try another removable storage.		
510	File system error (same name file).	An attempt was made to create a file with the same name as an existing file. Change the name of the file to be created (p. 137).		
511	File system error (system busy).	Processing could not be performed because files are in use by another executing process. Wait for the current process to finish. If there is no other executing process, turn the HiLogger off and back on.		
512	File system error (too long path name).	The specified path name is too long. Re-enter the name of a removable storage folder from the PC.		
513	File system error (no file).			
514	File system error (mode error).			
515	File system error (invalid file handle).			
516	File system error (file offset error).			
517	File system error (not enough capacity).	Insufficient free space is available on the removable storage for the process to execute. Delete files to increase free space, or try another removable storage.		
518	File system error (invalid file name).	The file name contains an invalid character. Rename the file (p. 137).		
519	File system error (directory error).			
520	File system error (invalid file type).			
521	File system error (file rename error).			
522	File system error (internal parameter error).	Turn the HiLogger off and back on. If the fault persists, perform system reset (p. 159).		
523	File system error (block size error).	, ,		
524	File system error (semaphore error).			
525	File system error (not supported action).			
603	Communication error.	Check communication settings.		
620	Bad MAC address.	The HiLogger's MAC address has been improperly altered. Please contact Hioki.		
621	Bad IP address.	Check the IP address setting.		

## Appendix 2 Error Messages and Remedial Actions

Messa	ige	Remedial Action	
622	Bad server IP address.	Check the server IP address setting.	
623	Can not connect to server.	Check settings and connections.	
625	Connection timed out.	Check the connection destination.	
626	Transfer was aborted.	Check the connection destination.	
627	Network error.	Check the HiLogger and connection destination.	
628	Server not found or DNS failed.	Check the DNS IP address and connection.	
629	DHCP failed.	Check the connections.	
630	Password error.	Check the password character string. The password is case sensitive.	
632	Bad FTP server IP address.	Check the IP addresses for FTP auto sending.	
633	Can not connect to FTP server.	Check the FTP auto sending settings and connections.	
634	Can not find FTP server/DNS failed.	Check the FTP auto sending settings, DNS IP address, and connections.	
635	Bad Mail server IP address.	Check the mail server IP address setting.	
636	Can not connect to Mail server.	Check the mail server settings and connections.	
637	Can not find Mail server/DNS failed.	Check the mail server settings, DNS IP address, and connections.	
638	Bad POP server IP address.	Check the POP server IP address setting.	
639	Can not connect to POP server.	Check the POP server settings and connections.	
640	Can not find POP server/DNS failed.	Check the DNS IP address and connection.	
660	Can not change while communication.	This item cannot be changed by remote operation.	
661	FTP Auto Transfer has been changed.	FTP auto sending settings changed due to auto-save setting change.	
662	Please set Auto Save to Binary.	FTP auto sending is only available when auto saving is not binary.	
663	Automatic data transfer via FTP is not possible while data is being saved.	Obtain manually the data file, if unable to be transferred, or copy the data to PC from the storage me-	
664	FTP data transfer failed. File not found.	dia.	

## **Appendix 3 File Naming**

File names are constructed as follows (must be exactly eight characters, not including extension).



2.	Autor	natic	serial	numbe	r
----	-------	-------	--------	-------	---

File Type	Folder Name	1. File Type	2. Automatic serial number	3. File Ex- tension
Settings Data	CONFIG	CONF	0001, 99999999	.SET
Waveform Data	DATA (Folders named by date are au- tomatically cre- ated) *2	Manual Save: WAVE Auto Save: (specified name) or AUTO	0001,99999999 *1	.MEM (Bi- nary) .CSV (Text) *3, *4
Numerical Cal- culation Results (calculation re- sults from start to stop)	MEASURE- MENT/ALL	Manual Save: MEAS	When [N-Calc. Data Sav- ing] on the System screen is set to [Single file]: 0001 to any available number When [N-Calc. Data Sav-	.CSV *3, *4
Numerical Cal- culation Results (calculation re- sults for each split interval when split calcu- lation is enabled)	MEASURE- MENT/PART	Auto Save: (specified name) or AUTO  JRE-  Auto Save: (specified is set to [Split save]: Calculations 1 to 6 are included by in files with 1 to 6		.CSV *3, *4
Captured Screen Image	PICTURE	SCR	0000199999999	.BMP

- \*1 When auto saving waveform data and calculation results, automatically generated serial numbers (up to eight digits) are appended to the specified file name. If no file name is specified, AUTO is automatically entered.
  - (XXXX0001.MEM, XXX00001.MEM, XX000001.MEM, X0000001.MEM)
  - When auto numbering exceeds 9999, the file name characters are overwritten (right to left) until all eight digits are used for serial numbers. (Example: WAVE9999.MEM, WAV10000.MEM, ...)
- \*2 When [Deleting] is enabled with auto save, the oldest waveform file is deleted when the CF card is full. When all waveform files within a date folder have been deleted, the folder name (date) is

  - automatically updated.
    (Example:) Before updating: 08-07-17
    After updating: 08\_07\_17\_080719\_101113 (old date\_new date\_new day and time)
    Hyphens (-) are changed to underbars (\_) and the date when the folder name was last changed is appended. (The example shows a new date and time of July 19th 2008, 10:11:13.)
- \*3 The TXT file extension is applied except when [Separator:Comma] is selected on the [System] screen.
- \*4 Before loading data into a spreadsheet program such as Excel, note that the number of rows that can be loaded at one time is limited (to 60,000 rows in Excel 97 2003, and to one million rows in Excel 2007)
  - Larger CSV files can be split by the following methods:
  - •Use a CSV file-splitting program (downloadable for free from Hioki's website).
  - •Before saving, select the [Split Save] saving method in the HiLogger. Note: The number of rows recorded per minute with 10 ms recording interval is:
  - 100 (data points per second) x 60 (seconds) = 6,000 rows

## **Appendix 4 Text File Internal Format**

Text files consist of header and data portions.

The header includes the following information related to measurement data.

- (1) File name and version, (2) Title comment, (3) Start trigger time,
- (4) Channel number of each line, (5) Measurement contents, (6) Range,
- (7) Comment, (8) Scaling setting, (9) Scaling ratio, (10) Scaling offset,
- (11) Channel number and input unit of each line

```
"File name", "AUTO0001.CSV", "V 1.00a" ••••••(1)
"Title comment","" •••••(2)
"Start trigger time","'09-12-16 13:52:32" ••••••(3)
"CH","A 1- 1","P 1","P 2","LOGIC-3","ALM-1","ALM-2","ALM-3","ALM-4","ALM-SOURCE-1","ALM-
SOURCE-2","ALM-SOURCE-3","ALM-SOURCE-4","Z 1", •••••(4)
"Mode","Voltage","Count","Revolve","Logic","Alarm","Alarm","Alarm","Alarm Source","Alarm
2.420000000E-02,0,
 1.000000000E-01, 1.17000E-02, 0.000000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",
2.340000000E-02,0,
2.00000000E-01, 1.15000E-02, 0.00000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",
2.300000000E-02,0,
3.000000000E-01, 1.16500E-02, 0.000000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",
2.330000000E-02,0,
4.00000000E-01, 1.16500E-02, 0.00000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",
2.330000000E-02.0.
5.00000000E-01, 9.05000E-03, 0.000000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",""
1.810000000E-02,0,
6.00000000E-01, 1.20500E-02, 0.000000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",
2.4100000000E-02.0.
7.00000000E-01, 9.45000E-03, 0.00000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",""
1.890000000E-02.0.
8.00000000E-01, 9.60000E-03, 0.00000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",
1.920000000E-02,0,
9.00000000E-01, 9.80000E-03, 0.00000000E+00, 0.00000000E+00,1,0,0,0,0,"","","","",
1.960000000E-02,0,
2.0100000000E-02.0.
```



## **Appendix 5 Binary File Size Calculation**

(Byte units)

File size = Header size + Data size

**Header size =** Text header size + Binary header size

Text header

**size =**  $512 \times (4 + \text{no. of analog channels} \times 3 + \text{no. of pulse channels} \times 3 + \text{no.}$ 

of logic bits x 3 + no. of alarm channels x 3 + no. of waveform calcula-

tions  $\times$  3)

Binary header

**size =**  $512 \times (12 + \text{no. of analog channels} \times 3 + \text{no. of pulse channels} \times 3 + \text{no.}$ 

of logic bits x 1 + no. of alarm channels x 20 + no. of waveform calcula-

tions  $\times$  3)

Data size = (no. of analog channels  $\times$  2 + no. of pulse channels  $\times$  4 + no. of logic

channels  $\times$  2 + no. of alarm channels  $\times$  58 + no. of waveform calcula-

tions  $\times$  8)  $\times$  no. of data points


Notes

The no. of logic channels can be either 0, or 1 when using logic.

The no. of logic bits can be 0 to 8.

The no. of alarm channels can be either 0, or 1 when using alarms.

You can check an estimate of the remaining time available on the attached CF card/ USB flash drive on the [Setting] screen.



## **Appendix 6 List of Default Settings**

When shipped from the factory or initialized to factory defaults, the settings are as follows.

Screen	Setting Item	Default Setting
Setting	Interval	20ms (50 ms when initial- ized with expansion input units installed)
	Filter	60Hz
	Time/DIV	100ms/DIV
	Cont	On
	Repeat	Off
	Numerical Calc.	Off
	Calc1,2,3,4,5,6	Off
	Timer	Off
	Auto Save	Off
СН	On/Off	On for UNIT1-1 to 2- 15 only (Expansion unit chan- nels are also On when initialized with the unit(s) installed.)
	Input	Voltage
	Range	10mV
	Thermocouple	K
	Burn Out	Off
	RJC	Int
	Count Mo	Add
	Pulse/Rev	1
	Slope	<b>↑</b>
	Disp Span	Pos
	Zoom	Voltage/Revolve:x1, Tc: x1
	0 Pos	Voltage: 50%, Tc/Revolve: 0%
	Upper	Voltage: 0.005, Tc: 100, Count/Revolve: 5000
	Lower	Voltage: -0.005, Tc/Count/Revolve: 0
	Scaling	Off
	Start Trig.	Off
	Stop Trig.	Off
	Alarm1, 2, 3, 4	Off

Screen	Setting Item	Default Setting
Trig &	Trig Func	Off
Alm	Timing	Start
	Trig Source	
	Start	OR
	Stop	OR
	Ext trig	
	Start	Off
	Stop	Off
	Pre-Trig	0d 0h 0m 0s
	Alarm Source	Off
	ALM1, 2, 3, 4	OR
System	Start Backup	Off
	File Protection	Low
	Backlight saver	OFF
	Backlight Brightness	100%
Display Color		Black
	Beep Sound	ON
	Time Disp	Time
	Language	English
	External Trig In	Trigger
	Starg/Stop message	ON
	Decimal Mark	Dot
	Separator	Comma
	N-Calc. Data Saving	Single file
	Event mark for alarm	OFF
	SAVE Key Op- eration	Select & Save

## **Appendix 7 Maximum Recordable Time**

Maximum recording time can be obtained with the following formula when saving binary waveform files to removable storage.

Max. recording time = Storage capacity\*1 x recording interval (seconds) / (data size from Appendix 5)

\*1. For internal memory, 16 x 1024 x 1024

The following maximum recording times are for the case of 30 analog measurement channels (with no pulse measurement, alarm outputs, or waveform calculations). The waveform file header is not included, so use about 90% of the values in the following table to estimate actual sizes.

The maximum recording time is longer when fewer channels are recorded.

	Storage capacity				
Interval	HiLogger's internal memory (16 MB)	9727 (256 MB)	9728 (512 MB)	9729 (1 GB)	9830 (2 GB)
20ms	1h 33min	1d 51min	2d 1h 42min	4d 3h 25min	8d 6h 50min
50ms	3h 53min	2d 14h 8min	5d 4h 16min	10d 8h 33min	20d 17h 6min
100ms	7h 46min	5d 4h 16min	10d 8h 33min	20d 17h 6min	41d 10h 12min
200ms	15h 32min	10d 8h 33min	20d 17h 6min	41d 10h 12min	82d 20h 24min
500ms	1d 14h 50min	25d 21h 22min	51d 18h 45min	103d 13h 30min	207d 3h 1min
1s	3d 5h 40min	51d 18h 45min	103d 13h 30min	207d 3h 1min	(1 year or more)
2s	6d 11h 20min	103d 13h 30min	207d 3h 1min	(1 year or more)	(1 year or more)
5s	16d 4h 21min	258d 21h 47min	(1 year or more)	(1 year or more)	(1 year or more)
10s	32d 8h 43min	(1 year or more)			

## **Appendix 8 Concerning Noise Countermea**sures

## Mechanism of Noise Introduction into Thermocouple Temperature Measurements

#### What are the sources of noise?

Within a factory, power is provided by large current flows at 50/60Hz. The main loads are primarily L loads, such as motors and solenoids; in addition, large current pulses are produced by capacitor input-type switching power supplies for device such as inverters and high-frequency induction furnaces. Basic wave component leak current, harmonic wave current, and other types of noise become mixed into the flow from each ground point to ground lines.

#### What are the paths of noise propagation?

- Common mode voltage introduced between the ground points of the device being tested and the HiLogger leaks to the input signal lines
- AC magnetic fields produced by current in power lines couple into loops in the input signal lines
- · Coupling due to electrostatic capacitance between input signal lines and power supply lines


#### What is common mode noise?

Noise that is generated between ground and the "+" and "-" input terminals of the HiLog-

#### What is normal mode noise?

Inter-line noise that is generated between the "+" and "-" input terminals of the HiLogger.

#### **Example of Connections Where Noise Can Affect Measurements**




When using a thermocouple to measure temperature, noise can affect measurements unless both the device being tested and the HiLogger are grounded.

Although there is no problem if the HiLogger is running on battery power, the HiLogger must be connected to ground if an AC adapter is being used.



## **Equivalent Circuit of Noise Introduction Path**

Measurements are directly affected by normal mode voltages from electromagnetically induced noise resulting from electromagnetic coupling into looped HiLogger input lines by AC magnetic fields produced by inverters and commercial power lines, as well as the capacitive coupling that results from interline capacitance.



Common mode noise results from the interposition of ground impedance between the ground point of the device being tested and the ground point of the HiLogger, and from capacitor coupling between the ground wire and noise source.

Common mode noise is converted to normal mode voltage (Enm) that is added to the "+" and "-" input terminals of the HiLogger as a result of the noise current (i1) and (i2) that flows to the coupling impedance (Z1) and (Z2) between the "+" and "-" input terminals of the HiLogger and ground. Because common mode noise is generated between the input pins, it has a direct effect on the measurements.

#### **Noise Countermeasure Example**


## 1st. The Importance of Device Grounding

#### **Ground the HiLogger securely**

The HiLogger is designed so that the chassis is grounded when the three-prong power cord from the adapter is plugged directly into a grounded, three-prong receptacle. If a three-prong-to-two-prong adapter must be used on the AC adapter power cord and therefore the HiLogger is not grounded, the HiLogger can still be grounded by connecting a grounded wire to the GND terminal (a M3 screw type terminal) located on the external control terminals of the HiLogger.


## Securely ground the chassis of the device being tested

Securely connect the chassis of the device being tested to a good ground.



## Connecting the chassis GND on the signal side to the HiLogger chassis

When connecting the chassis ground of the HiLogger to the chassis ground of the device being tested and then to ground, use a wire that is as short and as thick as possible to bring both pieces of device to equal potential.




#### Appendix 8 Concerning Noise Countermeasures

## Running the HiLogger on battery power

When the HiLogger is being powered by batteries and the AC adapter is not connected, the ground current loop is eliminated, making it possible to reduce the effects of common mode noise.


For measurements of short duration, powering the 8430-20 with batteries is an effective method for eliminating noise.

#### **Common Mode Noise Countermeasures**



Connect the chassis GND on the signal side to a good ground with a sufficiently low ground resistance. If there is still a large amount of noise, it may be possible to reduce the effects of common mode voltage by connecting a bypass ground wire to the GND terminal on the HiLogger.

Noise current (i1) and (i2) can be suppressed by suppressing the common mode voltage with a low-resistance ground wire or a bypass between ground poles. This suppresses the generation of normal mode voltages and reduces the effect on measurements.



If it is not possible to simply ground the HiLogger or the signal side, connect a ground wire between the chassis GND of the HiLogger and the signal side to equalize ground potentials. A basic requirement for obtaining stable measurements is to ground the device.

#### 2nd. Blocking Noise from External Sources

## Keep signal lines away from noise sources

Keep input signal lines (of the thermocouple) away from wiring that is a noise source (such as power lines, etc.), and make any permanent installation with as much separation as possible; for example, by running wires through a separate duct.


## Use shielded twisted pair wiring

It is effective to use shielded twisted pairs for the input signal lines (of the thermocouple). Twisted pairs are effective for preventing electromagnetic induction, and shielded wires are effective for preventing electrostatic induction.


The shielded wires should basically be grounded on the signal source side. If it is not possible to connect the signal source to ground, connect it to the chassis GND on the 8430-20. Note that doing so has no effect if the 8430-20 is not itself connected to ground through the three-prong power cord, etc.

Shielded twisted pair wires for the thermocouple can be obtained from thermocouple manufacturers.

#### **Normal Mode Noise Countermeasures**



Keep the signal lines (of the thermocouple) away from wiring that is a noise source (such as power lines, etc.). It is also possible to shield the signal lines from electrostatic coupling and to block noise by grounding the shield.



If the signal side is not grounded or if it is grounded inadequately, connect the HiLogger to ground. Also ground the shielding for the signal wires on the HiLogger side securely.

## Insulation from noise sources (temperature measurement by thermocouple)

The analog input channels are insulated from the chassis and each other. Therefore, the HiLogger allows you to attach the thermocouple directly to a conductor with a potential to measure it, provided that the voltage to ground does not exceed the maximum rating. If noise is likely affect measurement, wrap heat-resistant tape around the thermocouple for insulation, or use an ungrounded thermocouple and electrically insulate the input line.

## Setting the Digital Filter

To remove noise from input signals, the digital filter can be set for the analog channels. Select 50 or 60 Hz to match the local line frequency.

When 50 or 60 Hz is selected, longer recording intervals produce lower cut-off frequencies and better noise suppression.


A larger number of channels (input units) raises the cut-off frequency for a specific recording interval, and weakens noise suppression.

See: "Chapter 11 Specifications": "Cut-off frequency" (p.237)

## Inserting a Capacitor in the Signal Line

When noise affects the signal source directly or when measuring high-frequency pulses, it is effective to insert a capacitor between the "+" and "-" input terminals so that the noise does not enter the 8430-20. When inserting a capacitor, use one with a rated voltage that is equal to or exceeds the input voltage.

When a capacitor is inserted between the "+" and "-" input terminals, there are no restrictions on the recording interval because the filter is applied before the channel scan operation.



The capacitance of the capacitor should range from several  $\mu F$  to several thousand  $\mu F$ . Insert the capacitor between the "+" and "-" input terminals.

## **Appendix 9 Frequently Asked Questions**

Here are some common questions and answers about the HiLogger.

Installation and Settings			
Question	Remedial Action	Reference page	
Can the HiLogger be installed at an angle? Can it be mounted on a wall?	Use the optional Hioki Z5000 Fixed Stand.	"Chapter 11 Specifications": "Options (sold separately)" (p .239)	
How to measure the temperature of an object having applied voltage?	Be careful to not exceed 300 V DC between channels (for the Universal Unit, or 250V DC for the Voltage/Temp Unit), or 300 V AC/DC to ground. For higher voltage, avoid direct electrical contact, such as by using non-grounding thermocouples.	"4.1 Confirming Measured Values, and Starting Measurement" (p. 83): WARNING	
Is current measurement available?	Measure by connecting a 250 $\Omega$ resistor between + and - input terminals.	"Connect a 4-20 mA output device and record the average val- ue every minute"(p. A28)	
What is the maximum measuring time using the battery pack?	About 5 hours (@23°C)	"2.2 Using the Battery Pack (Option)" (p. 30)	
What is the power consumption?	Normal consumption is about 7 VA, and maximum (while charging the battery with maximum LCD brightness) is 24 VA.	"Chapter 11 Specifica- tions": "Power con- sumption" (p .227)	
Can recording resume automatically after a power outage?	Enable Auto Resume. Recording will automatically resume after a power outage. Because data measured before the outage is not retained in internal memory, we recommend enabling auto saving to removable storage.	"Using the Auto-Resume Function (Resume After Power Restoration)" (p .152)	
Can power be supplied from the HiLogger to an external sensor?	+12 V is provided at the external control terminals. Maximum supply current is 100 mA. Ground is common with the HiLogger.	"+12 V Output Connection (for external sensors)" (p .42)	

A**20** 

## Appendix 9 Frequently Asked Questions

Question	Remedial Action	Reference page
How to minimize thermocouple measurement error when moving the HiLogger between places with much different temperatures?	For thermocouple measurements, terminal temperature is measured by an internal sensor to provide reference junction compensation. When the ambient temperature changes abruptly, or when air blows directly on the terminals, errors occur due to thermal imbalance between the terminals and temperature sensor. When the HiLogger is moved to a location with significantly different ambient temperature, allow at least 60 minutes for thermal equalization before measuring.	"Instrument Installation" (p .6)
When connecting a thermocouple directly to the HiLogger, should reference junction compensation be set to external (EXT) or internal (INT)? How is accuracy affected?	Select INT when connecting a thermocouple (or compensating leads) directly to the HiLogger. Overall measurement accuracy is the sum of the accuracies of the thermocouple and the reference junction compensation (RJC). Example: when measuring 0 to 100°C with a K 100°C f.s. thermocouple For ±0.6°C thermocouple accuracy and ±0.5°C RJC accuracy, temperature measurement accuracy is ±1.1°C.	"Temperature Mea- surement Settings (us- ing thermocouples)" (p .56)
How to display only CH1 to CH3?	Select only the channels to be used on the Input Channel Settings display. To acquire data without displaying it, select x as the waveform display color.	"Input Channel Set- tings" (p .53) "Selecting Waveform Display Color" (p .65)
I want to measure motor tempera- ture. How can I display the differ- ence between ambient and measured temperature in real time?	Use the waveform calculation function. Calculates and displays the waveform of the real-time sum, difference, product, or quotient of values measured on two channels.	"7.3 Waveform Calculations" (p. 149)
How can I acquire maximum, minimum, and average values every hour?	"Interval Calculation" calculates and dis- plays the latest results after each inter- val. TXT format data can be saved to remov- able storage in real time.	"7.1 Calculate Average, Maximum, Minimum, and Etc." (p. 143)
I am measuring humidity with a converter that converts 0 to 100% RH to 1 to 5 V. How can I read humidity directly?	Set the scaling method to [2-pt], and enter the values. (1:1 conversion $\rightarrow$ 0, 2:5 conversion $\rightarrow$ 100, units: %RH)	"3.6 Scaling Settings (as needed)" (p. 69)

Triggering		
Question	Remedial Action	Reference page
Why does measurement not start when "Wating for trigger" is displayed?	Triggering is enabled. To start recording immediately with the <b>START</b> key, disable all trigger criteria or the trigger function on the <b>[Trig &amp; Alm]</b> screen.	"5.3 Confirming All Trigger and Alarm Cri- teria Settings" (p. 114)
How to acquire data before a trigger?	Enable pre-triggering to acquire data before trigger events.	"Setting Criteria for Pre- Trigger Measuring (Pre-Trig)" (p .108)
How to acquire data only when an external signal is HIGH?	Apply the external signal to the EXT.TRIG terminal, and set as follows: [Ext trig]-[Start]: ↑ (Rising), [Stop]: ↓ (Falling) Data will now be acquired only when the external signal is HIGH.	"Using External Trig- gering" (p .106)
How can I acquire data continuously starting on 1/4/2010, daily from 9:00 to 17:00, for one month?	Set as follows: Measurement Criteria [Interval]-[Cont]: Off, 8 hr 0 min 0 s [Repeat]: On Timer [Start]: On, 10 Year, 4 Mon, 1 Day, 9 Hour 0 Min 0 Sec [Stop]: On, 10 Year, 5 Mon, 1 Day, 9 Hour 0 Min 0 Sec [Interval]: On, 1 Day, 0 Hour 0 Min 0 Sec	"3.2 Configuring Measurement Settings" (p. 50) "5.4 Periodic (Timer) Measurements" (p. 115)
Is it possible to measure on 120 channels using two synchronized HiLoggers?	Measurement start can be synchronized using an external trigger. Sampling cannot be synchronized.	"9.4 Synchronous Measurements with Multiple HiLoggers" (p. 164)

Measuring		
Question	Remedial Action	Reference page
What should I do about zero off- set when the input is shorted?	Execute zero adjustment to compensate for offset when the inputs are shorted.	"2.7 Compensating for Input Circuit Offset (Ze- ro Adjustment)" (p. 48)
Even though a signal is only input on CH1, why do similar wave- forms appear on unused chan- nels?	An open-circuit input terminal can be affected by signals on other channels. By closing the input terminal circuit, normal measurement is possible. If this is impractical, disable unused measurement channels, or short the + and - terminals together.	
Why does it seem that measure- ment fluctuations are larger on UNIT2 than on UNIT1?	A larger number of channels (input units) raises the cut-off frequency for a specific recording interval, and weakens noise suppression.	"3.8 Suppressing Noise (Enable Digital Filtering)" (p. 73)

## A22

## Appendix 9 Frequently Asked Questions

Question	Remedial Action	Reference page
How to display numerical data values?	Press WAVE/DATA repeatedly to cycle through the Waveform (only), Waveform + Numerical Values, and Numerical Values (only) displays.  Numerical values can be displayed in a large font on the enlarged numerical display.  Numerical values at specific locations can be displayed using A/B cursors.	"Waveform/Numerical Screens" (p .19) "Viewing Input Signals as Numerical Values" (p .87) "Displaying Cursor Val- ues" (p .91)
What happens to pulse integration when there are more than one million pulses?	The counter saturates at 1,073,741,823 counts. If you expect to exceed this count, we recommend measuring with the Integration Mode ([Count]) set to Instantaneous ([Inst]), and summing later with a spreadsheet program.	"Integration (Count) Measurement Set- tings" (p .62)
What is the timing difference between CH1 and CH2?	When the <code>[Filter]</code> is Off, the time difference between data on neighboring channels is about 500 $\mu$ s, regardless of recording interval. When the <code>[Filter]</code> is enabled (50 or 60 Hz), the time difference increases with longer recording intervals.	"Appendix 1 Scan Timing" (p. A1)
How can I apply markers while measuring for easy searching lat- er? How can I search for alarm event locations?	Event marks can be applied by the following methods.  • Press START while measuring  • Press the on-screen [Make Mark] button.  • Apply a signal to the EXT.TRIG terminal  • When a warning occurs	"4.3 Marking Wave- forms and Searching Marks (Search Func- tion)" (p. 93)
Multiple temperature measure- ment values are scattered, even at the same location. Is it possible to match the value measured on CH1?	The Offset Cancel function is convenient for this. The value measured on UNIT1, CH1 is used as the scaling (offset) value for other channels.	"3.6 Scaling Settings (as needed)" (p. 69)
Is it possible to signal an alarm on ALM1 when the temperature on CH1 exceeds 40°C, and on ALM2 when it exceeds 50°C?	Yes. Four alarm channels are provided. Multiple alarms can be assigned to the same input channel.	"5.2 Alarm Output" (p. 109)

#### **Data Saving** Question Remedial Action Reference page Can after-market CF cards be Operation cannot be guaranteed. "2.6 Inserting a CF Card or USB Flash Please use a Hioki-specified card to used? Drive (when saving daavoid problems. ta)" (p. 45) Can after-market USB flash drives "2.6 Inserting a CF They can be used, although for real-Card or USB Flash time saving, we recommend using a be used? Hioki-specified CF card option for data Drive (when saving daprotection. Operation can only be guarta)" (p. 45) anteed for Hioki CF card options. Also, USB flash drive security features such as fingerprint authentication are not supported. Yes. Put the cursor on the [EJECT] but-Can removable media be replaced "Replacing Removable ton at the lower right of the screen, Storage During Realwhile measuring? press ENTER, and remove the media Time Saving" (p .127) following the displayed message. How much recording space is It depends on setting conditions (num-"Appendix 7 Maximum available? ber of channels and recording interval). Recordable Time" (p. About 200 days of recording is possible using 30 analog channels at 1 s recording interval to 1 GB media. How can I process acquired data Auto-saved files recorded in [Wave-"Automatic Saving (Waveform Data and form(realtime)] mode to removable later with a spreadsheet prostorage can be quickly and conveniently Numerical Calculation gram? converted to a text (CSV) file with the Results)" (p .125) Utility Logger program, which can then be loaded into a spreadsheet program. Auto-saved files recorded in [CSV(realtime)] mode can be directly loaded into a spreadsheet program, but note that the data cannot be reloaded into the HiLogger. Data can be transferred to a PC using "6.5 Transferring Data How can I load data from a CF card onto the PC when it has no the supplied USB cable and the USB to a PC (USB Drive Mode)" (p. 140) Drive mode. CF card slot? Data can also be transferred to a PC us-"10.5 Transferring Data ing the FTP function and LAN communito a PC with the FTP

Appendi

Server Function" (p.

(Waveform Data and

Numerical Calculation Results)" (p .125)

Saving

193)

"Automatic

cations.

([Ref Time]).

Set auto-saving [Split Save] to Periodic

How can I create files every hour,

from 0:00 (ideal split time)?

A24
Appendix 9 Frequently Asked Questions

Question	Remedial Action	Reference page
What is the file limit when auto saving to removable storage?	Depending on file size and CF card capacity, more than 1,000 files can be saved in one folder, although only 1,000 can be displayed on the file screen. As the number of files increases, the time required to start and stop measurement also increases, so we recommend storing no more than 1,000 files, if possible. (When saving, a folder named "HIOKI_LR8400" is created, and files with different data types are saved in subfolders within it.)	"6.1 About Saving and Loading Data" (p. 121)
Is data retained in internal memory when I turn the power off after measuring? I did not use auto saving to removable storage.	If waveforms are displayed when power is turned on, the data has been retained. Data in internal memory is retained for about 30 minutes after power-off. However, if power is off for more than 30 minutes, the data is lost.  To avoid such data loss, we recommend preparing and making settings for power outages when measuring for a long time.	"What happens to data in a power outage?" (p .123)
Why is only part of the data saved when saving to removable storage after measuring?	When A/B cursors are set to specify a save time span, only data within that span is saved. Also, internal memory capacity limits saving of measurement data to the most recent eight million data points.  If you need to save more data points, enable real-time auto saving beforehand.	"Specifying a Wave- form Time Span" (p .90) "Automatic Saving (Waveform Data and Numerical Calculation Results)" (p .125)
After starting measurement with real-time auto saving, can I still acquire data if I neglected to insert removable storage media until later?	As long as storage media is inserted be- fore internal memory overflows, data from the start of measurement will be saved to the removable storage. In the worst case (shortest interval), in- ternal memory overflows after about two minutes.	"Replacing Removable Storage During Real- Time Saving" (p .127)
Why does "Saving" continue to be displayed and saving not finish when saving internal memory data as text after measurement?	To save all data from a full internal memory to removable media as text after measurement takes about one hour. To abort the saving process, press and hold <b>STOP</b> for some time. We recommend saving binary data, and later converting to text with the Logger Utility (which takes only a few seconds).	Logger Utility Instruction manual "7.1.1 Saving Measure- ment Data as Text"
How to view data saved in binary format on a PC?	The Logger Utility PC application program is included on the supplied CD. Install it on the PC and use it to open the file.	"10.3 Using the Logger Utility" (p. 187)

Question	Remedial Action	Reference page
When opened in Excel, the time displayed is elapsed time from start. How can I display real time?	When saving data in CSV format on the HiLogger, the displayed time is determined by the [Time Disp] setting on the System screen. Select [Date] to display real time.  When converting CSV format with the Logger Utility, set the [Time Axis For-	"Selecting the Horizon- tal (Time) Axis Display" (p .155)  Logger Utility Instruction manual "7.1.1 Saving Measure-
	mat] to [Absolute Time].	ment Data as Text"
What are the files with .MEM and .LUW extensions?	MEM is the file extension for HiLogger waveform data, and LUW is the file extension for Logger Utility waveform data.  LUW files cannot be loaded into the HiLogger.	"6.1 About Saving and Loading Data" (p. 121) Logger Utility Instruction manual
How are event marks handled when converting data to text (CSV)?	When converting data to text with the HiLogger: Event numbers are included alongside measurement data. This is convenient when you need to later extract only marked data. When converting data to text with the Logger Utility: Event mark information is not included.	"4.3 Marking Wave- forms and Searching Marks (Search Func- tion)" (p. 93)

## **Logger Utility**

Question	Remedial Action	Reference page
What kind of program is the Logger Utility?	Running on a PC connected to the HiLogger by LAN or USB cable, it provides real time data acquisition, display, and calculation; display and analysis of waveform (binary) data acquired by the HiLogger; conversion of binary data to text (CSV) data; and printing.	Logger Utility Instruction manual
While measuring with the Logger Utility, can measurement data be transferred to a PC connected only when needed, and the PC disconnected at other times?	This is not possible while measuring with the Logger Utility. However, it can be done by transferring data files from removable storage using the FTP function.	"Automatic Saving (Waveform Data and Numerical Calculation Results)" (p .125) "10.5 Transferring Data to a PC with the FTP Server Function" (p. 193)
What is the method for converting data to a text (CSV) file with the Logger Utility?	In the menu bar, select [File]? [Save File in Text Format].     Select a file for CSV conversion in the displayed dialog, and set [CSV (comma separated)] as the file type.     Make other settings as necessary, and click the [Save] button.	Logger Utility Instruction manual


# Appendix 10Introduction to Measurement Applications

Two measurement applications are introduced.

## **Measuring Electrical Energy by Pulse Count**


This method acquires pulses from a watt-hour meter with pulse output of 50,000 pulses/kWh, and measures power consumption over one month (30 days). Watt-hour meter output pulses are measured every 30 minutes, and integrated energy is measured over a month.

## Prepare the Following Before Measuring




## **2** Configure Measurement Settings

On the [Setting] screen, set the recording interval and recording time, and enable auto saving.



Record at thirty-seconds intervals for thirty days automatically on the CF card Interval: 30min, Count: Off, Record time: 30 days
Auto Save: Waveform(realtime), Media: CF

Make input channel settings on the [CH] screen.



## **Setting Example**

Unit: PLS&ALM, Channel: P1, Input: Count, Count Mo: Add

Filter: Or

#### Scaling

Cond: Dec, Unit: kW, 1kW=50,000 Pulse

Disp Span

Type: Up/Lwr, Upper: 10000, Lower: 0

# When set as shown at the left, the vertical axes appear like this.

#### **Measurement Hints**

- Enable scaling to read measured values directly as electrical energy [kWh]. The display range
  changes automatically when scaling is enabled, so set the upper and lower display limits after
  enabling scaling.
- When the watt-hour meter uses mechanical (relay) contacts for output, chattering effects can be removed by enabling the filter.

## 3 Start and finish measuring



- Data is recorded for the specified recording time and saved to CF card. Recording stops 30 days after starting.
- To stop recording early, press STOP.

# Connect a 4-20 mA output device and record the average value every minute


This example introduces a method to connect an instrumentation device with 4-20 mA output and measure current variations. The average value is recorded every minute.

## Prepare the Following Before Measuring



## **2** Configure Measurement Settings

On the [Setting] screen, set the recording interval and recording time, and enal auto saving and numerical value calculation.



## Setting Example

To record at every 5-second interval for one hour, with auto saving to CF card, and recording calculated values every minute along with measurement data:

Interval: 5s, Cont: Off, Record time: 1 hour


Numerical Calc.: On, Calc1: Average, Split Calc: On, Length: 1 min

Auto Save: Waveform+Calc, Split Save: Off, Media: CF

#### **Measurement Hints**


ter : When 50 or 60 Hz is selected, longer recording intervals produce lower cut-off frequencies and better noise suppression.





#### **Setting Example**

Unit: UNIT1, Channel: 1-1, Input: Voltage, Range:



#### **Measurement Hints**

The "1-5 V" setting automatically selects the 10-V range with a 5-V upper limit and 1-V lower limit. To change the upper and lower limits, select the 10-V range.

## $oldsymbol{\mathcal{S}}$ Start and finish measuring




- Data is recorded for the specified recording time with calculations performed every minute, and saved to CF card.
   Recording stops one hour after starting.
- To stop recording early, press STOP.


## **Appendix 11Input Circuit Diagram**

Diagrams of the input circuits are shown below.

# Analog Inputs (Voltage, Thermocouple, Humidity, RTD, and Resistance)



## **Pulse Input Circuit Diagram**



# Index

Symbols	Sort
+12 V42	Charging time
12 0	Clock Setting15
Number	Comment
- 11	Communications commands
0 position	Continuous recording5
100BASE-T	Cursor
4-20 mA34	Type9
A	Cursor values9
A/B cursors91	D
Alarm	<u></u>
Alarm Event Marking	Daisy chain (serial) synchronization 16
Alarm output109, 163	Decimal Mark15
Upon thermocouple burn-out113	Decimal Point Character15
ALM41, 109, 163	Default Setting A 1
AND	Default settings A 1
Auto calculation	Delete while saving 12
Auto Resume	DHCP 179, 18
Auto resume	Display Color
Auto save124	Display range6
Average value143, 148	DNS
В	Drive
Background Color154	E
Background Color	E-Mail21
Background Color	E-Mail
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80	E-Mail21
Background Color	E  E-Mail
Background Color	E  E-Mail
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154	E  E-Mail
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15
Background Color	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57         C         Calculation formula       150	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16         F
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57         C         Calculation formula       150         Calculation Results	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16         F         File naming       A
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57         C         Calculation formula       150         Calculation Results       Save         124	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16         F         File naming       A         File Protection       15         File screen       47, 13         Formatting       4
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57         C         Calculation formula       150         Calculation Results       30         Save       124         CF card       45, 160	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16         F         File naming       A         File Protection       15         File screen       47, 13
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57         C         Calculation formula       150         Calculation Results       5ave         Save       124         CF card       45, 160         Copy       138	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16         F         File naming       A         File Protection       15         File screen       47, 13         Formatting       4         FTP       21         FTP client       19
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57         C         Calculation formula       150         Calculation Results       5ave         Save       124         CF card       45, 160         Copy       138         Delete       136	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16         F         File naming       A         File Protection       15         File screen       47, 13         Formatting       4         FTP       21         FTP client       19         FTP server       19
Background Color       154         Backlight Brightness       154         Backlight Saver       153         Batch Proc       75, 76, 77, 78, 80         Battery pack       30         Continuous operating time       30         Beep Sound       154         Beeper       154         Binary       122         Burn-out detection       56, 57         C         Calculation formula       150         Calculation Results       5ave         Save       124         CF card       45, 160         Copy       138	E-Mail       21         Error messages       A         Event mark       93, 9         Event mark for alarm       15         EXT.TRIG       43, 157, 16         External control terminals       16         External Trig In       106, 15         External trigger       9         External Trigger Input       16         F         File naming       A         File Protection       15         File screen       47, 13         Formatting       4         FTP       21         FTP client       19

## Index 2

## Index

FTP/HTTP authentication 188, 195	M	
G	Maximum value Measurement values	
Gateway182	Memory	
Gateway IP182	Minimum value	
Gauges86	Monitor	
GND 40, 42, 43	Move the cursor(s)	
Н	N	
Horizontal axis (Time Base)68	N-Calc. Data Saving	150
Horizontal cursors92	Network	
Host Name182	Noise	
Humidity measurement59	Numerical calculations	
	Numerical values	
	0	
Initialize159		
Initializing77	Operating keys	1
Inspection	OR	10
Installing173	_	
Integration (Count) measurement62	P	
Interval Calculation148	Dealcyalus	440 444
IP Address180	Peak value	
1	Port Number	
J	Pre-Trig	
Jump	Pulse measurement	0
K	Q	
K	Quick Save	128, 129
Key operation		
Trouble244	R	
KEY/LED160	D 17: 01 1 #	
Key-Lock25	Real-Time Calculation	
	Recording time	
L	Ref Time	
LAN	Remote operating	
Communication features	Repair	
When LAN communication fails186	Repeat recording	
Language155	Resistance measurement	
LCD	Revolution measurement	
Level monitor54	ROM/RAM	
Level trigger	RTD	58
Load	C	
Load Set	S	
	Save	
Logger Utility	Auto save	12
	Calc Results	
Logic trigger	File type	
LR8500 Voltage/Temp Unit28 LR8501 Universal Unit28	Numerical calculation results	
LINUSUT UTIIVEISAI UTIIL28	. tamonoai oaioaiation results	130

## Index 3

•	n	a	е	X

Quick save       124         Save Set       131         Screen Image       130         Select & Save       124         Waveform       130         Waveform data       130	
Scaling         69           Scrolling         88           Select & Save         128	
Self-Test	
Separator156	
Slope	
Specified time span for calculation147	
Split Length	
Split Save	
Start Backup152	
Start/Stop Confirmation Messages 155	
Start/Stop message	
System Reset159	
System screen151	
Т	
Temperature measurement	
RTD58 Thermocouple56	
RTD	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105         Trigger input       107	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105         Trigger input       107         Trigger output       162         Triggering       99	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105         Trigger input       107         Trigger output       162         Triggering       99	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105         Trigger input       107         Trigger output       162         Triggering       99	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105         Trigger input       107         Trigger output       162         Triggering       99         Triggering criteria       105	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105         Trigger input       107         Trigger output       162         Triggering       99         Triggering criteria       105         U       U         Uninstalling       177         Unit Information       160         USB       166	
RTD       58         Thermocouple       56         Text       122         Thermocouple       56         Time Disp       155         Time to maximum value       143, 148         Time to minimum value       143, 148         Time Value Display       155         Timer       99, 115         Trace cursors       92         TRIG.OUT       43, 162         Trigger combining logic       105         Trigger input       107         Trigger output       162         Triggering       99         Triggering criteria       105         U       Uninstalling       177         Unit Information       160	

USB driver USB flash drive Load USB flash driver Copy Delete Rename Sort USB Memory	. 45 132 138 136 137
V	
Vertical cursors	
W	
Waveform calculations	65 85
Z	
Zero Adjust	

## **Warranty Certificate**

Model	Serial No.	Warranty period
		One (1) year from date of purchase ( /)

This product passed a rigorous inspection process at Hioki before being shipped.

In the unlikely event that you experience an issue during use, please contact the distributor from which you purchased the product, which will be repaired free of charge subject to the provisions of this Warranty Certificate. This warranty is valid for a period of one (1) year from the date of purchase. If the date of purchase is unknown, the warranty is considered valid for a period of one (1) year from the product's date of manufacture. Please present this Warranty Certificate when contacting the distributor. Accuracy is guaranteed for the duration of the separately indicated guaranteed accuracy period.

- 1. Malfunctions occurring during the warranty period under conditions of normal use in conformity with the Instruction Manual, product labeling (including stamped markings), and other precautionary information will be repaired free of charge, up to the original purchase price. Hioki reserves the right to decline to offer repair, calibration, and other services for reasons that include, but are not limited to, passage of time since the product's manufacture, discontinuation of production of parts, or unforeseen circumstances.
- Malfunctions that are determined by Hioki to have occurred under one or more of the following conditions are considered to be outside the scope of warranty coverage, even if the event in question occurs during the warranty period:
  - Damage to objects under measurement or other secondary or tertiary damage caused by use of the product or its measurement results
  - b. Malfunctions caused by improper handling or use of the product in a manner that does not conform with the provisions of the Instruction Manual
  - Malfunctions or damage caused by repair, adjustment, or modification of the product by a company, organization, or individual not approved by Hioki
  - d. Consumption of product parts, including as described in the Instruction Manual
  - e. Malfunctions or damage caused by transport, dropping, or other handling of the product after purchase
  - f. Changes in the product's appearance (scratches on its enclosure, etc.)
  - g. Malfunctions or damage caused by fire, wind or flood damage, earthquakes, lightning, power supply anomalies (including voltage, frequency, etc.), war or civil disturbances, radioactive contamination, or other acts of God
  - h. Damage caused by connecting the product to a network
  - i. Failure to present this Warranty Certificate
  - Failure to notify Hioki in advance if used in special embedded applications (space equipment, aviation equipment, nuclear power equipment, life-critical medical equipment or vehicle control equipment, etc.)
  - k. Other malfunctions for which Hioki is not deemed to be responsible

#### \*Requests

- Hioki is not able to reissue this Warranty Certificate, so please store it carefully.
- · Please fill in the model, serial number, and date of purchase on this form.

13-09