## HIOKI
















## Wireless data logging at 1 kS/s (1 ms)

330-channel portable logger available with your choice of plug-in modules and wireless modules



# Two models: Standard Model and Wireless LAN Model



Standard model (designed for use with plug-in modules only)

LR8450

## You can add up to 4 plug-in modules which provides 120 channels of measurement






Configuration example: 120 channels of analog input

## **Plug-in units**

**VOLTAGE/TEMP UNIT U8552×4** 

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Add four units for 120 channels of measurement.

## Depending on various scenes, you can freely combine six types of plug-in modules





Configuration example: 60 channels of analog input + 1,000 channels of CAN input

#### Plug-in units

VOLTAGE/TEMP UNIT U8552×2 CAN UNIT U8555×2

Each VOLTAGE/TEMP UNIT U8552 accepts 30 channels of input. Each CAN UNIT U8555 accepts 500 channels of input.

### Wireless LAN model

## Add channels freely via either plug-in or wireless modules

Can also be used exclusively with wireless modules



# Wireless LAN model LR8450-01

## Add up to 7 wireless modules in total for a maximum of 330 channels

Configuration example: 330 channels

#### Plug-in modules

**VOLTAGE/TEMP UNIT U8552×4** 





#### Wireless modules

WIRELESS VOLTAGE/TEMP UNIT LR8532×7



With four U8552 VOLTAGE/TEMP UNITs and seven LR8532 WIRELESS VOLTAGE/TEMP UNITs, you can measure a total of 330 channels.

## Mix plug-in and wireless modules

Mixing and matching plug-in modules and wireless modules will allow you to build a measurement system that suits your needs.\*1

If wireless modules are used with other modules (wireless or plug-in), the sampling-timing shift between the units is periodically corrected.\*2

In addition, at times when the wireless communication is cut off, the correction function works after the communication is restored and the sampling-timing shift between the modules is corrected.

- \*1 Up to four CAN modules can be used at the same time. (Plug-in and wireless modules may be used in any combination.)
- \*2 Even in good wireless communication conditions (low interference) the sampling-timing between modules may shift about 20 ms. In bad wireless conditions, the sampling-timing shift will be much worse than this.

## Voltage measurement



## Measure outputs from a pressure sensor and other sensors at 1 kS/s max. sampling rate (1 ms interval sampling)

1 kS/s sampling is necessary to record outputs of several tens of Hertz from pressure sensors and vibration sensors.







WIRELESS HIGH SPEED VOLTAGE UNIT LR8533

## Temperature measurement



## Measure temperature near inverters and batteries at a sampling rate of up to 100 S/s (10 ms interval sampling)



VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552(\*)



WIRELESS VOLTAGE/TEMP UNIT LR8530 WIRELESS UNIVERSAL UNIT LR8531 WIRELESS VOLTAGE/TEMP UNIT LR8532(\*)

## Consistent sampling rate even with added modules

Each module incorporates its own A/D converter. This design keeps the maximum sampling rate high even when Modules are added.



Example 1: use four U8553 HIGH SPEED VOLTAGE UNITs (with 5 channels each) to measure 20 channels at a sampling rate of 1 kS/s (1 ms).

Example 2: Use four U8550 VOLTAGE/ TEMP UNITs (with 15 channels each) to sample 60 channels at a sampling rate of 100 S/s (10 ms).


## Consistent noise resistance even with added modules

Since increasing the number of modules has no effect on the cutoff frequency, which changes with the sampling rate, power supply noise can be reduced without sacrificing noise resistance.

(ex.) Samplng rate: 1 S/s		
Number of channels	Cutoff frequency	
1 ch to 15 ch	60 Hz	
16 ch to 30 ch	60 Hz	
31 ch to 45 ch	60 Hz	
46 ch to 60 ch	60 Hz	
*When using a power supply	<u> </u>	
frequency of 60 Hz.	Same cutoff frequency	

#### Set filters

#### Set filters for each module



The cutoff frequency, which varies with the data refresh interval, can be set separately for each module. You can use long data refresh intervals, which boost filter effectiveness, and short data refresh intervals for different modules at the same time.

- Measure control signals at maximum speed: module1 (data refresh interval: 1 ms)
- Measure battery voltage fluctuations: module 2 (data refresh interval: 1 ms)
- Measure temperature using thermocouples: module 3 (data refresh interval: 1 s) with strong filter

<sup>\*</sup>Sampling rate of 100 S/s (10 ms) is available when using 15 or fewer channels.

## Strain measurement

## Measure strain with a 1 kS/s sampling rate (1 ms)

Connect strain gages directly and measure at a sampling rate of up to 1 kS/s. Strain gages tend to have long, thin wires that are easily broken, but that potential pitfall can be avoided by using wireless modules so that wiring is minimized.









## **Connect strain gages directly**

The strain units have a built-in bridge box, allowing you to connect strain gages directly to their input terminals.



Strain-gage-type converters such as load sensors and pressure sensors can be connected directly to make measurement.





#### Reduced influence of noise

### Stable measurement, even at high voltages and high frequencies

Most competing loggers are incapable of measuring temperature accurately in noisy environments due to the influence of high frequencies, causing values to shift or fluctuate significantly. The LR8450 uses a new design to dramatically reduce the influence of high-frequency noise.

Example: measure temperature by connecting the tip of a K thermocouple to the screw on an inverter's PWM output terminal (W-phase) when using the U8550 VOLTAGE/TEMP UNIT (settings: 10 S/s sampling in the 100°C f.s. range).







Most competing loggers exhibit significant fluctuations when the inverter is operating, whereas the MEMORY HILOGGER LR8450 does not.


5

## **CAN** measurement NEW




## One instrument, two uses: CAN input + CAN output of measured values

	U8555	LR8535
Input: CAN and CAN FD	Yes	Yes
Output: CAN and CAN FD	Yes	No








CAN and CAN FD input or output



**WIRELESS CAN UNIT LR8535** 

CAN and CAN FD input only





## **CAN Editor** (standard CAN configuration software accessory)

Install this software from the application disc that comes with the MEMORY HiLOGGER LR8450 onto a PC to easily configure CAN Unit settings.

#### Setting method Online or offline


Save settings configured using the CAN Editor in the CES format and then load them with the LR8450. You can also configure instruments offline when a LAN or USB connection is difficult to establish.

#### Receive mode Loading DBC files

In addition to setting up channels manually, you can complete CAN communication definition settings simply by loading a DBC file.

#### Output mode Automatically configuring output targets

Creating output communication definitions one channel at a time for a logger that's handling a large number of channels is extremely time-consuming. With the CAN Editor, you need only specify the start ID and click the "Configure Automatically" button to complete all communication definitions. Those definitions can then be output as a DBC file and loaded onto an upstream system to complete the configuration process.



## Wireless for ease of use

### Collect data from dispersed locations all at the same time

The LR8450-01 can simultaneously collect measurement data from wireless units installed on various test equipment.


Collect measurement data from multiple locations with a single logger

Manage data in a single time sequence

Units can be placed in confined locations

Check the display during measurement







## Peace of mind in the event of an interruption in power or wireless connectivity

Peace of mind if communications are temporarily interrupted

#### Buffer memory holds up to 5 min.\*1 of measurement data

Each wireless unit has a built-in buffer memory that can hold up to 5 min.\*1 of measurement data. Data are resent along with more recent measurement data once communications resume, after which the data are restored inside the LR8450-01\*2.

The system can be configured to output an alarm if communications are interrupted or if a module encounters a low-battery state.

- \*1 The duration for which measurement data can be maintained does not vary with the recording interval (up to a maximum of 5 min.)
- \*2 Data collected using the Logger Utility software measurement cannot be restored in this manner.

#### **Battery operation**

## Use modules in locations where there's no AC power

#### Example

The wireless VOLTAGE/TEMP UNIT LR8530 can operate for about 9 hours on battery power. If the unit is charged at night, it can operate on just the battery pack during the day.

Using the Battery Pack Z1007

Wireless module model	Continuous operating time
LR8530	Approx. 9 hr.
LR8531	Approx. 7 hr.
LR8532	Approx. 9 hr.
LR8533	Approx. 9 hr.
LR8534	Approx. 5 hr.
LR8535	Approx. 10 hr.*





Peace of mind in the event of a power outage during measurement

#### Install a battery pack for peace of mind

If you've installed a battery pack in a module that's being powered by an AC adapter, the unit will automatically switch to battery power in the event of an outage so that the LR8450-01 can continue making measurements.

#### Make measurements in locations where it would be difficult to route wires

Work time can be reduced using the LR8450-01 and wireless modules, since only minimal wiring is required. If the measurement target is located in a lab, this approach eliminates the need for wiring and avoids having to drill holes in the walls of the monitoring room where data is being checked.





## Simple registration of wireless modules

Wireless modules, located within the range, that are not connected to another LR8450-01, can be automatically detected. Simply choose the module you wish to register from the list.








## Check the unused wireless LAN channels and select the wireless channel to use

You can reduce interference from other wireless devices by using an open channel (wireless frequency range being used by wireless devices in the area). Check for open channels on the instrument's screen.





## Observe data from a remote location using a PC or a tablet


By connecting the LR8450-01 to a PC or a tablet via wireless LAN, you can control the instrument remotely using the built-in HTTP server or obtain older data files using the built-in FTP server.

(You cannot use Logger Utility when using Station Mode or Access Point Mode. See below.)

# 



## Easy-to-read display of measured values




## External control terminals and interfaces to accommodate a broad range of use cases



#### Motor speed, flow rate integration, etc.


#### 8 channel pulse measurement



In "Revolve" mode, monitor production equipment by measuring the variations in revolution speed of motors or drills. In "Count" mode, identify operation status by acquiring integrated power or flow rate.

#### Useful in preventive maintenance


#### 8 channel alarm outputs



You can set alarm output for eight channels. You can set a level, a window, a slope, and a logic pattern on channels you wish to monitor.

#### Two terminals for voltage outputs (5, 12, or 24 V)

## Supplying power to the sensors



The LR8450/LR8450-01 provides two output terminals for voltages, each of which can supply 100 mA current, eliminating the need for a separate sensor power supply. You can select 5 V, 12 V, or 24 V from the VOUTPUT1 terminal and 5 V or 12 V from the VOUTPUT2 terminal.

#### Replace storage media during real-time saving

#### No need to stop recording


When you remove the storage media while recording data, and reinsert it, data remaining in the internal buffer memory will continue to be stored in a new and different file.



## **Extensive calculation functions**

#### **Numerical calculation function**

In addition to the maximum and minimum value calculation functions provided by previous models, the LR8450/LR8450-01 offers an extensive range of calculations, including on/off time, count, and usage ratio.




#### Types of calculations

Average value
Peak-to-peak value
Maximum value
Minimum value
Time at which maxi- mum value occurred
Time at which mini- mum value occurred
Integration
Aggregation
Usage ratio
On time
Off time
On count
Off count

#### **Waveform calculation function**

Calculate data while measurement continues and display calculated waveforms in real time. Calculation results are saved on a separate and dedicated calculation channel



#### Types of calculations

Basic arithmetic operations

Aggregation

Simple average

Moving average

Integration

## Recording over extended periods of time without interruption

Collect data on a storage device (SD memory card or USB drive) while measuring continues. The ability to segment files by hour or day without stopping measurement is convenient when you need to review data later.



#### **Maximum recording time (estimate)**

#### Example: Recording 30 analog channels with 2 modules (no alarm output or waveform processing)

Because the header portion of waveform files is not included in capacity calculations, expected actual maximum time is about 90% of those in the tables. The maximum recording time varies with the number of measurement channels. Recording times are doubled if the number of measurement channels shown in the table is halved.

When recording 30 analog channels with two U8550/U8551 modules or one U8552 module (no alarm output, no waveform processing) When recording 30 analog channels with two LR8530/LR8531 modules or one LR8532 module (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
10 ms	1 d	3 d 20 h	15 d 8 h	30 d 12 h
100 ms	10 d 8 h	38 d 18 h	153 d 9 h	305 d 5 h
1s	103 d 13 h	387 d 12 h	1,533 d 21 h	3,052 d 9 h
10 s	500 d	3,875 d 6 h	15,339 d 3 h	30,523 d 19 h

When recording 20 channels with four U8553 modules or U8554 modules (no alarm output, no waveform processing) When recording 20 channels with four U8553 modules or LR8534 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
1ms	3 h 43 min	13 h 56 min	2 d 7 h	4 d 13 h
10 ms	1 d 13 h	5 d 19 h	23 d	45 d 18 h
100 ms	15 d 12 h	58 d 3 h	230 d 2 h	457 d 20 h
1s	155 d 8 h	581 d 7 h	2,300 d 21 h	4,578 d 13 h
10 s	500 d	5,813 d 1 h	23,008 d 20 h	45,785 d 20 h

When recording 330 channels with four U8552 modules and seven LR8532 modules (no alarm output, no waveform processing)

Recording intervals	Internal buffer memory (512 MB)	SD MEMORY CARD Z4001 (2 GB)	SD MEMORY CARD Z4003 (8 GB)	USB DRIVE Z4006 (16 GB)
20 ms	4 h 8 min	15 h 28 min	2 d 13 h	5 d 2 h
100 ms	20 h 42 min	3 d 5 h	12 d 18 h	25 d 10 h
1s	8 d 15 h	32 d 6 h	127 d 19 h	254 d 8 h
10s	86 d	322 d 16 h	1,277 d 23 h	2,543 d 9 h

## Control the instrument remotely and capture data on a PC

**HTTP** server function

## Control the instrument remotely from a PC

Use a standard Web browser to control the LR8450/LR8450-01, start and stop measurement, then enter comments.

## Use a mouse to operate waveforms displayed on a PC

Enjoy intuitive mouse-based control, including waveform scrolling and cursor operations.



**FTP** server function

#### Download data files onto a PC

Your PC can get files from inside the SD memory card or USB drive inserted to the LR8450/LR8450-01.

#### FTP client

#### Automatically transfer data files to an FTP server

Automatically transmit files to an FTP server from the SD memory card or in the USB drive inserted to the LR8450/LR8450-01.

#### NTP client function

## Set the logger's clock

Set the clock in the LR8450/LR8450-01 and synchronize it to an NTP server on the network.

#### E-mail transmission function

CAN-FD - Powertrain

CAN-FD - ADAS

## Receive email notices on errors and other information

Receive emails to your PC or mobile phone when there is a communication loss and when an error occurs during measurement and wireless module communications.


It can also send instantaneous values by e-mail periodically.

## Use with other tools


#### NEW

### **Output measured values using XCP on Ethernet**

The LR8450 supports XCP slave operation based on the XCP protocol, a standard developed by the Association for Standardisation of Automation and Measuring Systems (ASAM). You can perform control to start and stop measurement and acquire measured values using an XCP master. (Measured values from CAN modules cannot be output.)







•Overwrite control parameters while ECUs continue to operate
•Consolidate data from multiple measurement systems and buses
•Monitor large amounts of microcontroller RAM at high speeds

#### NEW

#### Load data using MDF-compatible waveform viewers

Voltage, temperature, strain, CAN, and other measurement data captured by the LR8450 can be saved in the Measurement Data Format (MDF) and loaded by other software that supports the format.


#### Commercially available software

#### **FAMOS**



- More than 400 calculation processing variables
- · Easy report creation functionality

#### FlexPro




- High-speed search and processing of large volumes of data
- Share analysis templates within your company

#### NI DIAdem



- Functionality ranging from searching and loading of data to analyzing and creating of reports
- · Dialog-based interface

#### OS-2000



- Freely edit large data that cannot be handled by Excel
- Simultaneously display the waveforms which have different frequencies

## Logger Utility (standard accessory)

### Collect data at sampling speeds of up to 10 ms on a PC



Recording interval

Simultaneous recording

2035 channels

No. of connected units up to 5

Save destination PC

Connection method

+ 60 waveform calculation chann


→ Simult

Simultaneously log data from five LR8450 instruments at a speed of up to 10 ms.

Display logged data in real time as a graph.

## **GENNECT** One

## Make simultaneous measurements using multiple instruments



Aggregate measurement data from not only loggers, but also waveform recorders, power meters, and other instruments onto a single PC.

Record data on a PC in real time using the Logger Utility application software, a standard accessory. You can even scroll waveforms backwards to view older data

while recording is in progress. A real-time measurement is supported for recording intervals of 10 ms or longer.

U8555 and LR8535 CAN Unit real-time measurement and viewing of waveform data are not supported. Please use the GENNECT One software for real time viewing of

CAN data by the U8555 and LR8535.

Display this measurement data on a single graph in real time. Summarize it in daily and monthly reports. Manage in in a centralized manner. GENNECT One is a Windows application that specializes in aggregating measurement data.

Data including CAN data from the U8555 and LR8535 can be viewed and measured in real time (logging function, dashboard function). Real time measurement and viewing of CAN data will be available from the LR8450's next firmware update around mid or late 2022.

GENNEC One is a free application.

Access this 2D Code for details and downloads.



Recording interval

Simultaneous recording

512 channels

Total No. of connected devices up to 15 \*

Save destination PC

Connection method

\*Up to 30 devices can be connected when using only the logging or dashboard functions

Simultaneously log data from instruments like recorders and power meters as frequently as 1 s.

Display logged data in real time as a graph. Automatically create CSV files and daily/monthly reports.



Graphically display measured values using the dashboard function. Visually identify anomalies.



Download instrument data files saved on instruments' SD cards.



Change instrument settings remotely.

Specificatio	1 Memory HiLogger	
	ions, basic specifications	
Product warranty period	3 years	
Accuracy guarantee period	1 year	
Maximum number of connectable modules	4 plug-in modules + 7 wireless modules* *LR8450-01 only No more than 4 CAN modules (U8555 and/or LR8535) can be connected.	
Connectable modules (plug-in modules)	U8550 VOLTAGE/TEMP UNIT U8553 HIGH SPEED VOLTAGE UNIT U8551 UNIVERSAL UNIT U8554 STRAIN UNIT U8555 CAN UNIT	
Connectable modules (wireless modules) (LR8450-01 only)	LR8530 WIRELESS VOLTAGE/TEMP UNIT LR8531 WIRELESS UNIVERSAL UNIT LR8532 WIRELESS VOLTAGE/TEMP UNIT LR8533 WIRELESS HIGH SPEED VOLTAGE UNIT LR8534 WIRELESS STRAIN UNIT LR8535 WIRELESS CAN UNIT	
Internal buffer memory	Volatile memory, 256 M-words	
Clock functionality	Auto-calendar, automatic leap year recognition, 24-hour clock	
Clock precision (precision of clock dis- played by instrument as well as start/stop times)	±1.0 s/day (at 23°C) Time can be synchronized with an NTP server to which the instrument is connected.	
Time axis accuracy	±0.2 s/day (at 23°C)	
Backup battery service life	For clock, at least 10 years (reference value at 23°C)	
Operating environment	Indoors, pollution degree 2, altitude up to 2000 m	
Operating temperature and humidity range	-10°C to 50°C (14°F to 122°F), 80% RH or less (non-condensing) (charging temperature range: 5°C to 35°C)	
Storage temperature and humidity range	−20°C to 60°C (−4°F to 140°F), 80% RH or less (non-condensing)	
Dimensions	Without any modules: 272W $\times$ 145H $\times$ 43D mm (10.72"W $\times$ 5.71"H $\times$ 1.69"D) (excluding protrusions) With 2 modules: 272W $\times$ 198H $\times$ 63D mm (10.71"W $\times$ 7.8"H $\times$ 2.78"D) (excluding protrusions) With 4 modules: 272W $\times$ 252H $\times$ 63D mm (10.71"W $\times$ 9.92"H $\times$ 2.48"D) (excluding protruding parts)	
Mass	Approx. 1108 g (39.08 oz.) (excluding battery pack)	
Standards	Safety: EN61010 EMC: EN61326 Class A	
Vibration resistance	JIS D 1601:1995:1995 5.3 (1) Class 1: Passenger vehicles; conditions: Class A equivalent	
Accessories	Quick start manual, LOGGER application disc (quick start manual, instruction manual, logger utility, logger utility instruction manual, CAN editor, CAN editor instruction manual, communication instruction manual), USB cable, AC adapter Z1014, precautions concerning use of equipment that emits radio waves (LR8450-01 only)	
Display		

Display	
Display	7-inch TFT color LCD (WVGA 800 × 480 dots)
Display resolution (with waveform display selected)	Max. 20 divisions (horizontal axis) × 10 divisions (vertical axis) (1 division = 36 dots [horizontal axis] × 36 dots [vertical axis])
Display language	Japanese, English, Chinese, Korean
Backlight service life	Approx. 100,000 h (reference value at 23°C)
Backlight saver	Turns off backlight when no key is operated for a set amount of time
Backlight brightness	5 levels (user-selectable)
Waveform background color	Dark/light (user-selectable)

Power sup	ply	
Power supply	AC adapter	Z1014 AC Adapter (12 V DC ±10%) AC Adapter rated supply voltage: 100 V to 240 V AC (assuming voltage fluctuation of ±10%) AC Adapter rated power supply frequency: 50/60 Hz
	Battery	LR8450 accommodates 2 batteries Z1007 Battery pack (when used with AC Adapter, AC Adapter takes priority) Li-ion, 7.2 V, 2170 mAh
	External power supply	10 V to 30 V DC
Power consumption	Normal power consumption	Using Z1014 AC adapter or 12 V DC external power supply, without Battery Pack With LCD at maximum brightness: 8.5 VA (instrument only) With LCD backlight off: 7 VA (instrument only)
	Maximum rated power	When using the Z1014 AC adapter 95 VA (including AC adapter) When using a 30 V DC external power supply 28 VA (while charging battery with LCD at maximum brightness) When using the Z1007 Battery pack 20 VA (with LCD at maximum brightness)
Continuous operating time	Battery	With one Z1007 Battery pack: approx. 2 h (reference value at 23°C) With two Z1007 Battery packs: approx. 4 h (reference value at 23°C) Conditions: with one U8551 Universal Unit connected, backlight on, voltage output off, and Z4006 connected
Charging functionality	Charging is available when the Z1007 Battery pack is attached and the AC adapter is connected.  Charging time: Annow 7 h (reference value at 23°C)	

Interface specifications The LAN interface and USB interface (function) cannot be used at the same time		
THE LANT	nterface and USB interface (function) cannot be used at the same time	
interface	IEEE 802.3 Ethernet, automatic 100Base-TX/1000Base-T detection Auto MDI-X, DHCP, DNS supported Connector: RJ-45 Maximum cable length: 100 m	
	LAN functionality: Acquiring data and setting recording conditions with Logger	

LAN interface	LAN func- Configuring settings and controlling recording using communicationality: tions commands
	Manually acquiring data using the FTP server: Acquiring files from a connected SD Memory Card or USB Drive
	Automatically sending of data via FTP (FTP client) Transferring files saved on a connected SD Memory Card or USB Drive
	Waveform files while measurement is in progress: binary, text, MDF Waveform files after measurement has finished: binary, text, MDF, numerical calculation result files
	HTTP server function Control mode (one instrument):
	Displaying screen and remotely controlling instrument and modules, current measured value display, starting/stopping mea- surement, acquiring data via FTP, setting comments, updating instrument and modules
	Browsing mode (up to four instruments):  Displaying screen, measurement status, and comments
	Email transmission Start trigger, stop trigger, alarm, power outage recovery, internal buffer memory full, media full, wireless unit communication interruption, battery low, and periodic mail transmission. Instantaneous values can be attached for start trigger, stop trigger, alarm, and periodic transmission Emails can be sent regularly at the following intervals: 30 min., 1 h 12 h, or 1 day.
	NTP client function
	Time synchronization with an NTP server Regular synchronization intervals: 1 h, 1 day Pre-measurement synchronization function
Wireless LAN	IEEE 802.11b/g/n Communications range: 30 m, line of sight
interface (LR8450-01	Encryption function: WPA-PSK/WPA2-PSK, TKIP/AES Usable channels: 1 to 11
only)	Auto-connect function: wireless LAN function can be toggled on and off. Supported modes: access point, station, wireless module connectivity Devices that can be connected in wireless module connectivity mode: wireles modules or PC/tablet
	You can use either a wireless module or PC/tablet with wireless connection Wireless Configuring settings and controlling recording using
	LAN func- communications commands
	tionality: Manually acquiring data using the FTP server Acquiring files from a connected SD Memory Card or USB Drive
	Automatically sending data via FTP (FTP client) Transferring files saved on a connected SD Memory Card or USB Drive
	HTTP server function
	Control mode (one instrument):  Displaying screen and remotely controlling instrument and modules, current measured value display, starting/stopping measurement, acquiring data via FTP, configuring comment, updating the instrument and modules
	Browsing mode (up to four instruments): Displaying screen, current measured value display, measuremen status, and comments Email transmission
	Start trigger, stop trigger, alarm, power outage recovery, internal buffer, memory full, media full, wireless unit communication interruption, low bat- tery, and periodic mail transmission. Instantaneous values can be attache for start trigger, stop trigger, alarm, and periodic transmission.
	Emails can be sent regularly at the following intervals: 30 min, 1 h, 12 h, 1 day  NTP client function
	Time synchronization with an NTP server Regular synchronization intervals: 1 h, 1 day
LICD	Pre-measurement synchronization function
interface	Standard compliance: USB 2.0 compliant Connectors: Series A receptacle × 2
(host)	Guaranteed-operation options: Z4006 USB drive (16 GB) File system: FAT16, FAT32
LICD	Connectable devices: keyboard, mouse, hub (1 layer), USB drive (1 port only
USB interface	USB standard: USB 2.0 compliant Connector: series mini-B receptacle
(function)	USB functionality: data acquisition, condition settings used with the Logger Utility software (bundled)  Configuring settings and controlling recording using com
	munications commands USB drive mode: transferring data from a connected SD memory card to a compute
SD card slot	Standard compliance: SD standard-compliant slot × 1 (with SD memory card/ SDHC memory card support)
	Guaranteed-operation options: Z4001 (2 GB), Z4003 (8 GB)
	File system: FAT16, FAT32
External c	ontrol terminals

File system: FAT 16, FAT32					
Externa	l control te	rminals			
Terminal block		Push-button type terminal block			
External I/O	Number of terminals	4, non-isolated (same	4, non-isolated (same GND as instrument)		
	Input	Input voltage	0 V to 10 V DC		
		Slope	Rising/falling (user-selectable)		
		Functionality	Choose from off, start, stop, start/stop, trigger input, event input		
	Output	Output format	Open-drain output (with 5 V voltage output)		
		Maximum switching capacity	5 V to 10 V DC, 200 mA		
		Functionality	Trigger output		
Alarm ou	ıtput	Output format	Open-drain output (with 5 V voltage output)		
		Maximum switching capacity	5 V to 30 V DC, 200 mA		
		Number of terminals	8, non-isolated (same GND as instrument)		
Voltage output		Output voltage	Off, 5 V, 12 V, 24 V* (user-selectable) Supply current: max. 100 mA each *24 V output can be selected for the VOUT- PUT1 terminal only		
		Number of terminals	2, non-isolated (same GND as instrument)		
GND ter	minal	Number of terminals	10 (common GND)		

	Al.		Loading		0	and the shade of 1000 and 1100	
Recording mode		+ 5 + 40 - 00 - 50 - 400 - 500 - 400	Loading saved data		Specifies a position and then loads up to 256 mega-data-points of previously saved text-format data.		
kecording interv		ms*, 5 ms*, 10 ms, 20 ms, 50 ms, 100 ms, 200 ms, 500 ms, 1 s, 2 s, 20 s, 30 s, 1 min., 2 min., 5 min., 10 min., 20 min., 30 min., 1 h			11		
	* Setting av	ailable only when using a module with data refresh intervals that include 1 ms	Calculat	ions			
Data refresh inter	rval Automat	Automatically- or user-selected value per module		Number of	Up to 10 calc	ulations simultaneously	
Repeat recordin	ig Circli (deel edectable)		calculations Calculation				
Specified ime/continuous	Time car (total 25	Specified time: recording time is set in days, hours, minutes, and seconds. Time can be set up to maximum capacity of internal buffer memory. (total 256 mega-data-points)			time, minimun usage ratio*2,	e, peak-to-peak value, maximum value, maximum value n value, minimum value time, integration*1, aggregation*1, on time*2, off time*2, on count*2, off count*2	
	If maxim	ous: recording is performed once until it is stopped.  um capacity of internal buffer memory is exceeded, memory verwritten.		Calculation	*1: total, positive, negative, or absolute value (user-selectable) *2: threshold values can be set for individual channels  During recording:		
recording Scroll thre		mega-data-points are saved in internal buffer memory. rough and view data stored in internal buffer memory. rurce data recording can be toggled on and off.		range	calculations performed for all data during recording After recording has stopped: calculations performed for all data in the internal buffer memory, or for dat		
Backup of recorded of	data None			Time split	Disabled, ena	n range specified by the A/B cursors (on the vertical axis) bled, or timed (user-selectable)	
Display				calcula- tion		ulations performed for all data during recording for each segment of time, starting with the start of mea-	
Sheet function	Max. nu CAN cha channel	Display sheets can be switched between all channels and individual modules.  Max. number of channels on all-channel display sheet: 120 analog/ CAN channels, 30 waveform calculation channels, 8 pulse/logic channels, 8 alarm channels			surement Segmentation time: set DD:HH:MM format Timed: calculations will be made at intervals of the segment time based on the previously set reference time. Reference time: set in hours and minutes.		
Vaveform displa screen	(channel Simultane	waveform display: simultaneous display of gages and settings settings and display settings) sous display of time-axis waveforms and values: instantaneous ursor values, or numerical calculation values (user-switchable)	Waveform	Calculation	31	nin, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h n, 4 h, 6 h, 8 h, 12 h, 1 d erations among channels	
	Numerica cal values	I display: simultaneous display of instantaneous values and statisti-	calculations	content	Calculated va through W30).	s, simple average, aggregation, and integration of any channel llues are recorded as data for calculation channels (W1 (Calculations are performed at the same time as measure	
Display format		s waveform display: 1 screen			ment. Values cannot be recalculated after measurement.)		
	X-Y wav	Y waveform display: 1 screen		Triggers			
(-Y composite		ite up to 8 waveforms.	Trigger m		Digital compa	arison method	
lumerical displa		decimal, or exponent (user-selectable)	Trigger tir		Start, stop, o		
ormat  Vaveform colors	be set (v	When decimal is selected, number of decimal places to display can be set (values will then be rounded to set number of places).  24 colors		Trigger conditions		reation performed on trigger source, interval trigger, or er s are disabled, free run	
ooming in and	Horizontal	2 ms to 1 day/division	Trigger sources			e, logic, waveform calculations, CAN (max. 100)	
out on the vaveform displa	axis	Niverbase of divisions are a second 40	Trigger ty		Analog, puise	Level triggers: trigger activated by arising or falling	
raveloitii dispia	Vertical axis	Number of divisions per screen: 10 Setting method Select position or upper and lower limits for each channel. (Waveform calculation channels: upper and lower limits only)		,	pulse, waveform calculations,		
		When setting by position: set zoom factor and zero position.  Zoom factor: 1/2 ×, 1 ×, 2 ×, 5 ×, 10 ×, 20 ×, 50 ×, 100 ×  Zero position: –50% to 150% (with a zoom factor of 1 ×)			Logic, CAN	area or when value enters area  Trigger activated when patterns of 1/0/X match (wher "X" indicates either)	
Vaveform scroll	ing Display	When setting by upper/lower limit: set upper and lower limit.	Interval tr	Interval triggers Trigger activated for set recording interval after setting minutes/seconds			
Monitor display	recordin	g is stopped (during waveform rendering only) stantaneous values and waveforms without recording data to	External t	signal. Rising/falling (user-selectable)  Trigger response time When using plug-in units: (recording interval or data refresh interval, whichever is longer)		ated by rising or falling edge at set level in external inpu g/falling (user-selectable)	
. ,	memory	values and waveforms can be displayed while waiting for a trigger) sthe battery remaining and the radio-wave strength, in the				val or data refresh interval, whichever is longer) × 2 + 1 ms + analo	
lisplay (LR8450-01 o	nly)  four leve	ls, of the wirelessly connected modules				, rireless units (LR8450-01 only): erval or data refresh time, whichever is longer)×2+wireless	
Save SE	,	rd or USB drive (user-selectable) nedia sold by Hioki are guaranteed for operation)			*1: depends o 5 ms and l	*2+analog response time*1 n filter settings (U8554 with a data refresh interval of ow-pass filter of 120 Hz).	
,		byte characters	Time of the state of			radio-wave state is in good condition, 1s.	
Au	utomatic num	bering, dating, assignment of title comment (user-selectable)	Trigger le resolution	vel	Analog	0.1% f.s. (f.s. = 10 divisions)	
(us	ser-selectable	real-time saving): off, binary format, text format, or MDF format tition results (saved after recording): off or text format (user-selectable)		count per rotation setting)  Pre-triggers Set day/hours/minutes/seconds.			
W	hen text form e or to save e	at is selected, choose whether to save all calculations in one ach calculation in its own file.			Can be set d	uring real-time saving.	
_	elete and	On/off (user-selectable)	Alarms				
De		available space, system will delete oldest waveform file		nditions	Set separate	ly for ALM1 to ALM8	
	.vc	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file			System will ou • AND/OR op • Low battery	put an alarm when any of the following conditions are satisfied eration performed on alarm sources	
De sa		USB drive starts to run out of available space.  On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.			System will ou • AND/OR op • Low battery • Thermocou	put an alarm when any of the following conditions are satisfied eration performed on alarm sources	
De sa	older Splitting	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable)	Alarm soi		System will ou  AND/OR op  Low battery Thermocou  Wireless en	tout an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout	
De sa		USB drive starts to run out of available space.  On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.	Alarm soil	ırces	System will ou  AND/OR op  Low battery  Thermocou  Wireless en  Analog, pulse  Alarm output	tout an alarm when any of the following conditions are satisfier eration performed on alarm sources ple burnout for (LR8450-01 only) e, logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless	
De sa	older Splitting	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable)		urces	System will ou AND/OR op Low battery Thermocou Wireless en Analog, pulse Alarm output module is de Off/now/3 min Now: outputs	tout an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) e, logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless	
De sa	older Splitting	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.	Wireless (LR8450-	urces error 01 only)	System will ou  AND/OR op  Low battery  Thermocou  Wireless en  Analog, pulst  Module is de  Off/now/3 min  Now: outputs  3 min: output  minutes.  Alarm output	iput an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) a, logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless tected in (user-selectable) an alarm upon a communications disruption is an alarm if a communication disruption continues for when low remaining battery life is detected for the	
De sa	older Splitting	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30	Low remarks the state of the st	error 01 only)	System will ou  AND/OR op  Low battery  Thermocou  Wireless en  Analog, pulse  Analog, pulse  Goffnow/3 min  Now: outputs  3 min: output  minutes.  Alarm output  instrument or  Alarm output  Alarm output  Alarm output	tout an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) e, logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless tected in (user-selectable) an alarm upon a communications disruption is an alarm if a communication disruption continues for when low remaining battery life is detected for the a wireless module.	
Fo Fil	older Splitting le splitting	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d	Wireless (LR8450- Low rema battery life	urces error 01 only)  uining e puple	System will ou AND/OR op Low battery Thermocou Wireless en Analog, pulse Alarm output module is de Off/now/3 min Now: outputs 3 min: output minutes. Alarm output instrument or	fout an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) e, logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless tected in (user-selectable) an alarm upon a communications disruption is an alarm if a communication disruption continues for swhen low remaining battery life is detected for the a wireless module.	
Fo Fil Ex eje car	older Splitting le splitting sternal media act (SD memory d or USB drive)	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by activating a button on the screen and confirming a message.	Wireless (LR8450- Low rema battery lift Thermood burnout	urces error 01 only)  uining e puple	System will ou AND/OR op Low battery Thermocou Wireless en Analog, pulse Alarm output module is de Off/now/3 min Now: output 3 min: output minutes. Alarm output instrument or Alarm output detection settin Analog, pulse, waveform calculation,	iput an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) e, logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless tected in (user-selectable) an alarm upon a communications disruption is an alarm if a communication disruption continues for when low remaining battery life is detected for the a wireless module.  when a thermocouple burnout occurs (when Tc burnout in its problem) Level: system will output an alarm following a rising or falling edge at set level  Window: set upper limit and lower limit	
Fo Fil Ex eje car	older Splitting le splitting  atternal media act (SD memory d or USB drive) ata protec-	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.  Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by activating a button on the screen and confirming a message.  Yes (valid only when Z1007 Battery Pack is installed) If remaining battery life declines during real-time saving, system will close file and stop saving data (although mea-	Wireless (LR8450- Low rema battery lift Thermood burnout	urces error 01 only)  uining e puple	System will ou  AND/OR op  Low battery  Thermocou  Wireless en  Analog, pulse  Alarm output  module is de  Off/now/3 min  Now: outputs  3 min: output  minutes.  Alarm output  instrument or  Alarm output  detection settii  Analog,  pulse,  waveform	iput an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) e, logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless tected in (user-selectable) an alarm upon a communications disruption so an alarm if a communication disruption continues for when low remaining battery life is detected for the a wireless module. when a thermocouple burnout occurs (when Tc burnout ng is enabled) Level: system will output an alarm following a rising or falling edge at set level Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area Slope: set level and time.	
Ex eje car tio	older Splitting le splitting  sternal media act (SD memory of or USB drive) ata protec- ata is saved or	USB drive starts to run out of available space.  On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable)  Disabled, enabled, or timed (user-selectable)  Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement.  Segmentation time: day, hour, or minute (user-selectable)  Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files.  Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by activating a button on the screen and confirming a message.  Yes (valid only when Z1007 Battery Pack is installed)  If remaining battery life declines during real-time saving, system will close file and stop saving data (although measurement operation will continue).	Wireless (LR8450- Low rema battery lift Thermood burnout	urces error 01 only)  uining e puple	System will ou AND/OR op Low battery Thermocou Wireless en Analog, pulse Alarm output module is de Off/now/3 min Now: outputs 3 min: output minutes. Alarm output instrument or Alarm output detection settin Analog, pulse, waveform calculation, CAN	iput an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) e. logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless tected in (user-selectable) an alarm upon a communications disruption s an alarm if a communication disruption continues for when low remaining battery life is detected for the a wireless module.  When a thermocouple burnout occurs (when Tc burnout is enabled)  Level: system will output an alarm following a rising or falling edge at set level  Window: set upper limit and lower limit System will output an alarm when value leaves area of when value enters area  Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the specified change rate during the set time interval.	
Ex eje car tio	older Splitting le splitting  ternal media act (SD memory d or USB drive) ata protec- noose either nen SAVE ke	USB drive starts to run out of available space. On: when SD memory card or USB drive starts to run out of available space, system will delete oldest waveform file (binary, text, or MDF) and then continue saving data.  No segmentation, 1 day, 1 week, or 1 month (user-selectable) Disabled, enabled, or timed (user-selectable) Disabled: data for each recording session is saved in its own file. Enabled: data for each set period of time is saved in its own file, starting with the start of measurement. Segmentation time: day, hour, or minute (user-selectable) Timed: data will be segmented at intervals of the segment time based on the previously set reference time and saved in separate files. Reference time: set in hours and minutes. Split time: 1 min, 2 min, 5 min, 10 min, 15 min, 20 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h, 1 d  External media can be ejected during real-time saving by activating a button on the screen and confirming a message.  Yes (valid only when Z1007 Battery Pack is installed) If remaining battery life declines during real-time saving, system will close file and stop saving data (although measurement operation will continue).	Wireless (LR8450- Low rema battery lift Thermood burnout	urces error 01 only)  sining e puple alarms	System will ou AND/OR op Low battery Thermocou Wireless en Analog, pulse Alarm output module is de Off/now/3 min Now: outputs 3 min: output minutes. Alarm output Analog, pulse, waveform calculation, CAN  Logic	iput an alarm when any of the following conditions are satisfied eration performed on alarm sources ple burnout for (LR8450-01 only) e. logic, waveform calculations, CAN (max. 100) when a wireless communication error with a wireless tected in (user-selectable) an alarm upon a communication disruption continues for when low remaining battery life is detected for the a wireless module.  when a thermocouple burnout occurs (when Tc burnout ing is enabled)  Level: system will output an alarm following a rising or falling edge at set level  Window: set upper limit and lower limit System will output an alarm when value leaves area or when value enters area  Slope: set level and time. The system will output an alarm when the rate of change (level per unit time) continues to exceed the	

Alarm retention	On/off (user-selectable) Clear alarms: when alarm retention is on, alarms will be cleared without stopping recording.		
Alarm tone	On/off (user-selectable)		
Alarm output response time	When using plug-in units: (recording interval or data refresh interval, whichever is longer)×2+1 ms+analog response time*' When using wireless units (LR8450-01 only): (recording interval or data refresh interval, whichever is longer)×2+wireless response time*2+analog response time*.		
	*1: depending on filter settings (U8554 with a data refresh interval of 5 ms and low-pass filter of 120 Hz). *2: when the radio-wave state is in good condition, 1s.		
Other functionality			

	Z. WHEH THE TA	ulo-wave state is in good condition, is.	
Other functionality			
Even mark function	Number of inputs	Up to 1000 inputs per measurement	
	Search waveform	ns and display target location in center of waveform screen.	
function	Search conditions	Search by choosing level, window, maximum value, minimum value, local maximum value, or local minimum value.	
	Search range	All data in internal buffer memory or data between A/B cursors (on vertical axis)	
	Search targets	Analog, pulse, logic, waveform calculations	
Jump function	Specify event mark, A/B cursor position, trigger point, or waveform display position to display that section in center of waveform screen.		
Cursor	Cursor display	All channels or specified channels (user-selectable)	
measurement function	Cursor movement	A, B, or simultaneous (user-selectable)	
Turiction	Types of cursors	Vertical or horizontal (user-selectable)	
Scaling function	Scaling settings	s can be configured separately for each channel	
Comment entry function	Enter titles and	channel-specific comments	
Start state retention function	On/off (user-se	On/off (user-selectable)	
Auto-start function	On/off (user-selectable)		
Functionality for saving setting conditions	Up to five groups of setting conditions can be saved in the instrument's internal backup memory.		
Auto setup function		ons saved in the instrument's memory or on an SD r a USB drive can be automatically loaded when the owered on.	
	If there are setting conditions stored in the instrument's memory as well as on an SD memory card and a USB drive, setting conditions have the following precedence:		
	instrument's me	emory, SD memory card, and USB drive.	
Prevention of inadvertent START/ STOP key operation	ing if user wishe	STOP key is pressed, system will display a message asks to start or stop measurement.	
		essage: enable/disable (user-selectable)	
Key lock function	Disables operation keys		
Beep tone	On/off (user-selectable)		
Self-check function	Can check keys, LCD, ROM/RAM, LAN, media, and modules.		
Display of horizontal axis (time values)	Horizontal axis (time value) display can be set to time, date, or data point count. These are reflected in saved text data.		
Measurement start/ stop time specifica- tion function	Set measurement start and stop conditions.  Specified time: set start time and stop time (year, month, day, hour, and minute)		
Configuration navigation (quick set) function	nectivity trouble	le registration guide (LR8450-01 only), wireless con- eshooting guide (LR8450-01 only), connection diagram gage, external terminals), loading setting conditions	
Power supply frequency filter function	50/60 Hz select	tion	

Input	
Pulse/logic input	t en
Number of channels	8 channels (common GND, non-isolated) Exclusive setting for pulse/logic input for individual channels
Terminal block	Push-button type terminal block
Adaptive input format	Non-voltage contact, open collector (PNP open collector requires external resistor), or voltage input
Maximum input voltage	0 V to 42 V DC
Input resistance	1.1 MΩ ±5%
Detection level	2 levels (user-selectable) High: 1.0 V or greater; low: 0 to 0.5 V High: 4.0 V or greater; low: 0 to 1.5 V
Pulse input	

Measurement range, resolution

	Measurement target		Range	Maximum resolution	Measurable range
	Count		1000 mega-pulse f.s.	1 pulse	0 to 1000 M pulse
	Rotational speed		5000/n (r/s) f.s.	1/n (r/s)	0 to 5000/n (r/s)
			300,000/n (r/min) f.s.	1/n (r/min)	0 to 300,000/n (r/min)
			n: number of pulses per rotation (1 to 1000)		
Pulse input With filter off: 200 µs or greater (100 µs or greater during high and low in period With filter on: 100 ms or greater (50 ms or greater during high and low in					
Slo	Slope Set risir		g/falling for each chan	nel.	
Mea	Measurement mode Integrat		ion (addition, instantaneous), rotational speed		
Instanta		Instanta	counts number of pulse neous: counts number (integrated value is res	of pulses input with	in each recording
	Rotational speed r/s: counts number of input pulses during 1 s and calculates rotations speed. r/min: counts number of input pulses during 1 min and calculates rotational speed.				
Smoothing Select value from and r/min).		ralue from 1 s to 60 s (v	valid only when set t	o rotational speed	

Chatter pre- vention filter	Set to on/off for each channel
Logic input	
Measure- ment mode	Records 1 or 0 for each recording interval

#### **Software Logger Utility specifications**

U8555 CAN unit and	LR8535 wireless CAN unit are not supported.
Operating Environment	Windows7 (32/64 bit)   Windows8 (32/64 bit)   Windows10 (32/64 bit)
Overview	Control PC-connected logger to receive, display, and save measured waveform data sequentially. (Total recording samples is maximum 10 million data. Data exceeding this number will be segmented into separate measurement files while recording continues.) *Real-time measurement on the LR8450, LR8450-01 is possible with a recording interval of 10 ms or more.
Function	Controllable loggers: 5 Data Collection System: 1 system Display Format:  • Waveforms (split time-axis display is possible)  • Numerical values (logging): numerical display can be enlarged  • Alarms  Above items can be displayed simultaneously Numerical value monitor Display: display in a separate window is possible.  Scroll: waveforms can be scrolled during measurement.
Data Collection	Settings: data collection settings of logger modlues can be configured Monitor function can be checked before measurement. Save: save settings from multiple devices supporting real-time measurement (LUS format) and measurement data (LUW format) as one file. Data save format: real-time data collection file (LUW format), transfer data in real-time or non-real-time to Microsoft Excel®, Excel® template can be specified  Event mark: recording during measurement is possible
Waveform Display	Supported files: waveform data file (LUW format, MEM format) Display format: waveforms (split time-axis display available), simultaneous display of numerical values (logging) is available Maximum number of channels: 2,035 channels (measured) + 60 channels (waveform calculation) Waveform display sheets: waveform of each channel can be displayed on any of the ten sheets Scroll: available Event mark recording: available Cursors: cursors A and B can be used to display voltage values at cursor positions. Screen capture: screen capture of waveform display is available
Data Conversion	Applicable files: waveform data file (LUW format, MEM format) Conversion section: all data, specified section Conversion format: CSV format (comma delimited, space delimited, tab delimited), transfer to Excel® sheet, LR5000 format (hrp2,hrp) Data thinning: simple thinning with any thinning number
Waveform Calculation	Calculation items: arithmetic operations Number of calculation channel: 60 channels
Numerical Calculations	Applicable data: waveform data file (LUW format, MEM format), real-time measurement data, waveform calculation Calculation items: average value, peak value, maximum value, time to maximum value, minimum value, time to minimum value, off time, on count, off count, standard deviation, aggregation, area value, and integration Save calculation: performs numerical calculation and save to file
Search	Applicable data: real-time data collection file (LUW format), main unit measurement file (MEM format), waveform calculation data Search mode: event mark, date and time, maximum position, minimum position, local maximum position, local minimum position, alarm position, level, window, and variation
Print	Applicable printer: printer compatible to the OS in use Applicable data: waveform data file (LUW format, MEM format) Print format: waveform image, report print, list print (channel settings, event, cursor value) Print area: all area, specified area by A-B cursor Print preview: available

#### Option specifications (sold separately)

#### Plug-in units: U8550, U8551, U8552, U8553, U8554, U8555 Shared specifications

Host model	LR8450/LR8450-01 MEMORY HILOGGER
Operating temperature and humidity range	-10°C to 50°C, 80% RH or less (non-condensing)
Storage temperature and humidity range	-20°C to 60°C, 80% RH or less (non-condensing)
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent
Accessories	User manual, mounting screw × 2, wiring confirmation label (U8554 only)

#### Wireless units: LR8530, LR8531, LR8532, LR8533, LR8534, LR8535 **Shared specifications**

Host model	LR8450-01 MEMORY HILOGGER
Control communications method	Connect wirelessly via Z3230 WIRELESS LAN ADAPTER (included)
Communications buffer memory	4 Mword (volatile memory) Saves data in the event of a communications error. Data is resent when communications are restored.
Operating temperature and humidity range	-20°C to 55°C, 80% RH (non-condensing) (charging temperature range: 5°C to 35°C)
Storage temperature and humidity range	-20°C to 60°C, 80% RH (non-condensing)
Vibration resistance	JIS D 1601:1995 5.3 (1), Class 1A (passenger vehicle) equivalent
LED display	Wireless connection and measurement status, error status, AC adapter or external power, battery power, charge status

Auto-connect function	Available
Accessories	Z3230 WIRELESS LAN ADAPTER, user manual, Z1008 AC ADAPTER, mounting plate, M3×4 screw × 2 (for use with mounting plate), wiring confirmation label (LR8534 only)
Z3230 wireless specifications	Wireless LAN (IEEE 802.11b/g/n) Range: 30 m (line of sight) Encryption: WPA-PSKWPA2-PSK, TKIP/AES Channels: channel 1 to 11

Power supply speci	incations
AC adapter	Z1008 AC ADAPTER (12 V DC, standard accessory) Rated supply voltage: 100 to 240 V AC Rated power supply frequency: 50/60 Hz Maximum rated power: 25 VA (including AC adapter) Normal power consumption (instrument only, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531; 3.0 VA LR8534, LR8535: 4.0 VA
Battery	Z1007 BATTERY PACK (when using AC adapter, AC adapter takes precedence.) Rated supply voltage: 7.2 V DC (Li-ion 2170 mAh) Maximum rated power LR8530, LR8532: 1.5 VA LR8531, LR8533: 2.0 VA LR8534, LR8535: 3.5 VA
External power supply	Rated supply voltage: 10 to 30 V DC Maximum rated power: 8 VA (30 V DC external power supply, while charging battery) Normal power consumption (12 V DC external power supply, without battery pack) LR8530, LR8532, LR8533: 2.5 VA LR8531: 3.0 VA LR8534, LR8535: 4.0 VA
Continuous operating time	When using Z1007 BATTERY PACK (all data refresh rates, good communications state, 23°C reference values) LR8530, LR8532, LR8533: approx. 9 h LR8531: approx. 7 h LR8534: approx. 5 h LR8535: approx. 10 h (approx. 5 h when using two non-contact CAN sensors)
Charging function	When Z1007 BATTERY PACK installed while connected to AC adapter or 10 to 30 V DC external power supply Charging time: approx. 7 h (23°C reference value)

VOLTAGE/TEMP UNIT U8550 UNIVERSAL UNIT U8551 VOLTAGE/TEMP UNIT U8552

WIRELESS VOLTAGE/TEMP UNIT LR8530 WIRELESS UNIVERSAL UNIT LR8531 WIRELESS VOLTAGE/TEMP UNIT LR8532

(Accuracy guaranteed for 1 year)

#### **General specifications**

General specificati	ons
Number of input channels	U8550: 15 (set voltage, thermocouple, or humidity for each channel) LR8530: 15 (set voltage or thermocouple for each channel) U8551, LR8531: 15 (set voltage, thermocouple, humidity, RTD, or resistor for each channel) U8552: 30 (set voltage, thermocouple, or humidity for each channel) LR8532: 30 (set voltage or thermocouple for each channel)
Input terminals	U8550, LR8530: M3 screw-type terminal block (2 terminals per channel) U8551, LR8531: push-button type terminal block (4 terminals per channel) U8552, LR8532: push-button type terminal block (2 terminals per channel)
Output terminals	M3 screw-type terminal block (1 output, 2 terminals, Z2000 HUMIDITY SENSOR power supply [can power up to 15 Z2000 HUMIDITY SENSOR])(LR8531 only)
Measurement target	U8550, U8552: voltage, temperature (thermocouples), humidity LR8530, LR8531: voltage, temperature (thermocouples) U8551, LR8531: voltage, temperature (thermocouples), humidity, temperature (RTD), resistor
Input type	Scanning by semiconductor relays All channels isolated (not isolated when measuring with RTD, resistance or humidity)
A/D resolution	16 bits
Maximum input voltage	±100 V DC (maximum voltage between input terminals without causing damage)
Maximum channel- to-channel voltage	300 V DC (maximum voltage that can be applied between each input channel without causing damage; not isolated when measuring with RTD, resistance or humidity) "Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.
Maximum rated terminal-to-ground voltage	300 V AC, DC (maximum voltage that can be applied between input channels and the instrument or its chassis, or between units without causing damage; humidity measurement not isolated)
Input resistance	10 M $\Omega$ or greater (10 mV f.s. to 2 V f.s. voltage ranges, thermocouple ranges, RTD and resistor ranges) 1 M $\Omega$ ±5% (10 V f.s. to 100 V f.s. voltage range, 1-5 V f.s. voltage range, humidity measurement)
Allowable signal source resistance	1 k $\Omega$ or less
Data refresh interval	10 ms to 10 s (10 selectable levels)
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout setting, and power supply frequency filter setting
Dimensions	U8550, U8551, U8552: approx. 134W × 70H × 63D mm (5.28"W × 2.76"H × 2.48"D) LR8530, LR8531, LR8532: approx. 154W × 106H × 57D mm (6.06"W × 4.17"H × 2.24"D)
Mass	U8550: approx. 345 g (12.2 oz.), U8551: approx. 318 g (11.2 oz.), U8552: approx. 319 g (11.3 oz.), LR8530: approx. 423 g (14.9 oz.), LR8531: approx. 386 g (13.6 oz.), LR8532: approx. 386 g (13.7 oz.), (including Z3230 WIRELESS LAN ADAPTER)
Accessories	Instruction Manual, installation screws × 2

Analog input specifications (23  $\pm$ 5°C [73  $\pm$ 9°F], 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

Range	Maximum resolution	Measurable range	Measurement accuracy
10 mV f.s.	500 nV	-10 mV to 10 mV	±10 μV
20 mV f.s.	1 μV	-20 mV to 20 mV	±20 μV
100 mV f.s.	5 μV	-100 mV to 100 mV	±50 μV
200 mV f.s.	10 μV	-200 mV to 200 mV	±100 μV
1 V f.s.	50 μV	-1 V to 1 V	±500 μV
2 V f.s.	100 μV	-2 V to 2 V	±1 mV
10 V f.s.	500 μV	-10 V to 10 V	±5 mV
20 V f.s.	1 mV	-20 V to 20 V	±10 mV
100 V f.s.	5 mV	-100 V to 100 V	±50 mV
1-5 V f.s.	500 μV	1 V to 5 V	±5 mV

Thermocouple (not including accuracy of reference junction compensation)

ype	Range	Measurable range	Maximum resolution	Measurement accura
K	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
			0°C to less than 500°C	±0.5
			500°C to 1,350°C	±0.7
J	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
			-100°C to less than 0°C	±0.7
			0°C to 1,200°C	±0.5
E	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.7
			0°C to 100°C	±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±0.9
	000 0	0.00 0	-100°C to less than 0°C	±0.7
			0°C to 500°C	±0.5
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±0.9
	2,000 0 1.3.	0.10	-100°C to less than 0°C	±0.7
		-	0°C to 1.000°C	±0.7
Т	100°C f.s.	0.01°C	-100°C to less than 0°C	±0.5
1	100 C 1.8.	0.01 6	0°C to 100°C	
	50000 f -	0.0590		±0.5
	500°C f.s.	0.05°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
	0000001-	0.490	0°C to 400°C	±0.5
	2000°C f.s.	0.1°C	-200°C to less than -100°C	±1.4
			-100°C to less than 0°C	±0.7
		2.24.2	0°C to 400°C	±0.5
N	100°C f.s.	0.01°C	-100°C to less than 0°C	±1.1
	50000 6	0.0500	0°C to 100°C	±0.9
	500°C f.s.	0.05°C	-200°C to less than -100°C	±2.1
			-100°C to less than 0°C	±1.1
			0°C to 500°C	±0.9
	2,000°C f.s.	0.1°C	-200°C to less than -100°C	±2.1
			-100°C to less than 0°C	±1.1
			0°C to 1,300°C	±0.9
R	100°C f.s.	0.01°C	0°C to 100°C	±4.4
	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 1,700°C	±2.2
S	100°C f.s.	0.01°C	0°C to 100°C	±4.4
	500°C f.s.	0.05°C	0°C to less than 100°C	±4.4
		[	100°C to less than 300°C	±2.9
			300°C to 500°C	±2.2
	2,000°C f.s.	0.1°C	0°C to less than 100°C	±4.4
			100°C to less than 300°C	±2.9
			300°C to 1,700°C	±2.2
В	2,000°C f.s.	0.1°C	400°C to less than 600°C	±5.4
		"	600°C to less than 1,000°C	±3.7
			1,000°C to 1,800°C	±2.4
С	100°C f.s.	0.01°C	0°C to 100°C	±1.7
-	500°C f.s.	0.01°C	0°C to 500°C	±1.7
	000 0 1.5.	0.00 C	0 0 10 000 0	£1.1

Reference junction compensation: internal/external	At INT RJC, total accuracy = add ±0.5°C
detection: on/off	System will check for burnout at each data refresh interval during thermocouple measurement. (not available with 10 ms interval)

#### U8550, U8551, U8552, LR8531 only input specifications Humidity (use HUMIDITY SENSOR Z2000)

#### **HUMIDITY SENSOR Z2000**

Operating temperature and humidity range:


0°C to 50°C (32°F to 122°F), 100% RH or less (non-condensing)

Range	Maximum resolution	Measurable range
100% rh f.s.	0.1% rh	5.0% rh to 95.0% rh

#### HUMIDITY SENSOR Z2000 accuracy

If the humidity value lies on a boundary line below, the better of the two regions' measurement accuracy values applies.





#### U8551, LR8531 only input specifications

Temperature RTD Connection: 3-wire/4-wire, measurement current: 1mA (Pt100, Jpt100), 0.1 mA (Pt1000) Standards: Pt100, Pt1000: JIS C1604-2013, IEC751 JPt100: JIS C1604-1989

Туре	Range	Maximum resolution	Measurable range	Measurement accuracy
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
Pt100	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
JPt100	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 500°C	±0.9°C
	100°C f.s.	0.01°C	-100°C to 100°C	±0.5°C
Pt1000	500°C f.s.	0.05°C	-200°C to 500°C	±0.7°C
	2,000°C f.s.	0.1°C	-200°C to 800°C	±0.9°C

<sup>\*</sup>When using Pt1000, data refresh intervals of 10ms, 20m, and 50ms are not available.

#### Connection: 4-wire; measurement current is 1 mA

Range	Maximum resolution	aximum resolution Measurable range	
10 $\Omega$ f.s. 0.5 m $\Omega$		0 Ω to 10 Ω	±10 mΩ
20 Ω f.s.	1 mΩ	0 Ω to 20 Ω	±20 mΩ
100 Ω f.s.	5 mΩ	0 Ω to 100 Ω	±100 mΩ
200 Ω f.s.	10 mΩ	0 Ω to 200 Ω	±200 mΩ

HIGH SPEED VOLTAGE UNIT	WIRELESS HIGH SPEED VOLTAGE UNIT
U8553	LR8531

(Accuracy guaranteed for 1 year)

#### **General specifications**

Number of input channels	5 (voltage only)
Input terminals	M3 screw-type terminal block (2 terminals per channel), outfitted with terminal block cover
Measurement target	Voltage
Input type	Scanning by semiconductor relays, all channels isolated
A/D resolution	16 bits
Maximum input voltage	±100 V DC (maximum voltage between input terminals without causing damage)
Maximum channel-to- channel voltage	300 V DC (maximum voltage between input channels without causing damage)
	*Channels are isolated from each other with semiconductor relays. Never allow a voltage exceeding the product specifications, for example a lightning surge, to be applied across channels as doing so may cause the semiconductor relays to short.
Maximum rated termi- nal-to-ground voltage	300 V AC, DC (maximum voltage between input channel and chassis, or between modules, without causing damage)
Input resistance	1 MΩ ±5%
Allowable signal source resistance	100 $\Omega$ or less
Data refresh interval	1 ms to 10 s (13 selectable levels)
Digital filters	Digital filter cutoff frequency is automatically set to data refresh interval, burnout detection setting, and power supply frequency filter setting.
Dimensions	U8553: approx. 134W×70H×63D mm (5.28"W×2.76"H×2.48"D) LR8531: approx. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)
Mass	U8553: approx. 237g (8.4 oz.) LR8531: approx. 370g (13.1 oz.) (including Z3230 WIRELESS LAN ADAPTER)

Analog input specifications (23  $\pm 5^{\circ}$ C/73  $\pm 9^{\circ}$ F, 80% rh or less, after 30 minutes of warm-up and zero-adjustment, with the 50/60 Hz cut-off setting selected)

Measurement target	Range	Maximum resolution	Measurable range	Measurement accuracy
Voltage	100 mV f.s.	5 μV	-100 mV to 100 mV	±100 μV
	200 mV f.s.	10 μV	-200 mV to 200 mV	±200 μV
	1 V f.s.	50 μV	-1 V to 1 V	±1 mV
	2 V f.s.	100 μV	-2 V to 2 V	±2 mV
	10 V f.s.	500 μV	-10 V to 10 V	±10 mV
	20 V f.s.	1 mV	-20 V to 20 V	±20 mV
	100 V f.s.	5 mV	-100 V to 100 V	±100 mV
	1-5 V f.s.	500 μV	1 V to 5 V	±10 mV

STRAIN UNIT L	J8554	WIRELESS STRAIN UNIT LR8534			
(Accuracy guarant General specifica		year)			
Number of input channels	5 (set voltage or strain for each channel)				
Input terminals	Push-but terminal l	ton type terminal block (5 terminals per channel), outfitted with block cover, set DIP switches according to measurement target			
Measurement	Voltage				
target	Strain	Strain gage-type converter Strain gage 1-gage method (2-wire setup), 1-gage method (3-wire setup), 2-gage method (adjacent sides), 4-gage method			
Adaptive gage resistance		nethod, 2-gage method: 120 $\Omega$ (external bridge box required for 350 $\Omega$ ) nethod: 120 $\Omega$ to 1 $k\Omega$			
Gage ratio	2.0 (fixed	d)			
Bridge voltage	2 V ±0.0	5 V DC			
Balance	Method	Electronic auto-balancing			
adjustment	Range	Voltage: ±20 mV or less (1 mV f.s. to 20 mV f.s. range), ±200 mV or less (50 mV f.s. to 200 mV f.s. range) Strain: ±20,000 με or less (1,000 με f.s. to 20,000 με f.s. range), ±200,000 με or less (50,000 με f.s. to 200,000 με f.s. range)			
Input type		d differential input, simultaneous sampling of all channels (non- channels)			
A/D resolution	16bit	·			
Maximum input voltage	±0.5 V D damage)	C (maximum voltage between input terminals without causing			
Maximum channel- to-channel voltage	Non-isola	ated (all channels share common GND)			
Maximum rated terminal-to-ground voltage		AC or 60 V DC (maximum voltage between input channel and without causing damage)			
Input resistance	2 MΩ ±5	%			
Data refresh interval	1 ms to 10 s (13 selectable levels)				
Low-pass filter	Cut-off frequency: -3 dB ±30% Auto, 120, 60, 30, 15, 8, 4 (Hz) Auto: cut-off frequency of low-pass filter is automatically set based on set data refresh interval.				
	Attenuati	on characteristics: 5th-order butterworth filter, −30 dB/oct			
Dimensions	U8554: approx. 134W×70H×63Dmm (5.28"W×2.76"H×2.48"D) LR8534: approx. 154W×106H×57D mm (6.06"W×4.17"H×2.24"D)				
Mass		U8554: approx. 236g (8.3 oz.) LR8534: approx. 372g (13.1 oz.) (including Z3230 WIRELESS LAN ADAPTER)			

Analog input specifications (23  $\pm 5^{\circ}$ C/73  $\pm 9^{\circ}$ F, 80% rh or less, auto-balance at least 30 minutes after power on, with LPF set at 4 Hz)

1 301 41 4 112)					
Measure- ment target	Range	Maximum resolution	Measurable range	Measurement accuracy	
Voltage	1 mV f.s.	50 nV	-1 mV to 1 mV	±9 μV	
	2 mV f.s.	100 nV	-2 mV to 2 mV	±10 μV	
	5 mV f.s.	250 nV	-5 mV to 5 mV	±25 μV	
	10 mV f.s.	500 nV	-10 mV to 10 mV	±50 μV	
	20 mV f.s.	1 μV	-20 mV to 20 mV	±100 μV	
	50 mV f.s.	2.5 μV	-50 mV to 50 mV	±250 μV	
	100 mV f.s.	5 μV	-100 mV to 100 mV	±500 μV	
	200 mV f.s.	10 μV	-200 mV to 200 mV	±1 mV	
Strain	1,000 με f.s.	0.05 με	-1,000 με to 1,000 με	±9 με	
	2,000 με f.s.	0.1 με	-2,000 με to 2,000 με	±10 με	
	5,000 με f.s.	0.25 με	-5,000 με to 5,000 με	±25 με	
	10,000 με f.s.	0.5 με	-10,000 με to 10,000 με	±50 με	
	20,000 με f.s.	1 με	-20,000 με to 20,000 με	±100 με	
	50,000 με f.s.	2.5 με	-50,000 με to 50,000 με	±250 με	
	100,000 με f.s.	5 με	-100,000 με to 100,000 με	±500 με	
	200,000 με f.s.	10 με	-200,000 με to 200,000 με	±1000 με	

Internal bridge resistance precision tolerance: ±0.01%; temperature characteristics: ±2 ppm/°C

<sup>\*</sup> Measurement accuracy does not include internal bridge resistance tolerance and temperature characteristics

CAN UNIT U85	55	WIRELES	SS CAN UNIT LR8535	
General specifica	ntions			
Number of ports	2			
Input terminals	D-sub 9 pin MALE × 2			
input torrinido				
	$\left(\begin{array}{cccccccccccccccccccccccccccccccccccc$			
	Pin No.	Signal	Function	
	1	N.C.	Unused	
	2	CAN L	CAN L communications line	
	3	GND	GND	
	4	N.C.	Unused	
	5	N.C.	Unused	
	6	N.C.	Unused	
	7	CAN_H	CAN_H communications line	
	8	N.C.	Unused	
	9	N.C.	Unused	
Dawer august.	LICD next /sennes	tara Cariaa	A recented a v 2)	
Power supply terminals	USB port (connectors: Series A receptacle × 2) Dedicated power supply for Hioki NON-CONTACT CAN SENSOR			
(LR8535 only)	'	,		
Interface	CAN, CAN FD, CAN FD (non-ISO)			
Terminator	On/off setting available for each port			
ACT LED	120 Ω ±10 Ω built-in resistance Displays CAN bus operating status			
TERM LED	Illuminates when terminator is on			
Data refresh interval	10 ms to 10 s (10 selectable levels)			
Baud rate	CAN/CAN FD (arbitration): 50k, 62.5k, 83.3k, 100k, 125k, 250k,			
	500k, 800k, 1,000k [Baud] CAN FD (data): 0.5M, 1M, 2M, 2.5M, 4M, 5M [Baud]			
Sampling point	CAN or CAN FD (arbitration): 50.0% to 95.0% CAN or CAN FD (arbitration): 50.0% to 95.0%			
ACK	ACK response when receiving CAN data can be set to on or off			
transmission	·			
Operation mode	U8555: supports switching between receive mode and measured value output mode LR8535: supports only receive mode			
Dimensions	U8553: approx. 134W×70H×54D mm (5.28"W×2.76"H×2.13"D) LR8531: approx. 154W×106H×48D mm (6.06"W×4.17"H×1.89"D)			
Mass	U8553: approx. 235 g (8.3 oz.) LR8531: approx. 355 g (12.2 oz.) (including Z3230 WIRELESS LAN ADAPTER			
Receive mode sp				
No. of			nax. 50 channels (max. 50 signals)	
measurement channels	Data refresh interval 20 ms: max. 100 channels (max. 100 signals) Data refresh interval 50 ms: max. 250 channels (max. 250 signals)			
on annicio	Data refresh interval 100 ms or greater: max. 500 channels (max.			
Receive ID count	500 signals)  Function for recording the number of times a target ID is received during the data refresh interval			
User-defined	Sends user-defined CAN frames during receive mode operation			
frame transmission (U8555 only)	No. of configurabl			
	output mode specifications (U8555 only)			
Overview	Converts LR8450 measured values and output them as CAN frames.			
Output target	Measurement data from plug-in modules (other than CAN Unit)			
Output data	Depends on data refresh interval of module generating output (as			
refresh period	fast as 1 ms)  Data refresh interval × 2 ± 1 ms ± analog response time (*1)			
Response	Data refresh interval × 2 + 1 ms + analog response time (*1) 1 Varies with filter settings (U8554: 5 ms with 120 Hz low-pass filter)			
	cations (LR8535 c			
LED display when in wireless mode	Wireless connection, measurement status, error status, AC adapter or external power supply, battery power, charge status			
III WII EIESS IIIOUE		supply, Dati	ery power, charge status	
Control keys	HALITOL IRESETI			
Control keys Auto-connect	[AUTO], [RESET] Available			

#### **CAN Editor (software) specifications**

General specificat		100 100 100 100 100 100 100 100 100 100	
<u> </u>	Windows 10 (32/64-bit), Windows 11 (64-bit)		
Interface	LAN/USB		
	Japanese/English/Chinese		
	HIOKI LR8450/LR8450-01 MEMORY HILOGGER		
Set module position	Wireless module 1 to wireless module 7		
CAN interface set- ting	sampling points, ACK		
Module operating mode	Switch between receive mode and measured value output mod on a module-by-module basis		
Receive mode sett	ings		
Data refresh interval	10 ms to 10 s (10 selectable levels)		
Receive channel definition settings	CAN input port settings		
	Channel type	Data or ID count	
	Shared settings	1. Format: standard/extended 2. ID: 0h to 1 FFFFFFh 3. Comment 4. Unit 5. Factor, offset	
	Channel type: data	Start bits: 0 to 511     Bit length: 1 to 64 [bits]     Byte order: Motorola/Intel     Data type: unsigned/signed/IEEE/float	
	LR8450 display settings	Display upper limit value or display lower limit value     No. of display digits, display format     Numerical calculation threshold     Waveform color	
User-defined frame transmission set- tings	Receive condition numbe	No. 1 to No. 8	
	CAN output port set- ting	Port 1 or Port 2	
	No. of frame	1 to 8	
	Regular transmis- sion setting	On/off	
	Regular transmis- sion interva	1 to 9999 (× 10 [ms])	
	Timing	At measurement start, at measurement stop at start trigger, at alarm, manual	
	Frame type	CAN standard, CAN extended, CAN FD standard, CAN FD extended	
	Transmit ID	0 h to 1FFFFFF h	
	DLC (bite)	0 to 15 (0, 12, 16, 20, 24, 32, 48, 64)	
	Transmit data	Set as hexadecimal value	
	Delay	0 to 9999 (× 10 [ms])	
Measured value out	put mode setting		
Measured value output setting	CAN output port set-	Port 1 or Port 2	
	Frame type	Standard/extended	
	ID	0 h to 1FFFFFFF h	
	Data	Measured values from the following module can be set as output data U8550, U8551, U8552, U8553, U8554	
CAN bus load ratio estimation function		lld be the CAN bus load increase rate if were to be output using the current settings	
File specifications	ı		
Save function	CANdb file (.dbc) for transmit data defined using measured value output mode settings     Overall settings data for CAN Editor (.CES)		
Load function	Loads CANdb files (.dbc) and MR8904 definition files (.CDF) and use them to configure receive channel settings.     Loads LR8450 settings (.SET) and CAN Editor settings (.CES and applies them to the CAN Editor's overall settings.		
Title	and applies them to the CAN Editor's overall settings.  Sets titles for settings data (.CES) (up to 50 single-byte or 2.1.		
	double-byte characters).		

#### **Model: MEMORY HILOGGER LR8450**



#### Option

#### Plug-in modules



#### **VOLTAGE/TEMP UNIT U8550**

Channels: 15; maximum sampling rate: 10 ms



#### **UNIVERSAL UNIT U8551**

Channels: 15; maximum sampling rate: 10 ms



#### VOLTAGE/TEMP UNIT U8552

Channels: 30: maximum sampling rate: 20 ms (When 15 or fewer channels are used, 10 ms)



#### **HIGH SPEED VOLTAGE UNIT U8553**

Channels: 5; maximum sampling rate: 1 ms



#### **STRAIN UNIT U8554**

Channels: 5; maximum sampling rate: 1 ms



#### **CAN UNIT U8555**

Ports: 2, input: CAN or CAN FD, output: CAN or CAN FD maximum sampling rate: 10 ms

#### Model No. Specifications (order code) LR8450 Standard model, main unit only LR8450-01 Wireless LAN equipped model, main unit only

- The LR8450 and LR8450-01 cannot perform measurement on their own. One or more plug-in modules or wireless modules are required (sold separately).
- The LR8450-01 and each wireless module emit radio waves. Use of radio waves is subject to licensing requirements in certain countries. Using it in a country or region other than those indicated may violate the law and may result in legal penalties for the operator. For the latest information about countries and regions where wireless operation is currently supported, please visit the Hioki website.

#### Wireless modules



#### WIRELESS VOLTAGE/TEMP UNIT LR8530

Channels: 15; maximum sampling rate: 10 ms



#### **WIRELESS UNIVERSAL UNIT LR8531**

Channels: 15; maximum sampling rate: 10 ms



#### WIRELESS VOLTAGE/TEMP UNIT LR8532

Channels: 30: maximum sampling rate: 20 ms (When 15 or fewer channels are used, 10 ms)



#### **WIRELESS HIGH SPEED VOLTAGE UNIT LR8533**

Channels: 5; maximum sampling rate: 1 ms



#### **WIRELESS STRAIN UNIT LR8534**

Channels: 5; maximum sampling rate: 1 ms



#### **WIRELESS CAN UNIT LR8535**

Ports: 2, input: CAN or CAN FD, maximum sampling rate: 10 ms

## **Power supplies**

For instrument and wireless modules



**BATTERY PACK** Z1007

Instrument takes two; wireless modules take one

For instrument



**AC ADAPTER** Z1014

For wireless modules



AC ADAPTER Z1008

#### **Fixed Stand**



**FIXED STAND** Z5040

For installing logger on wall

#### CASE



**CARRYING CASE** C1012

Accommodates instrument and four plug-in modules or seven wireless modules

#### Wireless Lan Adapter

For wireless modules



WIRELESS LAN ADAPTER Z3230

### Cables, sensors, etc.



#### LAN CABLE 9642

Straight Ethernet cable, supplied with straight to cross conversion adapter, 5 m (16.41 ft) length



#### **HUMIDITY SENSOR** Z2000

(analog output), 3 m (9.84 ft) length





### Thermocouple

For reference only. Please purchase locally.



#### **CAN CABLE 9713-01**

For the U8555, LR8535. Unprocessed on one end, 1.8 m (5.91 ft) length



#### NON-CONTACT CAN SENSOR SP7001-95

Supports CAN FD or CAN signals, SP7001, SP9250, SP7150 set

#### Storage media

\*Always use HIOKI optional storage media. Proper operation is not guaranteed when using storage media from other manufacturers, and may prevent the product from saving and loading data properly.



#### SD memory card Z4001

2 GB capacity



SD memory card Z4003

8 GB capacity



#### USB drive Z4006

16 GB, long-life, high-reliability SLC flash memory

#### For the PC



#### LOGGER UTILITY/CAN EDITOR

measurement of loggers, real-time data collection CAN EDITOR: CAN configuration software Standard accessory You can download the latest version from our websit

#### **GENNECT One**

LOGGER UTILITY: The control of the Displays measurement results from multiple instruments in graph form Free application for Windows